


[Back to CD Contents](#)

Repair Manual No.4

# BMW 524td - 535i U.S.

11/85



# Main contents

Introduction		34 Brakes .....	613
00 Maintenance and general data .....	03	35 Pedals .....	658
11 Engine .....	25	36 Wheels and tires .....	667
12 Engine electrical equipment .....	149	41 Body .....	674
13 Fuel system .....	194	51 Body equipment .....	726
16 Fuel tank and lines .....	288	52 Seats .....	786
17 Radiator .....	294	54 Hood, sunroof .....	806
18 Exhaust system .....	303	61 Electrical system .....	820
21 Clutch .....	308	62 Instruments .....	830
23 Manual transmission .....	316	63 Lights .....	857
24 Automatic transmission .....	368	64 Heating and air conditioning .....	863
25 Gear shift mechanism .....	464	65 Radio and special equipment .....	898
26 Propeller shaft .....	482	72 Equipment and accessories .....	936
31 Front axle .....	498	for body	
32 Steering and wheel alignment .....	519	97 Body cavity sealing and .....	943
33 Rear axle .....	576	undercoating	

# 00 Maintenance and general data

Introduction .....	0-	1
Lifting the vehicle with a car hoist .....	0-	2
Lifting the vehicle with a garage jack .....	0-	2
Towing .....	0-	3

## **BMW maintenance system**

00 00 009	Pre-delivery inspection .....	00-	1
210	BMW running-in inspection at 1,200 miles .....	00-	7
220	BMW inspection I .....	00-	10
230	BMW inspection II = inspection I + additional work .....	00-	14
240	BMW annual check .....	00-	16
249	BMW engine oil service .....	00-	17
259	Additional rec. service .....	00-	18

# Introduction

The repair manual microfilm is to assist you in performing the necessary maintenance and repair work expertly and correctly. It must be placed at the disposal of workshop foremen and mechanics, and will complement the practical and theoretical training offered by our Service training schools.

Specifications and adjusting values are shown on the technical data and nominal value microfilms.

This repair manual microfilm is in reference to a standard production car free from accident damage and not subsequently modified in any way.

The group system has been adopted from the flat rate manual.

The job numbers used in the text are meant for use as cross reference. They will frequently contain job procedures, which must not be used for extension of the flat rates. They are only provided to make the finding of repair procedures easier.

The individual page numbering, for example 32-6, means:

32 - main group

6 - page number (in ascending numerical order)

The special tools essential for correct repair work are summarized on the special tool microfilm, Order number 01 99 9 699 422. Their use is illustrated in the descriptions of the various repair jobs.

The removal work is described for each repair job in this manual. If installation does not take place in the reverse order of work, an "installation" note is provided.

In addition to the improvements supplied to you regularly in the form of "Service Information", you are recommended to consult the parts microfilms for additional illustrated data.

**BAYERISCHE MOTOREN WERKE AG**  
**SERVICE DEPARTMENT**

© 1981 by Bayerische Motoren Werke AG, 80788 Munich, Germany;  
Service Division


All rights reserved. Not to be reproduced wholly or in part without written permission.  
Printed in Germany.




## GENERAL INFORMATION

## LIFTING VEHICLE ON A LIFTING PLATFORM


Before driving a car on the platform, make sure that there is sufficient space (clearance) between the lifting platform and vehicle (if applicable spoiler, splash guard, etc.).



Lifting platforms must conform with local and national legislative measures concerning accident prevention and maintenance. Arms of a lifting platform must always be applied only on the reinforced points of the frame members.



Front: Apply rubber block of lifting arm on the front perpendicular reinforcement of the frame member, which is also provided for application of the car's jack.




Rear: Apply rubber block of lifting arm on the rear perpendicular reinforcement of the frame member, which is also provided for application of the car's jack.


## LIFTING VEHICLE ON A WORKSHOP TROLLEY JACK

A workshop trolley jack may also only be applied for lifting the vehicle on the same take-up points described for the lifting platform.

A suitable liner (rubber, wood or plastic) must be used between the jack and vehicle to avoid damage to the undercoating, frame members or floor plate.



Front Take-up Point



Rear Take-up Point

## TOWING

Please conform with local and national legislative measures concerning the towing of vehicles as applicable.

Turn the ignition key to position "1" to unlock the steering wheel and be able to use the turn signals, horn and possibly windshield wipers.

Since the brake booster only works with the engine running, greater force will be required on the brake pedal of cars with a brake booster when the "engine is stopped".

The towing cable should be elastic to protect the towing and towed vehicles. Consequently only use plastic fiber cables or cables with elastic links.

### *Cars with Automatic Transmission:*


Selector lever in "N".

Max. towing speed: 50 km/h (30 mph).

Max. towing distance: 40 to 50 kilometers  
(25 to 30 miles).

If the car has to be towed further than 50 km (30 miles) add an extra liter (2 pints) of ATF than the specified oil volume for automatics or remove the propeller shaft.  
After repairing the car it is absolutely essential to correct the ATF volume to the specified amount.

0-3



Towing eyes front

Towing eye rear



# 00-2

00 00 009 Pre-Delivery Inspection	General Information					Important Instructions!
	Repair Manuel	Specifications	Nominal Values	Service Information	Owner's Manual	
Check nuts and bolts of steering box, coupling, tie rods, front axle for tightness, or presence of cotter pins		Gr. 32/34				Check locks and cotter pins
Check power steering for leaks						Visual inspection Use approved brake fluids only; tightening torque
Check fluid level in tank for hydraulic brake and clutch systems		Gr. 34		Gr. 00		
Check connections and lines of brake system for leaks, damage or wrong routing						Visual inspection
Check tire condition, tire size and type as well as tire inflation pressure (also spare wheel)		Gr. 36		Gr. 36	+	
Check wheel bolts for specified tightening torque		Gr. 36				
Check function of lights: parking lights, turn signals, tail lights, stop lights, high and low beam headlights, side marker lights, backup light(s), license plate lights, passenger compartment light and delay system, glove box light, trunk light and engine compartment light					+	
Check aiming of headlights	Gr. 63					
Check function of horns, headlight flasher and hazard light and control					+	
Adjust digital clock					+	
Program on board computer and check operation of lever and push button control						

00 00 009 Pre-Delivery Inspection	General Information					Important Instructions!
	Repair Manual	Specifications	Nominal Values	Service Information	Owner's Manual	
<p>Check instrument and sign lights, and brightness control</p> <p>Check indicator and warning lamps, clock, buzzer and check control: alternator, oil pressure, coolant temperature, turn signal indicator, fog light indicator, oxygen sensor, seat belt lamps, ignition key warning buzzer, high beam indicator, fuel gauge, ABS and SRS light, Check control function</p> <p>524 td: check indicator lights of glow plug system</p> <p>Fill supply tank for windshield washing system, check antifreeze protection</p> <p>Check function of windshield wipe/wash system and aiming of spray jets, remove protective sleeves on wiper blades</p> <p>Check rear window defogger</p> <p>Check function of cigar lighter</p> <p>Check function of headlight cleaners</p> <p>Radio: check antenna, trimming, tune in station, check shielding with engine running while switching all electric equipment on and off check cassette tape player</p> <p>Check function of other special equipment, e.g.: electric windows front and rear, sun roof in all positions, fog lights and aiming, electric radio antenna and speaker balance control. Check other equipment installed by dealer</p> <p>Check outside mirrors</p> <p>Check operation of central locking system</p> <p>Check seat adjustment manual/electric</p> <p>Check seat belts</p>	Gr. 65			Gr. 00	<p>+</p> <p>+</p> <p>+</p> <p>+</p> <p>+</p> <p>+</p>	<p>Fill with antifreeze additive if necessary</p>



# 00-4

BMW MAINTENANCE SYSTEM	General Information					Important Remarks!
	Repair Manual	Technical Data	Nominal Values	Service Information	Owner's Manual	
00 00 009 Pre-Delivery Inspection						
<p>Check data plate, chassis and engine numbers</p> <p>Compare ordered car equipment against delivered car equipment</p> <p>Install wheel covers, if applicable ornamental rings and tailpipe extension</p> <p>Place car tools in toolbox, secure jack and wheel bolt wrench</p> <p>Mount label for annual brake fluid change</p> <p>Place owner's manual, list of BMW service stations, spare keys and key case in glove box.</p> <p>Battery and accessory warranty cards</p> <p>Radio operating manual (if equipped)</p> <p>Factory Invoice (Monroney Label)</p> <p>Tape unit cleaning cassette kit</p>						

# 00 – 5

00 00 009 Pre-Delivery Inspection	General Information					Important Instructions!
	Repair Manuel	Specifications	Nominal Values	Service Information	Owner's Manual	
<p>Test drive: check acceleration, coasting, brake system (before and during road test)</p> <p>Check idle RPM</p> <p>Check function of Motronic</p> <p>Check car for rattling and squeaking noise</p> <p>Check handling and wheel balance</p> <p>Check function of engine, clutch, transmission, rear axle, steering (wheel in straight ahead position), cars with rear disc brakes: breaking in parking brake</p> <p>Heater, fresh air ventilation/air condition</p> <p>Check function of all instruments</p> <p>Cruise control</p>			+			<p>Caution: On systems with Politec brake linings, increased braking effect</p>
	Gr. 34					

## BMW MAINTENANCE SYSTEM

## General Information

00 00 009 Pre-Delivery Inspection

Repair  
ManualTechnical  
DataNominal  
ValuesService  
InformationOwner's  
Manual

Important Remarks!

## After Test Drive:

Leak test on: engine, transmission, steering, final drive, dust covers on output shafts, fuel system, clutch and brake hydraulic systems and Cooling system

Check interior of car and clean

Car cleaned and polished  
No damage on underside  
Car without scratches or damage

Remove seat and protective covers

*Important!*

The service indicator (SI) must be reset after completion of the pre-delivery inspection as follows.

Switch off all electrical equipment.

Turn on ignition.

Do not run engine.

Plug SI-R \* in diagnosis socket.

Push in and hold recessed, red INSPECTION button - green lamp (function control) comes on.

Red lamp also comes on after approx 3 sec. and goes out after approx. 12 sec.


Release inspection button - green lamp goes out.

## Checking Service Indicator (SI):

All five green diode lights must be on.

Yellow and possibly red diodes as well as INSPECTION sign should go out.

\* SI-R = Service indicator resetter, Order No. 62 1 100.



62 1 100

20 00 005

# 00-7

## BMW MAINTENANCE SYSTEM

## General Information

00 00 210 1200 Mile Inspection

Replace engine oil and oil filter at operating temperature

Gr. 11

Gr. 00

+

Use approved oil only see below

Check and adjust valve clearance

Gr. 11

Gr. 11

Check coolant hoses and connections as well as heater hoses for leaks; check coolant level and concentration, correcting if necessary

Gr. 00

+

Longterm anti-freeze and corrosion inhibitor

Replace oil in manual transmission at operating temperature (not applicable to automatic transmission)

Gr. 23

Gr. 00/23

+

Use approved oil only

Check ATF level in automatic transmission correcting if nec.

Gr. 24

Gr. 00/24

+

Use approved ATF only

Check exhaust system and catalytic converter for correct installation, routing, damage or leaks

Visual inspection


Tighten nuts and bolts of steering, brake calipers, output shafts and wheel bolts

Gr. 32/33/34  
36

Tightening torque check locks and cotter pins

Check power steering for leaks and oil level, correcting if necessary

Gr. 32



Caution!  
524 td:  
When starting the engine first time after an oil change, push lever on injectionpump to "stop" (arrow) until oil pressure control light goes off.


# 00-8

BMW MAINTENANCE SYSTEM	General Information					Important Remarks!
	Repair Manual	Technical Data	Nominal Values	Service Information	Owner's Manual	
00 00 210 1200 Mile Inspection						
Replace final drive oil at operating temperature		Gr. 33		Gr. 00		Use approved oil only
Check fluid level in tank for brake and clutch hydraulic systems				Gr. 00		Use approved brake fluid only
Check connections and lines of brake system for leaks and damage	Gr. 34					Visual inspection
Check tire inflation pressure, correcting if necessary (including spare wheel)				Gr. 36		
Fill supply tank for windshield washing system / check antifreeze protection				Gr. 00		



BMW MAINTENANCE SYSTEM	General Information					Important Remarks!
	Repair Manual	Technical Data	Nominal Values	Service Information	Owner's Manual	
00 00 210 1200 Mile Inspection						
Check function of following equipment:						
Lights: headlights, parking lights, backup lights, license plate lights, interior lights and delay system, glove box light, engine compartment light and trunk light						
Aiming of headlights, adjust if necessary	Gr. 63					
Indicators: turn signals, hazard lights, stop lights, headlight flasher and headlight dimmer switch					+	
Inspect check control panel operation: ABS and SRS lights						
524 td: check indicator lights of glow plug system					+	
Check instrument lights, indication lamps, windshield wipe/wash system and aiming of spray jets, heater and air conditioner blowers, rear window defogger					+	
Final inspection and test drive with check of fuel inspection system and operational safety of: brakes, steering, clutch or automatic transmission and mirrors, break in parking brake	Gr. 34					Caution: On systems with Politec brake linings, increased braking effect. See Rep. Manual Gr. 34 10 014 breaking in p. brake

# 00-10

BMW MAINTENANCE SYSTEM	General Information					Important Remarks!
	Repair Manual	Technical Data	Nominal Values	Service Information	Owner's Manual	
00 00 220 BMW Inspection I						
Replace engine oil and oil filter at operating temperature	Gr. 11			Gr. 00	+	Use approved oil only see below
Check and adjust valve clearance	Gr. 11	Gr. 11				
Lubricate joints and bearings of accelerator linkage, rotary shaft and throttle linkage with oil; lubricate bearings of throttle lever and gate with grease						
Check fuel tank, tank cap, lines and connections for leaks						Visual inspection
Check cooling system and all connections as well as heater hoses for leaks. Check coolant level and concentration, correcting if necessary.				Gr. 00	+	
<i>Important!</i> Coolant must be drained completely and replaced every 2 years.						
Check condition, routing, suspension and leaks on exhaust assembly	Gr. 18					
Replace automatic transmission fluid at operating temperature (only in Inspection I)	Gr. 24	Gr. 24		Gr. 00		Use approved ATF only
Replace oil filter screen in automatic transmission (only in Inspection I)	Gr. 24	Gr. 24				
						 <p>Caution! 524 td: When starting the engine first time after an oil change, push lever on injectionpump to "stop" (arrow) until oil pressure control light goes off.</p>

BMW MAINTENANCE SYSTEM	General Information					Important Remarks!
	Repair Manual	Technical Data	Nominal Values	Service Information	Owner's Manual	
00 00 220 BMW Inspection I						
Check manual transmission oil level, correcting if necessary		Gr. 23		Gr. 00		Use approved oil only
Check power steering for leaks and oil level, correcting if necessary	Gr. 32			Gr. 00		
Check condition of tie rods, front axle joints, drop arms and coupling	Gr. 31/34/36					Tightening torque/ visual inspection of cotter pins
Check mechanical steering play, in straight ahead position	Gr. 32					
Check final drive oil level, correcting if necessary				Gr. 00		Use approved oil only
Remove and install front and rear disc brake pads, check total thickness, if necessary replace, check surface condition of brake discs.	Gr. 34	Gr. 34				
Lubricate aluminum wheel rim centers	Gr. 36			Gr. 36		
Check fluid level in tank for hydraulic brake and clutch systems, correcting if necessary Important: replace brake fluid annually at latest.	Gr. 34			Gr. 00		Use approved brake fluids only
Check brake calipers and dust boots for leaks	Gr. 34			Gr. 00		visual inspection

BMW MAINTENANCE SYSTEM	General Information					Important Remarks!
	Repair Manual	Technical Data	Nominal Values	Service Information	Owner's Manual	
00 00 220 BMW Inspection I						
Check brake lines and connections for leaks damage or distortion. Check movement of parking brake cables. Adjust parking brake.	Gr. 34					
Check tire inflation pressure, correcting if necessary (including spare wheel). Check trunk for gasoline odor.				Gr. 36	+	
Check condition of tires.						
Tighten bolts and nuts of door locks and strikers. Lubricate door hinges and hood hinges with oil; lubricate door locks with grease and check function.						
Check battery acid level, adding distilled water if necessary				Gr. 00		
Check function of air conditioner and Freon charge	Gr. 64					
Tighten mounting bolts of A/C compressor		Gr. 64				Tightening torque
524 td: check indicator lights of glow plug system					+	
524 td: with the 4th Inspection I replace toothed belt	Gr. 11					
524 td: with the 4th Inspection I replace glow plugs (necessary for California version only)	Gr. 12					

BMW MAINTENANCE SYSTEM	General Information				
	Repair Manual	Technical Data	Nominal Values	Service Information	Owner's Manual
00 00 220 BMW Inspection I					
Check function of following equipment: Lights: headlights, parking lights, backup lights, license plate lights, interior light and delay system, glove box light, engine compartment light and trunk light. Indicators: turn signals, hazard lights, stop lights, horn, headlight flasher and dimmer switch. Check aiming of headlights, correcting if necessary. Test check control panel operation ABS and SRS lights.	Gr. 63				
Check ground conn. of SRS-front sensor screws to body	Gr.32				
Fill supply tank for windshield washing system, check antifreeze protection				Gr. 00	
Check function of windshield wipe/wash system and aiming of spray jets					
Check instruments lights, control lights, heater and air conditioner blower and rear window defogger					
Check condition and function of seat belts					
Final inspection and test drive with check of operational safety: brakes, steering, clutch or automatic transmission and mirrors, break in parking brake	Gr. 34				Caution: On systems with Polytex brake linings increased braking effect See Rep. Manual Gr. 34 10 014 breaking in p. brake
<b>Important!</b> The Service Indicator (SI) must be reset after completion of inspection I as follows. Switch off all electrical equipment. Turn on ignition. Do not run engine. Plug SI-R* in diagnoses socket. Push in and hold recessed, red INSPECTION button - green lamp (function control) comes on. Red lamp also comes on after approx. 3 sec. and goes out after approx. 12 seconds. Release inspection button - green lamp goes out.	Gr.62				524 td: The time factor is uncoupled from the wear factor. The time factor activates only the "INSPECTION" sign. The wear factor also switches off the green LED'S.
Checking Service Indicator (SI): All five green diode lights must be on. Yellow and possibly red diodes as well as INSPECTION sign should go out.					
<b>Note:</b> 524 td: If the time factor has activated the INSPECTION sign, the green LED's do not change after the first reset, only the sign INSPECTION goes off. If time factor and wear factor have simultaneously activated the INSPECTION sign, the reset has to be carried out twice in order.					
* SI-R = Service Indicator resetter, Order No. 62 1 100					



# 00 – 14

BMW MAINTENANCE SYSTEM	General Information					Important Remarks!
	Repair Manual	Technical Data	Nominal Values	Service Information	Owner's Manual	
00 00 230 BMW Inspection II = Inspection I + Additional Jobs						
Check all drive belts, adjust tension if necessary	Gr. 12/32/64					
Replace spark plugs		Gr. 12			+	
Air cleaner: replace air filter cartridge Replace filter cartridge more frequently when car is operated in dusty regions.	Gr. 13					
Replace fuel filter Shorten intervals when contaminated fuel was used	Gr. 16				+	
Check clutch drive plate for wear	Gr. 21					
Replace manual transmission oil at operating temperature		Gr. 23		Gr. 00		Use approved oil only
Check automatic transmission oil level correcting if necessary (only in inspection II)		Gr. 24		Gr. 00		Use approved oil only
Check front wheel bearing play	Gr. 31					
524 td: check injection timing	Gr. 13					
524 td: check idle rpm						
524 td: check and adjust toothed belt, change toothed belt every second inspection II, or every 4 years.	Gr. 11					
524 td: with the 2nd Inspection II replace glow plugs (on 49 states model only, but recommended for California version)	Gr. 12					

## BMW MAINTENANCE SYSTEM

## General Information

00 00 230 BMW Inspection II = Inspection I + Additional Jobs

Replace final drive oil at operating temperature

Check condition of dust covers on output shafts

Car with rear brake discs: Check parking brake liner thickness

*Important!*

The Service Indicator (SI) must be reset after completion of inspection II as follows.

Switch off all electrical equipment.

Turn on ignition.

Do not run engine.

Plug SI-R \* in diagnosis socket.

Push in and hold recessed, red INSPECTION button - green lamp (function control) comes on.

Red lamp also comes on after approx. 3 sec. and goes out after approx. 12 sec.

Release inspection button - green lamp goes out.

## Checking Service Indicator (SI):

All five green diode lights must be on.

Yellow and possibly red diodes as well as INSPECTION sign should go out.

*Note:*

524 td: If the time factor has activated the INSPECTION sign, the green LED's do not change after the first reset, only the sign INSPECTION goes off. If time factor and wear factor have simultaneously activated the INSPECTION sign, the reset has to be carried out twice in order.

\* SI-R = Service Indicator resetter, Order No. 62 1 100

Repair  
ManualTechnical  
DataNominal  
ValuesService  
InformationOwner's  
Manual

Important Remarks!

Gr. 33

Gr. 00

Use approved oil  
only

Gr. 34

Gr. 34

Gr.62



62 1 100

20 00 005

## 524 td:

The time factor is uncoupled from the wear factor. The time factor activates only the "INSPECTION" sign. The wear factor also switches off the green LED'S.

BMW MAINTENANCE SYSTEM	General Information					Important Remarks!
	Repair Manual	Technical Data	Nominal Values	Service Information	Owner's Manual	
00 00 240 BMW Annual Check (after every 11 to 13 months)						
Important: renew brake fluid annually	Gr. 34			Gr. 00		Use approved brake fluids only
Check operation of master cylinder and servo, and inspect for leaks. Check and adjust headlights and auxiliary driving lights. Check Steering: Lock angle limits, threaded connections, power assistance.						
Important: coolant must be drained completely and renewed every 2 years, check antifreeze protection (against extra charge)				Gr. 00		Use approved anti-freeze additives only
Inspect body according to the terms of the BMW 6 year limited warranty-rust perforation					+	Register check or repair on Owners Handbock
Reminder only! Replace oxygen sensor every 50 000 Miles or 80 000 km	Gr. 11					
528 e: replace oxygen sensor every 30 000 Miles or 48 000 km, reset oxygen sensor indicator light.	Gr. 11					528 e: Reset oxygen sensor indicator light. Press recessed button on control box, mounted behind left dash panel cover, near pedal cluster.

## BMW MAINTENANCE SYSTEM

## General Information

## 00 00 249 BMW Engine Oil Service

Repair  
ManualTechnical  
DataNominal  
ValuesService  
InformationOwner's  
Manual

Important Remarks!

Engine oil and oil filter — replace at operating temperature

*Important!*

The Service Indicator (SI) must be reset after completion of the oil service as follows.

Switch off all electrical equipment.

Turn on ignition.

Do not run engine

Plug SI-R \* in diagnosis socket.

Push in and hold yellow OIL SERVICE \*\* button - green lamp (function control) comes on.

Yellow lamp also comes on after approx. 10 sec. and goes out after approx. 3 sec.

Release oil service button - green lamp goes out.

Checking Service Indicator (SI) after 10 Seconds:

At least one green diode light (however more than before) should come on.

Yellow (possibly red) diode and OIL SERVICE sign must go out.

\* SI-R = Service indicator resetter, Order No. 62 1 100.


*\*\* Caution!*

Resetting with the wrong button cannot be corrected.

Service Intervals would be mixed up - also refer to BMW Technik information of Group 62.

Gr. 00

Only use approved oil

*Caution!*

524 td:

When starting the engine first time after an oil change, push lever on injectionpump to "stop" (arrow) until oil pressure control light goes off.



20 00 006

BMW MAINTENANCE SYSTEM	General Information					Important Remarks!
	Repair Manual	Technical Data	Nominal Values	Service Information	Owner's Manual	
00 00 259 Additional Recommended Service (To be invoiced seperately)						
Steering Test: Steering gear, linkage, coupling, connetions, leaks, oil volume and condition for power steering	Gr. 32			Gr. 00		Use only approved oil
Brake Test: Brake pads (remove and install wheels), brake discs, lines, hoses, connetions, brake fluid level parking brake	Gr. 34					
<i>Important!</i> Replace brake fluid at least annually.				Gr. 00		Use only approved brake fluids
Tire and Wheel Rim Test: Condition, tire inflation pressure and specified size (including spare wheel)		Gr. 36		Gr. 36		
Light Test: Headlights, additional headlights (also aiming), parking lights, tail Lights,backup lights, license plate lights, instrument and sign lights, indicator and warning lamps interior lights.also delay system,glove box, engine and luggage compartment lights Signal Test: Horns, headlight flasher, turn signals, hazard lights, stop lights Check control panel operation ABS-, SRS light.	Gr. 63					
Wipers and Washer/Cleaners Test: Wiper blades, waler (windshield and, if applicable, headlights), tank (fluid level/antifreeze), spray jet aiming (windshield and, if applicable, headlights). If equipped, intensive cleanser level.				Gr. 00	+	
Seat Belt Test: Condition and function	Gr. 72					
Clean cassette tape head capstan and pinch rollers every 50 - 100 hours of operation or earlier if quality of sound is impaired						
Final inspection and test drive with check of operational safety: brakes, steering, clutch or automatic transmission and mirrors 524 td: Drain water from seperator in fuel filter						Caution: On systems with Polite tex brake linings, increased braking effect
Remarks: Repairs and adjustments against extra charge.						



## 11 Engine

BMW 528e .....

BMW 524td .....


BMW 533i, BMW 535i .....

# 11 Engine

## BMW 528e

11 00 006	Diagnosis with BMW service tester .....	see nominal value microfiche
039	Compression of all cylinders – check .....	11- 101
050	Engine – remove and install .....	11- 102
091	Exchange engine – install .....	11- 104
11 11 160	Bearing for oil pump drive shaft – replace .....	11- 105
11 12 000	Cylinder head cover – remove and install .....	11- 105
100	Cylinder head – remove and install .....	11- 106
101	Cylinder head gasket – replace .....	11- 109
240	Radial oil seal in end cover – replace .....	11- 109
561	Valve guide – replace (valve removed) .....	11- 110
595	Valve guide – check for wear .....	11- 110
600	Valve guide – ream out .....	11- 110
607	Valve seats and valves – machine (cylinder head disassembled) .....	11- 111
719	Cylinder head sealing surface – grind (cylinder head disassembled) .....	11- 111
729	Cylinder head – check for cracks in water test (cylinder head disassembled) .....	11- 111
11 13 000	Oil pan – remove and install .....	11- 112
11 14 175	Front end cover – remove and install .....	11- 112
180	Radial oil seals in front end cover – replace .....	11- 113
605	Radial oil seal in clutch end cover – replace .....	11- 113
11 21 000	Crankshaft – remove and install .....	11- 114
501	Crankshaft – replace (crankshaft removed) .....	11- 115
531	Crankshaft main bearing shells – replace (engine disassembled) .....	11- 115
571	Pilot bearing in crankshaft – replace .....	11- 116
11 22 000	Flywheel – remove and install .....	11- 117
051	Drive plate for torque converter – replace .....	11- 117
541	Starter gear ring – replace .....	11- 117
11 23 010	Vibration damper – replace .....	11- 118
031	Vibration damper hub – replace .....	11- 118
11 24 521	Connecting rods – replace (pistons removed) .....	11- 119
571	Connecting rod bearing shells – replace (engine disassembled) .....	11- 119
11 25 000	Piston – remove and install .....	11- 120
651	Piston rings of one piston – replace (piston removed) .....	11- 121
11 31 000	Camshaft – remove and install .....	11- 122
100	Toothed belt – tighten .....	11- 122
110	Toothed belt – remove and install .....	11- 123
11 33 020	Rocker arm shafts – remove and install .....	11- 124
031	Rocker arms – replace .....	11- 125
11 34 004	Valve clearance – adjust .....	11- 125
509	Valves – check for leaks (camshaft removed) .....	11- 125
550	Valves – remove and install .....	11- 126
11 35 020	Intermediate shaft – remove and install .....	11- 126
	Engine oil circuit .....	11- 127
11 40 000	Engine oil pressure – check .....	11- 128
11 41 000	Oil pump – remove and install .....	11- 129
110	Pressure relief valve – remove and install .....	11- 130
11 42 020	Full flow oil filter – replace .....	11- 130
11 43 101	Oil dipstick guide tube – replace .....	11- 130
11 51 000	Water pump – remove and install .....	11- 130
502	Water pump – overhaul (water pump removed) .....	11- 131
11 52 000	Fan – remove and install .....	11- 132
020	Fan coupling – replace .....	11- 132
11 53 000	Coolant thermostat – remove and install .....	11- 132
080	Temperature transmitter – replace .....	11- 132
11 76 010	Catalytic converter – remove and install .....	11- 133
11 78 010	Oxygen sensor – check .....	11- 133
510	Oxygen sensor – replace .....	11- 134

11-100



28.11 525

## 11-101


### 11 00 039 CHECKING COMPRESSION OF ALL CYLINDERS

Pull off main relay (1).



28 11 511

Unscrew spark plugs.  
Test compression\*.  
*Installation:*  
Tightening torque\*\*.




20 11 205

\* See Specifications  
\*\* See Specifications of Gr. 12

# 11-102


## 11 00 050 REMOVING AND INSTALLING ENGINE

Remove transmission — see Group 23 or 24.  
Unscrew power steering pump.  
Pressure hoses remain connected.  
*Installation:*  
Tighten drive belt, see 32 41 060.




20 11 222

Unscrew plug and drain coolant.  
Remove radiator 17 11 000.




20 11 103

Unscrew compressor.  
Refrigerant hoses remain connected.  
*Installation:*  
Tighten drive belt and check tightness with Special Tool 11 5 020.




28 11 513

Unscrew ground wire for hood.  
Disconnect or remove gas pressure props and prop engine hood with Special Tool 51 2 110.  
*Caution!*  
Use locks (1).




20 11 104



28 11 528


Disconnect negative and positive leads on battery.  
Unscrew wire (2).



28 11 529


Disconnect accelerator cable (1) and cruise control cable (3).  
Pull off vacuum hose (4) and hoses (5).  
Loosen clamp (6).

*Installation:*  
Adjust accelerator cable — see 35 41 421.  
Adjust cruise control cable — see Group 65.



28 11 530


Pull off plug (7).  
Pull out hose (8) and loosen strap (9).  
Unscrew nuts (10) and remove air cleaner with air flow sensor.




28 11 531

Take off cover (11) and lift off cap (12).  
Pull off plug (13).  
Lift out relays (14 ... 16).  
Loosen straps (17).


## 11-103




Unscrew fuel line (1) and holder (2).




Disconnect heater water hoses (3).




Unscrew fuel lines (4 and 5).  
Unscrew ground strap (6).  
Pull off hoses (7 and 8).




Pull off plugs (9 and 10) on control units in glove box.  
Disconnect lead (11).



Unscrew wire straps on firewall and pull out wire harness into engine compartment.  
Pull off wire (4).  
Disconnect wire (5).  
Pull off plug (6).  
Disconnect hoses (7).  
Disconnect wire harnesses.  
*Installation:*  
Use new squeeze-hose clamp.




Unscrew ground strap (8) and both engine mounts.  
*Installation:*  
Tightening torque\*.



Apply Special Tool 11 0 020 and lift out engine.  
*Installation:*  
Adjust engine idle speed/CO 13 00 054.

\* See Specifications



## 11 00 091 INSTALLING EXCHANGE ENGINE

Remove engine 11 00 050.  
Exchange Engine Identification On The Crankcase:

- 1 = Type designation/displacement\*
- 2 = Year of manufacture (1981)
- 3 = "A" for exchange or "N" for new
- 4 = Month of manufacture

Stamp engine number (5).

Drive in supplied oil dipstick guide tube (see 11 43 101) and transfer parts from the old engine to the exchange engine.  
Fill exchange engine with oil\*\*.

*Important!*

Remove pilot bearing in crankshaft, see 11 21 571, if the car has an automatic transmission.

Install engine.

Adjust engine idle speed/CO 13 00 054.

\* See BMW Technik/Serv. Inform. of Gr. 11


\*\* See Service Information of Group 00




## 11-105

### 11 11 160 REPLACING BEARING FOR OIL PUMP DRIVE SHAFT

Remove oil pump 11 41 000.  
Unscrew bolt (1) and take off cover (2).




Remove gear (3).  
*Installation:*  
Open end of gear shaft faces down.  
Check seal (4), replacing if necessary.



Drive out needle bearing from bottom upwards with Special Tool 11 1 310.




*Installation:*  
Lubricate needle bearing with grease.  
Drive in needle bearing against stop with Special Tool 11 1 300.



### 11 12 000 REMOVING AND INSTALLING CYLINDER HEAD COVER


Pull off plugs (11 and 12) and unscrew holder (13).  
Unscrew support (14).



Disconnect ignition lead tube (9) and vent hose (10).

Take off cylinder head cover.

*Installation:*  
Check gasket, replacing if necessary.  
Tighten nuts in order of 1 through 8.  
Mount ground strap (15).



\* See Specifications




## 11-106

### 11 12 100 REMOVING AND INSTALLING CYLINDER HEAD

Unscrew exhaust pipes on exhaust manifolds and pipe clamp on transmission.

*Installation:*

Check gaskets, replacing if necessary.  
Coat studs with copper paste "CRC".  
Replace self-locking nuts.  
Tightening torque\*.




28 11 540

Unscrew plug and drain coolant.  
Disconnect battery ground lead.

*Installation:*

Fill cooling system with coolant\*\*\* and bleed 17 00 039.  
Replace engine oil\*\*\*.



20 11 103


Disconnect throttle cable (1) and cruise control cable (2).

*Installation:*

Adjust throttle cable — see 35 41 421.  
Adjust cruise control cable — see Group 65.  
Disconnect accelerator cable (3).


*Installation:*

Adjust accelerator cable s. Gr. 24.



28 11 514

Pull off vacuum hose (4) and hoses (5).  
Pull off plugs (7 and 11).  
Pull out hose (8) and loosen strap (9).  
Unscrew nuts (10) and remove air cleaner with air flow sensor.




28 11 541

\* See Specifications


\*\*\* Source: HWB

\*\*\* See Service Information of Gr. 00




28 11 542

Disconnect diagnosis plug (1).  
Disconnect radiator hoses (2 ... 5).  
Pull off fuel line (6).  
Unscrew holder (7).



28 11 543

Unscrew holder (8).  
Disconnect hose (9).




20 11 126

Press vent tube down and hold down with Special Tool 11 1 290.


*Installation:*

Check seal, replacing if necessary.  
Check vent tube for correct fit after removing Special Tool 11 1 290.




28 11 538

Pull off hoses (10).  
Unscrew fuel lines (11 and 12).  
Unscrew holder (13).  
Pull off plugs on fuel injectors 4, 5 and 6.  
Pull off plugs (14 and 15).  
*Installation:*  
Use new squeeze hose clamps.




Pull off plugs on fuel injectors 1, 2 and 3.  
Pull off plugs (5 ... 8).  
Pull off wire (4) and disconnect ignition coil.  
Pull off wire (9) on solenoid and wires on oil pressure switch.  
Disconnect wire harness and pull out to the left side.




Pull off spark plug end caps and unscrew ignition lead tube (10).  
Disconnect vent hose (11).  
Unscrew holder (12).  
Unscrew nuts (1 ... 8) and take off cylinder head cover.

## Installation:

Check gasket, replacing if necessary.  
Tighten nuts in order of 1 through 8.




Turn crankshaft to set cylinder no. 1 to TDC; valves of cylinder no. 6 overlap.  
Remove distributor cap.




Remove distributor rotor.  
Unscrew adapter (12).  
Remove cover (13).  
Unscrew bolts (14).  
Unscrew nut (15).  
Remove guard (16).

## Installation:


Screw on holder (17).  
Check rubber ring (18).  
Insert rubber cover (19).



Loosen bolts (7 and 8).  
Press in tensioning roller.  
Tighten bolt (6).




Take off drive belt on camshaft sprocket.  
*Caution!*  
Never crank engine after removing drive belt.  
*Installation:*  
Check/tighten drive belt 11 31 100.



*Installation:*  
Before installing the cylinder head, turn the camshaft that mark on camshaft sprocket is facing mark on cylinder head.  
Cylinder no. 1 is in TDC.  
Also install the drive belt in this position.

## 11-108



Unscrew bolts in order of 14 through 1 and remove cylinder head.

*Installation:*

Keep oil out of cavities, since otherwise bolts tightened to specified torque would not exert sufficient pressure on the cylinder head and, in addition, the crankcase could be cracked.

Clean cylinder head bolts.

Apply a light coat of oil on threads and bearing surfaces of bolt heads.

Always replace the cylinder head gasket.

Tighten bolts in order of 1 through 14 in 3 steps. Tightening torque\*.

Adjust valve clearance 11 34 004.

Adjust ignition timing 12 11 004.

Adjust engine idle speed/CO 13 00 054.

In the 3rd step (cylinder head cover removed again after running engine warm) tighten cylinder head bolts to torque angle with Special Tool 11 2 110 regardless of the engine temperature.


*Note:*

Cylinder head need not be tightened again after driving car 1,000 km (600 miles).

\* See Specifications

## 11-109

### 11 12 101 REPLACING CYLINDER HEAD GASKET



28 11 628

Remove cylinder head 11 12 100.  
Clean sealing surfaces on cylinder head and crankcase — using sealant remover\*\* and a hard wood scraper.  
Check levelness with a standard steel ruler, grinding cylinder head sealing surface if necessary 11 12 719.


#### Installation:

Only use original cylinder head gaskets, of which the openings for coolant are matched precisely.

Identification: 2.7 stamped.

#### Important!


A 0.3 mm (0.012") thicker gasket must be installed after grinding the cylinder head to prevent reduction in combustion chamber size.



28 11 630


### 11 12 240 REPLACING RADIAL OIL SEAL IN END COVER

Remove drive belt 11 31 110.  
Take off sprocket.



28 11 553

Unscrew cover.



28 11 554

Replace radial oil seal (2) and round cord seal (3).

#### Installation:

Use Special Tool 11 2 212 to install the cover.

# 11-110




## 11 12 561 REPLACING VALVE GUIDE — Valve Removed —

Check wear\* of valve guide with Special Tool 00 4 300.




## 11 12 595 CHECKING VALVE GUIDE FOR WEAR — Valve Removed —


To measure, insert a new valve that its stem end is flush with the valve guide. Apply dial gage and measure the tilt clearance. Max. permissible tilt clearance\*.



Drive out valve guide (cold) into the combustion chamber with Special Tool 11 1 330.




Inspect bore in cylinder head with Special Tool 00 4 530. If permissible diameter A is exceeded, ream out the bore with a standard reamer and install an oversize\* valve guide.



## 11 12 600 REAMING OUT VALVE GUIDE — Valve Removed —

If there is excessive play between the valve guide and valve stem, see 11 12 595, ream out the valve guide and install a valve with a larger stem diameter "S"\*. The valve seat must then also be machined in conjunction with this, see 11 12 607. Press guide pad (1) on to valve seat and ream out valve guide from the combustion chamber end — turning down the reamer once.




Heat\* cylinder head. Drive valve guide into the combustion chamber from the camshaft side with Special Tool 11 1 320. Stepped end of valve guide faces the camshaft. *Important!* The bore in the special tool determines the installed depth B =  $14.5 \pm 0.5$  mm ( $0.571 \pm 0.020$ "). Ream out valve guide to 7 mm H 7 diameter with Special Tool 00 4 200. Machine valve seats, see 11 12 607.

\* See Specifications

\* See Specifications

## 11-111


### 11 12 607 MACHINING VALVE SEATS AND VALVES — Valves Removed —




The valve has to be replaced, if the minimum edge thickness A\* cannot be held.



Produce the valve seat diameter M\* and valve seat width B\* by machining correction angles\* after machining the valve seat angle\*. Grind in valves with grinding paste and check for leaks, see 11 34 509.



\* See Specifications



### 11 12 719 GRINDING CYLINDER HEAD SEALING SURFACE — Cylinder Head Disassembled —


The original total thickness (A) of the cylinder head is  $125.1 \pm 0.1$  mm ( $4.925 \pm 0.004$ "') and not more than 0.3 mm (0.012"') may be ground off.

Use a 0.3 mm (0.012"') thicker gasket on a reground cylinder head (also refer to 11 12

28 11 511

### 11 12 729 CHECKING CYLINDER HEAD FOR CRACKS IN WATER TEST

Mount Special Tools 11 1 026 on the cylinder head, using cylinder head bolts. Close off water circuit on the cylinder head with Special Tools 11 1 023, 11 1 024 and 11 1 025.




28 11 519

Apply compressed air on cylinder head. Pressure: 4.5 bar (64 psi). Place cylinder head in a water bath and check for cracks.

Note:

If necessary, relax water bath with a detergent.



28 11 520


\* See Specifications




## 11-112

### 11 13 000 REMOVING AND INSTALLING OIL PAN

Lift out and disconnect plug.  
Drain oil.  
*Installation:*  
Add engine oil\*\*\*.




Unscrew cover/reinforcement plate.





Unscrew oil pan.  
Unscrew oil pump and remove oil pan.  
*Installation:*  
Insert oil pump drive shaft, see 11 41 000.  
Replace gasket.



*Installation:*  
Clean sealing surfaces.  
Coat joint surfaces on timing case covers and end cover with a brush-on universal sealing compound\*\*.



\*\* Source: HWB  
\*\*\* See Service Information of Gr. 00





### 11 14 175 REMOVING AND INSTALLING FRONT END COVER

Remove radiator, see Group 17.  
Remove toothed drive belt 11 31 110.  
Single piece Hub/Drive Belt Sprocket:  
Hold drive belt sprocket with Special Tool 11 2 150.  
Unscrew bolt (3).  
Take off collar washer (4).  
*Installation:*  
Tightening torque\*.

Screw in bolt (3) about three turns.  
Pull hub/sprocket off of the crankshaft with Special Tools 00 7 501 and 11 2 132.  
*Important!*  
Woodruff key.


Two-piece Hub/Drive Belt Sprocket:  
Screw in bolt (3).  
Pull sprocket off of the crankshaft with Special Tools 00 7 501 and 11 2 131.  
*Important!*  
Woodruff key.  
*Installation:*  
Mount sprocket that lettering faces forward.



Hold sprocket of the intermediate shaft with Special Tool 11 2 190.  
Unscrew bolt (6).  
Take off washer and sprocket.  
*Installation:*  
Guide centering pin (7) into bore.

\* See Specifications


## 11-113



Unscrew bolts (8 ... 10).  
Only loosen the other oil pan bolts.  
Loosen oil pan gasket on end cover carefully with a knife.  
Take off cover.  
*Installation:*  
If oil pan gasket was damaged, remove oil pan and replace gasket — see 11 13 000.  
Coat bores of oil pan gasket with a brush-on universal sealing compound/Three Bond Silicone 1207\*\*.  
Replace gasket.





Check radial oil seals, replacing if necessary.  
*Important!*  
Always use Special Tools 11 2 211 (crankshaft) and 11 2 212 (intermediate shaft) for installation of the end cover.



### 11 14 605 REPLACING RADIAL OIL SEAL IN CLUTCH END COVER — Transmission Removed —

Remove flywheel 11 22 000.  
Unscrew oil pan/end cover bolts.  
Only loosen the other oil pan bolts.  
Loosen oil pan gasket on end cover carefully with a knife.  
If oil pan gasket was damaged, remove oil pan and replace gasket — see 11 13 000.  
Take off end cover.  
Replace gasket (1).  
*Important!*  
Check cover (2) of main oil bore for leaks, replacing with a new plug (3) if necessary.  
Install plug with Loctite No. 270\*\*.




Press in the radial oil seal with Special Tools 11 1 260 and 00 5 500.  
Press in the new radial oil seal approx. 1 to 2 mm (0.039 to 0.079") deeper, in contradiction to the standard seal which had been installed flush.  
Lubricate sealing lip with oil.

30 11 027

### 11 14 180 REPLACING RADIAL OIL SEAL IN END COVER

Remove end cover 11 14 175.  
Press radial oil seals out of the cover.  
Press in radial oil seals with Special Tools 24 1 050 and 24 1 040.  
Press in the new radial oil seals approx. 1 to 2 mm (0.039 to 0.079") deeper, in contradiction to the standard seal which had been installed flush.  
Lubricate sealing lips with oil.



M 21 11 050



Coat end cover/oil pan joint with a brush-on universal sealing compound / Three Bond Silicone 1207\*\*.  
Use Special Tool 11 2 213 to avoid damage on the radial oil seal.


\*\* Source: HWB




## 11-114

### 11 21 000 REMOVING AND INSTALLING CRANKSHAFT


Remove the engine 11 00 050.  
Mount engine block in assembly stand  
00 1 490 with Special Tool 11 0 120.




Remove the clutch 21 21 000.  
Take off the cylinder head 11 12 100.  
Remove front end cover 11 14 175.  
Remove the oil pump 11 41 000.  
Check axial play\* before removing the crankshaft.  
Check / replace the thrust bearing, if the maximum permissible play is exceeded.




Remove flywheel 11 22 000.  
Take off the end cover.  
*Installation:*  
Replace the gasket.  
Use Special Tool 11 2 213 to avoid damage on the radial oil seal.  
Cut off gasket on the oil pan sealing surface.



Unscrew the conrod bearing caps.  
*Installation:*  
Replace conrod bearing shells and measure the conrod bearing play, see 11 24 571.  
The pairing code (0 to 99) must be the same on the connecting rods and caps.



\* See Specifications



Remove crankshaft bearing caps and lift out the crankshaft.

*Installation:*

Do not mix up the bearing caps.  
Bearing cap no. 1 is on the drive belt end.  
Bearing no. 6 is the thrust bearing.  
Install bearing shells and check the bearing play, see 11 21 531.

*Installation:*

Measure axial play with the crankshaft installed – loosen thrust bearing no. 6.  
Center the thrust bearing by applying knocks from a plastic hammer on the front and rear ends of the crankshaft.  
Tighten the thrust bearing to specifications.  
Measure the axial play\*.  
If the crankcase is replaced, clean the oil and water bores again thoroughly to remove casting sand.

\* See Specifications

# 11-115

## 11 21 501 REPLACING CRANKSHAFT — Crankshaft Removed —

### Identification of Crankshafts:


Standard ground size\* with one red or blue paint dot on side of counterweights.

### Crankshaft Identification:

Type	Throw (cast on cheek 6)	Code
M 20 B 27	H 81 mm (3.189")	W



28 11 303



520 11 159

Reground crankshafts are marked with stripes of paint.

Check machined sizes!

### Connecting Rod Bearing Journals (A)

1 paint stripe = size 1\*

2 paint stripes = size 2\*

### Main Bearing Journals (B)

1 paint stripe = size 1\*

2 paint stripes = size 2\*

### Important!

The crankshaft is surface treated and can only be reground in the plant.

Crankshafts are supplied with corresponding bearing shells.

Install bearing shells and check bearing play, see 11 21 531.

Install pilot bearing for cars with a manual transmission, see 11 21 571.

\* See Specifications

## 11 21 531 REPLACING CRANKSHAFT MAIN BEARING SHELLS — Engine Disassembled —


Bearing shells are marked with color codes. Double classification: red/blue.

Triple classification: yellow/green/white.

1 = Bearing shell 1 2 3 4 5 7

2 = Bearing shell 6 (thrust bearing)


Check machined size (main bearing diameter).



28 11 503



Bearing shells are installed in the crankcase according to color code of the crankcase. If color code has been washed off of the crankcase, both shells are installed according to the crankshaft color code. Install the crankshaft.



Bearing shells are installed in bearing caps according to color code of the crankshaft. Only Double Classification: If red and blue bearing shells are required on one bearing journal, bearing shells must be installed that all shells of same color on all bearing journals are in one plane (down or up). Place Plastigage (Type PG-1) on crankshaft wiped clean of oil and bolt down bearing caps to specified torque\*. Don't turn the crankshaft.

### Source for Plastigage:

Cartool


Alfred-Brehm-Str. 5

D-8070 Ingolstadt / West Germany

### Take off the bearing caps.

Read bearing play\* from width of flattened Plastigage with help of supplied scale.


Correct bearing play by installing new bearing shells, bearing shells of different machined size or with different color codes.




\* See Specifications

## 11 21 571 REPLACING PILOT BEARING IN CRANKSHAFT

Remove clutch disc 21 21 000.  
Pull out ball bearing with Special Tool  
11 2 010.




28 11 054




20 11 128

Installed Order:  
Ball bearing (1), cover (2), felt ring (3) and  
capsule (4).  
Install cover (2) with embossment facing out.




20 11 148

Pack bore in crankshaft with approx. 1 gram  
of lubricating grease.  
Drive in pilot bearing with Special Tools  
11 2 030 and 00 5 500.



# 11 22 000 REMOVING AND INSTALLING FLYWHEEL


Remove clutch 21 21 000.  
Hold flywheel with Special Tool 11 2 170.  
Unscrew bolts and take off flywheel.  
*Installation:*  
Clean tapped bores.  
Insert ring (1).  
Replace and install expansion bolts with Loctite No. 270\*\*.  
Tightening torque\*.




Check flywheel for axial runout\*.

Friction surface may be machined to minimum distance A\*.  
If machining the friction surface reduces distance "h" to zero, the flange surface (distance "h") has to be machined.

M 88 11 072



\* See Specifications  
\*\* Source: HWB




# 11 22 051 REPLACING DRIVE PLATE FOR TORQUE CONVERTER

Remove transmission — see Group 24.  
Hold flywheel with Special Tool 11 2 170.  
Unscrew bolts and take off flywheel.  
*Installation:*  
Clean tapped bores.  
Replace and install expansion bolts with Loctite No. 270\*\*.  
Tightening torque\*.




# 11 22 541 REPLACING STARTER GEAR RING

Drill a 6 mm (0.236") dia. hole about 8 mm (0.315") deep underneath a tooth gap to make removal of gear ring easier.



Break starter gear ring at a drilled point with a chisel.



*Installation:*  
Heat new starter gear ring to 200 ... 230° C (395 to 445° F), checking temperature with a thermo color pencil.  
Tooth bevel faces engine.  
Drive on starter gear ring to fit tight with a brass mandrel.

\* See Specifications  
\*\* Source: HWB

## 11-118

### 11 23 010 REPLACING VIBRATION DAMPER


Take off drive belts on the alternator, power steering pump and, if applicable, compressor for the air conditioner.

*Installation:*

Tighten drive belt and check tightness with Special Tool 11 5 020.



20 11 150




20 11 151

Take pulley and vibration damper off of the hub.

*Installation:*

Centering pin must be in the bore of the vibration damper.




20 11 152

### 11 23 031 REPLACING HUB FOR VIBRATION DAMPER

Two-piece Hub/Drive Belt Sprocket:  
Remove the radiator 17 11 000.  
Remove the vibration damper 11 23 010.  
Hold hub with Special Tool 11 2 150.  
Unscrew bolt (3).  
Take off collar washer (4).

*Installation:*

Tightening torque\*.




M21 11 018

Screw in bolt (3) about three turns.  
Pull the hub off of the crankshaft with Special Tools 00 7 501 and 11 2 132.  
Remove bolt (3).

\* See Specifications


## 11-119



### 11 24 521 REPLACING CONNECTING RODS — Pistons Removed —

#### *Important!*

Only use connecting rods of the same weight group in one engine.  
The weight group is stamped in the machined conrod bearing cap surface.  
Connecting rods may not be machined!  
Check length of connecting rods!



M86 11 065

The piston pin must slide through the conrod bushing under light pressure.



M 21 11 154

### 11 24 571 REPLACING CONNECTING ROD BEARING SHELLS — Engine Disassembled —


Install the conrod bearing shells in the rods and caps.

Double Classification:

Install red or blue conrod bearing shells according to the color code on the connecting rods.

#### *Important!*

Check machined size (conrod bearing diameter).



20 11 155


Turn to BDC, place Type PG-1 Plastigage on crankshaft wiped clean of oil and mount conrod bearing caps that grooves are on one side. The pairing code (0 to 99) must be the same on the connecting rod and cap.

Source for Plastigage:

Cartool

Alfred-Brehm-Str. 5

D-8070 Ingolstadt / West Germany



20 11 156

Tighten the bolts in two steps (use the old conrod bolts).

1st step 20 Nm (14.4 ft. lbs.)


2nd step 70° torque angle

#### *Important!*

Don't turn the connecting rods or crankshaft. Take off the bearing caps.

Read the bearing play\* from the width of the flattened Plastigage with help of the supplied scale.

Correct the bearing play by installing new bearing shells, bearing shells of different machined size or with a different color code. Replace the conrod bolts for final installation and tighten the conrod bearing caps in two steps (see above).



20 11 157

\* See Specifications



# 11-120

## 11 25 000 REMOVING AND INSTALLING PISTON

Remove engine.  
Take off cylinder head, oil pan and oil pump.  
Removing connecting rod bearing cap and press out the piston with connecting rod upwards.  
*Important!*  
Mark installed position of connecting rod to the crankshaft, if connecting rod bearing shells do not have to be replaced.

Remove circlip (1).  
Press out piston pin.  
*Installation:*  
Piston pin is matched with piston and must not be mixed up.  
*Important!*  
If the clearance between the piston pin and conrod bushing is excessive (which will sound like acceleration knock), check the conrod bushing diameter and replace the connecting rod or bushing if necessary.

Only install piston of same make and same weight class.  
Weight class is stamped with "+" or "-" in piston crown.  
*Important!*


Check machined size (piston diameter)\*.

Type	E*	Piston Bowl	Diameter
M 20 B 27	9	3.5 mm (0.138")	84 mm (3.307")

Check piston installed clearance\*.

Type	Make	Checkpoint A
Pistons with total height: 68.7 mm (2.705")		
M 20 B 27	Mahle	8 mm (0.315")
	KS	14 mm (0.551")
Pistons with total height: 77.7 mm (3.059")		
M 20 B 27	Mahle	23 mm (0.905")
	KS	23 mm (0.905")


\* See Specifications



Set internal calipers to zero on the micrometer with the measured piston diameter.

Measure cylinder bore at bottom, middle and top with internal calipers in forward and rotating directions.  
Check piston installed clearance\*.

Lubricate the piston and piston rings with oil.  
Offset piston ring end gaps by 120° to each other.  
Compress piston rings with Special Tool 11 2 260.



Install the piston that the arrow faces the drive belt.  
Install the connecting rod, see 11 24 521.

\* See Specifications

# 11-121


## 11 25 651 REPLACING PISTON RINGS OF ONE PISTON - PISTON REMOVED -

Measure side clearance\* of piston rings.



28 11 509

Remove piston rings and measure end clearance\*.



28 11 521

Installation:

Install piston rings that word "TOP" faces piston crown.

- 1 Plain compression ring
- 2 Taper face ring
- 3 Oil scraper ring



28 11 510


\* See Specifications



## 11-122

### 11 31 000 REMOVING AND INSTALLING CAMSHAFT

Remove rocker arm shafts 11 33 020.  
Unscrew end cover.



28 11 555



28 11 556



28.11 557

Check radial oil seal (1) and round cord seal (2), replacing if necessary.


*Installation:*

Use Special Tool 11 2 212 for installation of the end cover.


Check axial clearance\*.

Pull out the camshaft.


\* See Specifications



28 11 574



28 11 575



28 11 576

### 11 31 100 TIGHTENING DRIVE BELT

Do not tighten an used drive belt — replace a loose drive belt.

Tighten drive belt with a coolant temperature of 15 to 35°C (60 to 95°F).

Remove rubber guard (1).

Unscrew nut (2).

*Installation:*

Tightening torque\*.

Unscrew bolts (3).


Crank the engine on the crankshaft in running direction of the engine — this tightens the drive belt.

Tighten bolts (3).

Tightening torque\*.


\* See Specifications

## 11-123




### 11 31 110 REMOVING AND INSTALLING DRIVE BELT


Remove distributor cap (1).  
Remove distributor rotor (2).  
Old Version:  
Unscrew adapter (8).  
Remove cover (3).  
Unscrew bolts (4).  
Installation:  
Check seal (9), replacing if necessary.  
Tightening torque\*.



Take off rubber guard (5).  
Unscrew nut (6).  
Remove cover (7).  
Install adapter (8).




Turn the crankshaft to set cylinder no. 1 to TDC – arrow on camshaft sprocket faces the mark on the cylinder head.  
Remove the vibration damper 11 23 010.




Two-piece Hub/Drive Belt Sprocket:  
Remove hub for the vibration damper – see 11 23 031.  
Swing away the tensioning bar (7).  
Lift out TDC transmitter (8).  
Unscrew bolt (9) and take off the cover.


\* See Specifications




Loosen bolts (7 and 8).  
Press in the tensioning roller.  
Tighten bolt (8).  
Installation:  
Tighten drive belt 11 31 100.



Mark running direction of the drive belt and take off belt.  
Installation:  
Check drive belt, replacing if necessary.  
Install drive belt in opposite direction of the engine's turning direction, beginning on the crankshaft sprocket.



Installation:  
Turn engine again in turning direction and recheck timing after installation of the drive belt.  
Adjust ignition timing 12 11 004.




Drive Belt Layout:  
1 Camshaft sprocket  
2 Tensioning roller  
3 Crankshaft sprocket  
4 Intermediate shaft sprocket  
5 Drive belt


## 11-124

### 11 33 020 REMOVING AND INSTALLING ROCKER ARM SHAFTS — PLUGGED DISTRIBUTOR ROTOR —

Remove cylinder head 11 12 100.  
Set up Special Tool 11 1 060 on Special Tool  
00 1 490 and mount cylinder head with one  
cylinder head bolt.




28 11 558




28 11 259

Unscrew bolt (1) and take off sprocket.  
Press adapter (2) out of sprocket and install  
sprocket again.  
Adjust valve clearance of all valves to greatest  
value.




28 11 560

Remove front and rear plugs (3).  
Remove guide plate (4).  
*Installation:*  
Guide plate (4) must fit in grooves of rocker  
arm shafts.




28 11 561

Remove spring clamps.  
*Installation:*  
Straight surfaces of spring clamps must fit in  
grooves of rocker arm shafts.




28 11 562

Remove rocker arm shafts.  
1) Exhaust Side:  
Cylinder no. 6 must overlap.  
Push in rocker arms of cylinder no. 1 and turn  
camshaft on adapter to intake side until rocker  
arms (all) are relaxed.  
Pull out rocker arm shaft.



28 11 563

2) Intake Side:  
Turn camshaft on the adapter to exhaust side  
and move rocker arms until all rocker arms are  
relaxed.  
Pull out rocker arm shaft.  
Replace worn (scored) rocker arm shafts and  
rocker arms.




28 11 564

*Installation:*  
Install rocker arm shafts that large oil bores  
face down to valve guides and small oil bores  
as well as grooves for guide plate face in.

## 11-124a


### 11 33 020 REMOVING AND INSTALLING ROCKER ARM SHAFTS - BOLTED DISTRIBUTOR ROTOR -

Remove cylinder head 11 12 100.  
Set up Special Tool 11 1 060 on Special Tool  
00 1 490 and mount cylinder head with one  
cylinder head bolt.



28 11 558

Mount adapter (2) again.  
Adjust valve clearance of all valves to greatest  
value.




28 11 632

Remove front and rear plugs (3).  
Remove guide plate (4).

*Installation:*

Guide plate (4) must fit in grooves of rocker  
arm shafts.




28 11 633


Remove spring clamps.

*Installation:*

Straight surfaces of spring clamps must fit in  
grooves of rocker arm shafts.



28 11 561



28 11 634


Remove rocker arm shafts.

1) Exhaust Side:

Cylinder no. 6 must overlap.

Push in rocker arms of cylinder no. 1 and turn  
camshaft on adapter to intake side until rocker  
arms (all) are relaxed.

Pull out rocker arm shaft.




28 11 635

2) Intake Side:

Turn camshaft on the adapter to exhaust side  
and move rocker arms until all rocker arms are  
relaxed.

Pull out rocker arm shaft.

Replace worn (scored) rocker arm shafts and  
rocker arms.



28 11 636

*Installation:*

Install rocker arm shafts that large oil bores  
face down to valve guides and small oil bores  
as well as grooves for guide plate face in.


## 11-125

### 11 33 031 REPLACING ROCKER ARMS

Remove rocker arm shafts 11 33 020.  
Replace worn rocker arms or rocker arms with loose guides.  
Loose guides will be noticed as excessively loud valve noise.



28 11 565




28 11 565


Transfer screw (1), eccentric (2), washer (3) and nut (4) to new rocker arm.  
Replace a worn eccentric.

*Important!*

Screw and nut have M 6 x 0.75 fine threads.  
Bore faces out and thick side down.  
Bevelled surface of screw faces tab on rocker arm.



28 11 583



28 11 582


### 11 34 004 ADJUSTING VALVE PLAY

Remove cylinder head cover 11 12 000.  
Crank engine with a wrench socket on the crankshaft (vibration damper).  
Adjusting order is same as the firing order (1 5 3 6 2 4) in compression top dead center (TDC).  
Adjust valve clearance\* between valve and eccentric after loosening nut (1).

Tighten nut (1) with Special Tools 11 1 150 and 00 2 050.  
Tightening torque\*.

### 11 34 509 CHECKING ALL VALVES FOR LEAKS - CAMSHAFT REMOVED -

Spark plugs remain installed.  
Fill combustion chamber with gasoline outdoors or indoors with strict conformance with fire prevention regulations.  
If the gasoline runs past the valve heads, check valves and valve seats.  
Remove and install valves 11 34 550.  
Machine valve seats 11 12 607.




28 11 580

\* See Specifications




## 11-126



### 11 34 550 REMOVING AND INSTALLING VALVES

Remove rocker arm shafts 11 33 020.  
Place tray 11 1 066 in assembly stand 11 1 060.

Unscrew intake.  
*Installation:*  
Replace gaskets.




Press down the valve springs with Special Tool 11 1 060 and remove the valve collets.




Remove the upper spring retainer, valve springs and lower spring retainer.  
Take the tray out of the assembly stand and pull out the valve.

*Installation:*  
Only use valve springs with same color code, wire gage size and length.  
Lubricate valve guide and valve stem with oil.




Pull off valve stem seal with Special Tool 11 1 250.




Install valve.  
Always use Special Tool 11 1 350 to avoid damage on the valve stem seal.  
Lubricate valve stem seal (1) with oil and install.


Source for Special Tool Sleeves:  
Cartool  
Alfred-Brehm-Str. 5  
D-8070 Ingolstadt / West Germany



"Goetze" Seals:  
Press on the valve stem seal to fit tight with Special Tool 11 1 140.  
Dia. A = 12.8 mm (0.504").  
"Elring" Seals:  
Press on the valve stem seal to fit tight with Special Tool 11 1 080.  
Dia. A = 13.5 mm (0.531").




The new, improved valve stem seals (internal grooving) are pressed on by hand with Special Tool 11 1 200.  
Special Tool 11 1 200 has two diameters – for 7/8 mm (0.276/0.315") valve stem seals.



### 11 35 020 REMOVING AND INSTALLING DISTRIBUTOR INTERMEDIATE SHAFT

Remove fuel pump 13 31 030.  
Remove distributor 12 11 060.  
Remove front end cover 11 14 175.  
Remove guide plate (1).  
Pull out the intermediate shaft (2).

*Installation:*  
Check sprocket, replacing the intermediate shaft if necessary.  
The bearings in the crankcase cannot be replaced.



520 11 253

▲ unfiltered oil  
 ▤ filtered oil

## ENGINE OIL CIRCUIT



- |   |  |                                       |                    |
|---|--|---------------------------------------|--------------------|
| 1 Oil pan   | 5 Main distribution bore                 | 14 Rocker arm bearing (exhaust valve) | 22 Oil return      |
| 2 Intake with filter screen   | 6 Transmitter for oil pressure ind. lamp | 15 Intermediate shaft bearings        | 23 Oil filler neck |
| 3 Oil pump  | 7 Crankshaft bearings                    | 16 Oil line for cams                  | 24 Oil dipstick    |
| 3 a Pressure relief valve   | 8 Oil bore in cylinder head              | 17 Valve guide                        | 25 Oil drain plug  |
| 4 Oil filter  | 9 Hollow rocker arm shaft                | 18 Connecting rod bearings            |                    |
| 4 a Safety valve (oil filter)                                       | 10 Front camshaft bearing                | 19 Spray oil                          |                    |
| 4 b Check valve — unfiltered side ) prevents draining of oil filter | 11 Camshaft bearing                      | 20 Piston pin / cylinder wall         |                    |
| 4 c Check valve — filtered side ) when engine is stopped            | 12 Rear camshaft bearing                 | 21 Overflow from cylinder head        |                    |
| 4 d Pressure relief valve   | 13 Rocker arm bearing (intake valve)     |                                       |                    |

## 11 40 000 CHECKING ENGINE OIL PRESSURE

Pull off wires on oil pressure switch.  
Unscrew oil pressure switch (1).

*Installation:*

Check gasket, replacing if necessary.




Screw in Special Tool 11 4 050 (adapter).  
Connect Special Tools 13 3 063 (hose) and  
13 3 061 (pressure tester).  
Check oil pressure\*.

\* See Specifications



## 11-129




### 11 41 000 REMOVING AND INSTALLING OIL PUMP


Remove oil pan 11 95 000  
Unscrew oil pump.



*Installation:*  
Guide in drive shaft (1).  
Replace bearing, see 11 11 160.




*Testing and Servicing:*  
Unscrew cover (2) and clean oil filter screen (3).




Check whether gears turn easily by turning the drive shaft.




Unscrew oil pump cover and check oil pump for wear.  
– Scoring in body/cover  
– Wear on gears



The overload valve regulates oil pressure in front of the oil filter and prevents oil filter leakage. Check that piston (5) moves easily. Check length of spring (6) =  $44 \pm 0.2$  mm ( $1.732 \pm 0.008$ ").



*Installation:*  
Press in and hold spring (6) and washer (7) with a screwdriver.  
Install circlip (8).



# 11 41 110 REMOVING AND INSTALLING PRESSURE RELIEF VALVE

The pressure relief valve is installed in the main bore and regulates the engine oil pressure\* after the oil filter.  
Remove oil pan 11 13 000.  
Unscrew pressure relief valve.  
Take off the sleeve (1).




# 11 42 020 REPLACING FULL FLOW OIL FILTER

Unscrew filter with Special Tools 11 4 020/ 11 4 650.

## Installation:

Give gasket a light coat of oil.  
Screw on the oil filter by hand until the gasket touches – then tighten by hand with one half turn.  
Add oil, start engine and check oil level and for leaks.

If the engine no longer builds up oil pressure after replacement of the oil filter cartridge, stop the engine, loosen the filter cartridge by approx. 90° and start the engine. Tighten the filter again after oil has run out briefly (bleeding procedure).




# 11 51 000 REMOVING AND INSTALLING WATER PUMP

Drain coolant.  
Remove distributor cap (1).  
Remove distributor rotor (2).  
Unscrew adapter (8).  
Remove cover (3).  
Unscrew bolts (4).  
Remove fan 11 52 000.

## Installation:

Pour in coolant and bleed the cooling system 17 00 039.


Check seal (9), replacing if necessary.



Remove pulley.  
Unscrew nut (4) and take off the drive belt.  
Lift out rubber part (5) and pull out the protective cover (6).

## Installation:


Tighten the drive belt and check the tightness with Special Tool 11 5 020.



Compress the spring and clamp the pin with Special Tool 11 5 010.


## Installation:

Check installed position of the pin to the water pump.



# 11 43 101 REPLACING GUIDE TUBE FOR OIL DIPSTICK

Install the guide tube with Loctite No. 270\*\* and drive it in against the stop.



Disconnect coolant hoses (7 and 8).  
Remove the water pump.

## Installation:


Replace the gasket.

\* See Specifications

\*\* Source: HWB

11 51 502 OVERHAULING WATER PUMP  
- WATER PUMP REMOVED -

Pull off hub (1) with Special Tool 00 8 500.  
Remove circlip (8).




Press out water pump bearing.



Drive out seal (4).

**Installation:**

Press in seal (4) with Special Tool 00 5 550.



Replace bearing (3) and seal (4).  
Check impeller (6), replacing if necessary.


1 = hub

7 = Water pump body

**Installation:**


Press in bearing (3) against stop.

Press on impeller (6).



Check dimensions after assembling.

## 11-132




### 11 52 000 REMOVING AND INSTALLING FAN

Temperature Dependent Visco Fan Clutch:  
Hold pulley with Special Tool 11 5 030 and unscrew the coupling nut (1).

*Important!*

Left-hand threads — nut turned clockwise to unscrew.  
Tightening torque\*.



### 11 52 020 REPLACING FAN CLUTCH

Remove fan 11 52 000.


Reasons for Replacing the Fan Clutch:

- a) Hub has seized — fan of stopped engine cannot be turned or is hard to turn.
- b) Fan clutch has axial/radial play or is losing oil.

Check the switching points\* with a Vibrocard\*\*\*.

Unscrew the fan mounting bolts and take off the fan clutch.

736 11 215




### 11 53 000 REMOVING AND INSTALLING COOLANT THERMOSTAT

Drain some of the coolant.  
Unscrew cover (1).

*Installation:*

Bleed the cooling system 17 00 039.



Remove thermostat.

*Installation:*


Clamp on the thermostat faces out.

Replace rubber ring (2).

Since 1986 Models:

New thermostat housing:

Install thermostat no. 1 713 040 (smaller valve seat diameter).




Checking Thermostat:

Check whether opening temperature agrees with the value in the Specifications.

Check opening temperature in a hot water bath and compare value with the stamped opening temperature value.

20 11 190



### 11 53 080 REPLACING TEMPERATURE TRANSMITTER

Pull off wire (1).

Unscrew the transmitter.

*Installation:*

Replace seal (2).


Bleed the cooling system 17 00 039.

28 11 586

\* See Specifications

\*\*\* See Workshop Equipment Catalog

## 11-133



28 11 523

### 11 76 010 REMOVING AND INSTALLING CATALYTIC CONVERTER


Remove the exhaust assembly 18 00 020.  
Unscrew the triangular flange.  
Pull off the catalytic converter.

*Installation:*

Replace the gasket.

Check catalytic converter for damage on the outside, cracks and loose parts on the inside.  
*Important!*

Replace the oxygen sensor and catalytic converter, if the car had been operated on gasoline containing lead.



28 11 590

### 11 78 010 CHECKING FUNCTION OF OXYGEN SENSOR

Unscrew plug (1).


Screw in Special Tool 13 0 100 and mount Special Tool 13 0 090.

Connect the BMW service tester.

Measure the CO level.

Specifications: 0.2 to 1.2 % by volume.

Refer to 13 00 054 for other information.



20 11 242


Pull off vacuum hose (1) on the pressure regulator and plug.

The CO level will rise briefly and be regulated back to the original value immediately = the oxygen sensor is working.

*Defective:*

Check power supply to the oxygen sensor via the relay according to the wiring diagram.  
See Group 13 for additional information.


## 11 78 510 REPLACING OXYGEN SENSOR



Oxygen sensors have to be replaced at intervals of 30,000 miles — see "O<sub>2</sub> SENSOR" lamp in check control.


- Do not clean the oxygen sensor or let it come in contact with lubricants.
- Only use "Anti-Seize"\*\*\* on threads.
- Protect the oxygen sensor when undercoating the car.

Disconnect plugs (1).  
Lift wires out of clips.



Pull off plate (2).  
Unscrew the oxygen sensor (3).

Installation:  
Coat threads with "Anti-Seize"\*\*\*.



Since 1985 Models:  
Reset the oxygen sensor indicator by pressing the resetter (arrow) — the "O<sub>2</sub> SENSOR" lamp goes out.

- 1 Resetter
- 2 Steering column support
- 3 Steering wheel
- 4 Impact guard



Until 1984 Models:  
However, the "O<sub>2</sub> SENSOR" sign will light up only after the first 30,000 miles.  
Lift out the check control.



Remove lamp for the "O<sub>2</sub> SENSOR" sign.


\*\*\* Source: HWB, No. 81 22 9 400 088

# 11 Engine

## BMW 524td


	Special working instructions .....	11-	200a
11 00 039	Compression – check .....	11-	201
050	Engine – remove and install .....	11-	202
091	Engine – exchange .....	11-	204
11 11 160	Bearing for oil pump drive shaft – replace .....	11-	205
11 12 000	Cylinder head cover – remove and install .....	11-	205
100	Cylinder head – remove and install .....	11-	206
101	Cylinder head gasket – replace .....	11-	209
240	Radial oil seal in end cover – replace .....	11-	210
595	Valve guide – check for wear (valve removed) .....	11-	211
600	Valve guide – ream out (valve removed) .....	11-	211
607	Valve seat – machine (cylinder head disassembled) .....	11-	211
729	Cylinder head – check for cracks in water test (cylinder head disassembled) .....	11-	212
11 13 000	Oil pan – remove and install .....	11-	213
11 41 175	Front end cover – remove and install .....	11-	214
180	Radial oil seal in front end cover – replace .....	11-	214
605	Radial oil seal in clutch end cover – replace .....	11-	215
11 21 000	Crankshaft – remove and install .....	11-	216
501	Crankshaft – replace (crankshaft removed) .....	11-	217
531	Crankshaft main bearing shells – replace (engine disassembled) .....	11-	217
571	Pilot bearing in crankshaft – replace .....	11-	218
11 22 000	Flywheel – remove and install .....	11-	218
051	Drive plate for torque converter – replace .....	11-	218
11 23 010	Vibration damper – replace .....	11-	219
031	Vibration damper hub – replace .....	11-	219
11 24 521	Connecting rods – replace (pistons removed) .....	11-	220
571	Connecting rod bearing shells – replace (engine disassembled) .....	11-	220
11 25 000	Piston – remove and install .....	11-	221
651	Piston rings of one piston – replace (piston removed) .....	11-	222
11 31 000	Camshaft – remove and install .....	11-	223
100	Toothed belt – tighten .....	11-	224
110	Toothed belt – remove and install .....	11-	225
11 33 050	Rocker arm – replace .....	11-	226
11 34 004	Valve clearance – adjust .....	11-	226
509	Valves – check for leaks (camshaft removed) .....	11-	226
550	Valves – remove and install .....	11-	227
11 35 020	Intermediate shaft – remove and install .....	11-	227
	Engine oil circuit .....	11-	228
11 40 000	Engine oil pressure – check .....	11-	229
11 41 000	Oil pump – remove and install .....	11-	230
11 42 020	Oil filter – replace .....	11-	231
650	Oil spray jet – remove and install/replace (crankshaft removed) .....	11-	231
11 51 000	Water pump – remove and install .....	11-	231
502	Water pump – overhaul (water pump removed) .....	11-	232
11 52 000	Fan – remove and install .....	11-	233
020	Fan coupling – replace .....	11-	233
11 53 000	Coolant thermostat – remove and install .....	11-	233
080	Temperature transmitter – replace .....	11-	233
11 61 450	Charging air pressure blow-off valve – remove and install .....	11-	234
11 65 015	Bearing play of turbocharger – check (turbocharger removed) .....	11-	235
018	Charging air pressure of turbocharger – check .....	11-	235
020	Turbocharger – remove and install .....	11-	236
059	Control valve – check and adjust .....	11-	237
060	Control valve – remove and install .....	11-	237
11 66 000	Vacuum pump – remove and install .....	11-	237
	Emission control layout – 524 td .....	11-	238
11 70 009	Emission control – check .....	11-	239
11 71 501	EGR valve – replace .....	11-	241





M21 11 191

M 21 D 24 = BMW 524 td



M21 11 190



## 11-200a

### WORKING INSTRUCTIONS

These instructions concern cleanliness when working on fuel supply and control systems.


- Clean area around repair point thoroughly – e.g. before disconnecting lines, switches, etc..
- Place removed parts only on clean surfaces and cover with plastic sheet – never use cloths losing lint.
- Cover or inert plugs in open lines and openings in parts immediately – do not work with compressed air.
- Only install cleaned parts.  
Take new replacement parts out of their packaging only shortly before installing.
- Keep diesel fuel off of coolant hoses – or wash off immediately with water if applicable.

### EXPLANATIONS OF ABBREVIATIONS

Injection Pump Attachments:


- |      |  |
|------|--|
| TLA  | – Temperature dependent idle speed boost                         |
| ALDA | – Atmospheric and charging air pressure dependent full load stop |
| AGR  | – Exhaust gas recirculation (EGR)                                |

## 11 00 039 CHECKING COMPRESSION



M2111115

Testing Conditions:  
Battery in perfect charged condition –  
check acid density if necessary.  
Engine temperature = max. 35° C (95° F)  
coolant temperature.  
Lift off cover (2) and pull off plug (3) on  
the heating time control unit.




M2111121

Unscrew the glow plugs with Special Tool  
11 2 100 – see Group 12.

Installation:

Screw in the glow plugs with copper paste  
"CRC"\*\*\*.

Tightening torque\*\*\*.



M2111039

Screw in compression tester 11 0 160  
together with an adapter completely and  
tighten slightly by hand.  
Press the manual stopping lever forward and  
measure the compression pressure\*.  
Operate the starter so long, until the pressure  
stops rising – the compression tester has  
completed the test.

\* See Specification

\*\* Source: HWB

\*\*\* See Specifications of Gr. 12/23


## 11-202

### 11 00 050 REMOVING AND INSTALLING ENGINE

Remove transmission — see Group 23 or 24.  
Unscrew power steering pump.  
Pressure hoses remain connected.

*Installation:*

Tighten drive belt and check tightness with Special Tool 11 5 020.





Unscrew compressor.  
Refrigerant hoses remain connected.  
*Installation:*  
Tighten drive belt and check tightness with Special Tool 11 5 020.



Unscrew plug (2) and drain coolant.  
Remove radiator 17 11 000.  
Remove circlip and disconnect power lead.




Unscrew ground wire for hood.  
Disconnect or remove gas pressure props and prop up engine hood with Special Tool 51 2 110.  
*Caution!*  
Use locks (1).




Disconnect negative and positive leads on battery.  
Unscrew wire (2).  
Lift off cover (3) and pull off plugs (4 and 5).  
Unscrew wire (6).  
Remove preheating time control unit (7).


Remove tank.




Take off cover (8) and lift off cap (9).  
Pull off plug (10) and lift out relay (11).  
Pull off plug (12).  
Disconnect plug (13).  
Unscrew wire harness on body.



Disconnect accelerator cable (12) and cruise control cable (13).  
Disconnect fuel hoses (14 and 15).  
*Installation:*  
Adjust accelerator cable, see 35 41 421.  
Adjust cruise control cable, see Group 65.




## 11-203




Disconnect hoses (1 ... 5).  
Pull off plug (6) and disconnect wire.



Disconnect water hoses for heater.




Disconnect hose (1).  
Turn out hose (2).  
Loosen clamp (3).  
Unscrew nut (4) and remove air cleaner.  
*Installation:*  
Turn arrow to face up.



Unscrew oil lines on oil cooler.  
*Installation:*  
Pour in engine oil\*\*\*.

\*\*\* See Service Information of Gr. 00




Pull off hose.



Pull off plug (5) on control unit in glove box.  
Disconnect engine wire harness and pull it into engine compartment.




Attach Special Tool 11 0 020 on engine.



Unscrew wire (5) and ground strap (6).  
Unscrew both engine mounts and lift out engine.  
*Installation:*  
Guide pin (7) into bore of axle carrier.  
Tightening torque\*.  
Check engine performance 13 00 050.

\* See Specifications

11 00 091 INSTALLING EXCHANGE  
ENGINE

Remove engine 11 00 050.

Exchange Engine Identification on Crankcase:

1 = Type/delivery scope

NO = Normal version

AB = Stripped version

2 = Manufacturing year (1983)

3 = "A" = exchange, "N" = new part

4 = Manufacturing month

Die stamp engine number (5).

Transfer parts from old to new engine.

Pour in engine oil\*\*\*.

*Important!*

If car has an automatic transmission, remove  
pilot bearing in crankshaft – see 11 21 571.

Install engine.


Check static adjustment of injection pump, see  
13 51 005.

Check engine performance, see 13 00 050.

\* See Specifications


\*\*\* See Service Information of Gr. 00

## 11-205




### 11 11 160 REPLACING BEARING FOR OIL PUMP DRIVE SHAFT


Remove oil pump 11 41 000.  
Remove injection pump, see Group 13.  
Unscrew the console.




Lift out cover (1).  
Remove gear (2).  
*Installation:*  
The open end of the gear shaft faces down.  
Check bearing in cover (1) and seal (3), replacing if necessary.



Drive out needle bearing from bottom to top with Special Tool 11 1 310.




*Installation:*  
Lubricate the needle bearings.  
Drive in needle bearing against the stop with Special Tool 11 1 300.




### 11 12 000 REMOVING AND INSTALLING CYLINDER HEAD COVER


Disconnect hoses (1 and 2).  
Remove pipe (3).



Loosen protective cover screws.  
*Installation:*  
First tighten cylinder head cover and then the protective cover.



Unscrew oil trap (7).  
Unscrew threaded sleeves and take off the cylinder head cover.  
*Installation:*  
Install the threaded sleeves with seals.  
Check seal on the oil trap, replacing if necessary.



*Installation:*  
Check cylinder head cover gasket (8) and rubber ring (9), replacing if necessary.  
Insert rubber ring (9) in cover and lubricate with oil.  
Tightening torque\*.


\* See Specifications



## 11-206


### 11 12 100 REMOVING AND INSTALLING CYLINDER HEAD

Remove turbocharger, see 11 65 020.  
 Unscrew plug and drain coolant.  
 Disconnect battery ground lead.  
*Installation:*  
 Pour in coolant\*\*\* and bleed cooling system  
 17 00 039.  
 Replace engine oil\*\*\*.




M 21 11 206

Remove fan, see 11 52 000.  
 Disconnect coolant hoses.




M 21 11 137

Disconnect coolant hose.  
 Pull off plug (1).  
 Pull off leak oil line (2).



M 21 11 138


Disconnect coolant hose (3).  
 Unscrew holder (4).  
 Unscrew wires on heater plugs.



M 21 11 139

\*\*\* See Service Information of Gr. 00

Pull off plug (5) on control unit in glove box.




M 21 11 203

Disconnect engine wire harness and pull into engine compartment.  
 Pull off hoses (6 and 7).  
 Disconnect plugs (8 ... 10).  
 Disconnect diagnosis plug.


*Installation:*

Always connect two gray plugs (9) together.




M 21 11 207


Disconnect coolant hose (11).  
 Unscrew wires on heater plugs.  
 Pull off plugs on temperature sensors.  
 Pull off plug (12).  
 Unscrew support (13).  
 Disconnect wire harness and lead it down.




M 21 11 208



Pull off hose (10).  
Unscrew holder (11).  
Pull off plug (12).




Unscrew oil trap (13).  
Pull off hose (14).  
*Installation:*  
Check seal, replacing if necessary.




Unscrew injection lines on fuel injectors and injection pump with Special Tool 13 5 020.  
Install protective caps.  
Remove cylinder head cover, see 11 12 000.  
*Installation:*  
Tightening torque: 20 to 25 Nm (14 to 18 ft. lbs.).  
Screw on injection lines and bleed fuel system, see 13 51 . . . .







Turn cylinder no. 1 to TDC — cyl. no. 6 overlaps.



Hold the crankshaft with Special Tool 11 2 300.



Remove hose (5) and the protective cover.  
*Installation:*  
First tighten the cylinder head cover and then the protective cover.




Loosen screws (1 and 2) and nut (3).  
Loosen the drive belt and take it off of the camshaft sprocket.



*Installation:*

Turn in the camshaft to have the valves of cylinder no. 6 overlapping before mounting the cylinder head — hold the camshaft with Special Tool 11 3 090.  
Install and tighten the drive belt, see 11 31 110.



Unscrew the bolts in order of 14 to 1 and take off the cylinder head.


*Installation:*

Keep oil out of the cavities, since otherwise the bolts tightened with the correct torque will not exert sufficient force on the cylinder head and, in addition, the crankcase might be cracked.

Clean the cylinder head bolts and give the threads and bolt head bearing surface a light coat of oil.

Replace the cylinder head gasket.

Measure the piston protrusion, see 11 12 101.



Tighten the bolts in three steps in order of 1 to 14.

Tightening torque\*.

Adjust the valve clearance 11 34 004.

Check the static adjustment of the injection pump 13 51 005.

In the third step (cylinder head cover removed again after running the engine warm) the cylinder head bolts are tightening to the correct torque angle\* with Special Tool 11 2 110 regardless of the engine temperature.

\* See Specifications


## 11 12 101 REPLACING CYLINDER HEAD GASKET

Remove the cylinder head 11 12 100.  
Clean the sealing surfaces on the cylinder head and crankcase thoroughly with a sealant remover\*\* and hard wood scraper carefully (even slight scoring would render the engine to leak due to the high compression).  
Check the levelness with a standard steel ruler\*.  
*The cylinder head may not be reground.*  
A cylinder head gasket must be installed which conforms with the maximum piston protrusion of all six pistons.

**Measuring Piston Protrusion:**  
Set up a dial gage with Special Tool 00 2 530 on the cleaned cylinder head sealing surface and set the dial gage to zero with preload.

Place the dial gage on checkpoint "A" of the cleaned piston and find the highest point by turning the crankshaft.  
Note the displayed value = "piston protrusion A".  
Set up the dial gage on checkpoint "B" and note "piston protrusion B".  
The mean value of "A" + "B" is the "piston protrusion" of a piston.  
Repeat these measurements on all six pistons.


\* See Specifications  
\*\* Source: HWB



The piston with the highest "piston protrusion" determines the thickness of the cylinder head gasket.

Cylinder Head Gaskets:

Max. Piston Protrusion of All Six Pistons	Identification of Cyl. Head Gasket Number of Holes
0.64 ... 0.78 mm (0.025 ... 0.030")	1
0.79 ... 0.91 mm (0.031 ... 0.035")	2
0.92 ... 1.08 mm (0.036 ... 0.042")	3



The burners have a shrink-fit in the cylinder head.  
The cylinder head has to be replaced, when burners are loose or damaged.

Burner retrusion "distance B"\*.  


\* See Specifications


## 11-210

### 11 12 240 REPLACING RADIAL OIL SEAL IN END COVER


Remove drive belt 11 31 110.  
Unscrew the drive belt sprocket (1).

*Installation:*


Slide slot of sprocket and bore of washer (2)  
over the pin of the camshaft.



M2111052




M2111144




M2111145

Unscrew the oil line (3) and bearing cap (4).  
Pull off the radial oil seal.

Coat the sealing surface with a brush-on  
universal sealing compound / Three Bond  
Silicone 1207\*\* and mount the bearing  
cap (4) again.  
Tightening torque\*.



M2111146



M2111147

Slide on the radial oil seal over Special Tool  
11 2 212.

Lubricate the sealing lip with oil.


Press in the radial oil seal with Special Tools  
11 3 080 and 00 5 500.

Press in the new radial oil seal against the stop,  
in contradiction to the standard seal which had  
been pressed in flush.

\* See Specifications


\*\* Source: HWB

# 11-211




## 11 12 595 CHECKING VALVE GUIDE FOR WEAR — Valve Removed —

To measure, install a new valve that its stem end is flush with the valve guide. Apply the dial gage and measure the tilt clearance.  
Max. permissible tilt clearance\*.




## 11 12 607 MACHINING VALVE SEAT — Cylinder Head Disassembled —

The valve seat machine from "Hunger" and the five-edged cutting tool from "New Way" are approved for the machining of valve seat insert rings.  
An oversized valve must be installed after machining a valve seat.  
Machine the valve seat insert rings until the specified valve retraction "R" is reached.




Valve retraction R\*.  
Produce the valve seat diameter M\* and valve seat width B\* by grinding the correction angles\* after machining the valve seat angle\*. The valves must not be ground in.  
Check the valves for leaks 11 34 509.



## 11 12 600 REAMING OUT VALVE GUIDE — Valve Removed —

If there is excessive play between the valve guide and valve stem, see 11 12 595, ream out the valve guide and install a valve with a larger stem diameter "S"\*.  
The valve seat must also be machined in conjunction with this step, see 11 12 607.  
Press guide mushroom (1) on to the valve seat and ream out the valve guide from the combustion chamber end — turning down the reamer once.




\* See Specifications

\* See Specifications

## 11-212

### 11 12 729 CHECKING CYLINDER HEAD FOR CRACKS IN WATER TEST — Cylinder Head Disassembled —

Mount Special Tools 11 1 031 on the cylinder head (using cylinder head bolts).




M 2111083

Unscrew adapter (1) and plug holes with Special Tools 11 1 036.

Use seals.


*Note:*

Screw in the adapter with a bolt cement\*\*.



M 2111100

Install Special Tools 11 1 034 and 11 1 035.




M 2111117

Install Special Tool 11 1 033.

Apply 4.5 bar (64 psi) air pressure on cylinder head and check for leaks (cracks) by placing the head in a water bath.

*Note:*

Relax the water bath with a detergent.




M 2111118


\*\* Source: HWB

# 11-213

## 11 13 000 REMOVING AND INSTALLING OIL PAN




Drain engine oil.  
Lift out and disconnect plug (1).  
Disconnect hose (2).  
*Installation:*  
Pour in engine oil\*\*\*.



Unscrew reinforcement plate.



Unscrew oil pan.  
Unscrew oil pump and remove oil pan.  
*Installation:*  
Insert drive shaft for oil pump, see 11 41 000.  
Replace gasket.



*Installation:*  
Clean sealing surfaces.  
Coat mating surfaces on timing case cover  
and end cover with universal sealing com-  
pound\*\*.

\*\* Source: HWB  
\*\*\* See Service Information of Gr. 00



## 11-214

### 11 14 175 REMOVING AND INSTALLING FRONT END COVER

Remove hub for vibration damper — see 11 23 031.  
Remove the drive belt, see 11 31 110.  
Hold the intermediate shaft sprocket with Special Tool 11 2 040.  
Unscrew the bolt.  
Take off the washer and sprocket.

*Installation:*






Guide the centering pin into the bore.

Screw in bolt (1).  
Pull the sprocket off of the crankshaft with Special Tools 00 7 501 and 11 2 131.

*Important!*  
Woodruff key.

*Installation:*  
Mount the sprocket that the stepped side faces forward.

Unscrew bolts (4 ... 6).  
Only loosen the other oil pan bolts.  
Loosen the oil pan gasket on the end cover carefully with a knife.  
Remove the cover.



*Installation:*


If the oil pan gasket was damaged, remove the oil pan and replace the gasket 11 13 000.  
Coat the bores of the oil pan gasket with a brush-on universal sealing compound / Three Bond Silicone 1207\*\*.  
Replace gasket (7).

Check the radial oil seals, replacing if necessary.  
Install the end cover with Special Tools 11 2 211 (crankshaft) and 11 2 212 (intermediate shaft).

### 11 14 180 REPLACING RADIAL OIL SEAL IN END COVER





Remove the end cover, see 11 14 175.  
Press radial oil seals out of the cover.  
Press in the radial oil seals with Special Tools 24 1 050 / 24 1 040.  
Press in the new radial oil seals 1 to 2 mm (0.039 to 0.079") deep, in contradiction to the standard seals which had been installed flush.  
Lubricate the sealing lips with oil.

\*\* Source: HWB



M 21 11 050

## 11-215



### 11 14 605 REPLACING RADIAL OIL SEAL IN CLUTCH END COVER — Transmission Removed —

Remove the flywheel, see 11 22 000.  
Unscrew the oil pan/end cover bolts.  
Only loosen the other oil pan bolts.  
Loosen the oil pan gasket on the end cover  
carefully with a knife.  
If the oil pan gasket is damaged, remove the  
oil pan and replace the gasket, see 11 13 000.  
Remove the end cover.

#### Installation:

Replace gasket (1).  
Coat the bores of the oil pan gasket with a  
brush-on universal sealing compound / Three  
Bond Silicone 1207\*\*.

Press in the radial oil seal with Special Tools  
11 1 260 and 00 5 500.  
Press in the new radial oil seal 1 to 2 mm  
(0.039 to 0.079") deep, in contradiction to  
the standard seal which had been pressed in  
flush.  
Lubricate the sealing lip with oil.


#### Installation:

Install the end cover with Special Tool  
11 2 213.

\*\* Source: HWB




## 11-216




### 11 21 000 REMOVING AND INSTALLING CRANKSHAFT


Remove the engine, see 11 00 050.  
Mount the engine block on Special Tool 11 0 110 in Special Tool 00 1 490.



Remove the clutch, see 21 21 000.  
Remove the cylinder head, see 11 12 100.  
Remove the front end cover, see 11 14 175.  
Remove the oil pump, see 11 41 000.  
Unscrew the struts.




Measure the axial play\* before removing the crankshaft.  
Check / replace the thrust bearing, if the maximum permissible play is exceeded.



Remove the flywheel, see 11 22 000.  
Remove the end cover.  
*Installation:*  
Replace the gasket.  
Use Special Tool 11 2 213 to avoid damage on the radial oil seal.  
Cut off the gasket on the oil pan sealing surface.


\* See Specifications



Unscrew the connecting rod bearing caps.

*Installation:*

Replace the conrod bearing shells and measure the conrod bearing play, see 11 24 571.  
The pairing code (0 to 99) must be the same on the connecting rods and bearing caps.



Remove the crankshaft bearing caps and lift out the crankshaft.

*Installation:*

Do not mix up the bearing caps.  
Bearing cap no. 1 is on the drive belt end.  
Bearing no. 6 is the thrust bearing.  
Install the bearing shells and check the bearing play, see 11 21 531.

*Installation:*

Measure the axial play with the crankshaft installed — loosen thrust bearing 6.  
Center the thrust bearing by applying knocks from a plastic hammer on the front and rear ends of the crankshaft.  
Tighten the thrust bearing to specifications.  
Measure the axial play\*.

Clean the oil and water bores thoroughly to remove the casting sand, if the crankcase is replaced.

\* See Specifications


# 11-217



28 11 30i



28 11 30E



M21 11 023

## 11 21 501 REPLACING CRANKSHAFT — Crankshaft Removed —

Crankshaft Identification:

Engine	Stroke	Code
M 21 D	81 mm (3.189")	C

Reground crankshafts are marked with stripes of paint.

Check the machined sizes!

Conrod Bearing Journal (A)

1 paint stripe = size 1\*

2 paint stripes = size 2\*

Main Bearing Journal (B)

1 paint stripe = size 1\*

2 paint stripes = size 2\*


*Important!*

Crankshafts are surface treated and may only be reground in the plant.

Crankshafts are supplied with the corresponding bearing shells.

Install bearing shells and check the bearing play, see 11 21 531.

Install the pilot bearing for cars with a manual transmission, see 11 21 571.



M 21 11 007

## 11 21 531 REPLACING CRANKSHAFT MAIN BEARING SHELLS — Engine Disassembled —

The bearing shells are marked with yellow, green or white paint.


1 = Bearing shell 1 2 3 4 5 7

2 = Bearing shell 6 (thrust bearing)


3 = Bearing shell with lubricating groove installed in crankcase

4 = Bearing shell without lubricating groove installed in bearing cap


Check the machined size (main bearing dia.).



M 88 11 060



M 88 11 061



M 88 11 062

Install bearing shells in the crankcase according to the color code of the crankcase.

If the mark has been washed off in the crankcase, install both shells to the crankshaft color code.

Install the crankshaft.

Install bearing shells in the bearing caps to the color codes of the shaft.

Place Type PG-1 Plastigage on crankshaft wiped clean of oil and tighten bearing caps to the correct torque\*.

Do not turn the crankshaft.

Source for Plastigage:

Cartool

Alfred-Brehm-Str. 5

D-8070 Ingolstadt / West Germany

Remove the bearing caps.

Read the bearing play\* from the width of the flattened Plastigage with help of the scale.

Correct the bearing play by installing new bearing shells, bearing shells with different machined size or different color code.

\* See Specifications


\* See Specifications

## 11-218




### 11 21 571 REPLACING PILOT BEARING IN CRANKSHAFT


Remove the clutch, see 21 21 000.  
Pull out the ball bearing with Special Tool 11 2 010.



Installed Order:  
Ball bearing (1), cover (2), felt ring (3) and capsule (4).  
Install the cover (2) with the embossment facing out.



Pack bore in the crankshaft with approx. 1 gr. of lubricating grease.  
Drive in the pilot bearing with Special Tools 11 2 030 and 00 5 500.



### 11 22 000 REMOVING AND INSTALLING FLYWHEEL

Remove the clutch, see 21 21 000.  
Hold the flywheel with Special Tool 11 2 170.  
Unscrew the bolt and take off the flywheel.


Installation:

Clean the tapped bores.

Insert ring (1).



Replace and install the new expansion bolts with a bolt cement\*\*.

Tightening torque\*.



Check the axial runout\* of the flywheel.  
The friction surface may be machined to minimum thickness A\*.  
If machining the friction surface reduces distance "h" to zero, the flange surface (distance "h") has to be machined.

M 88 11 072



### 11 22 051 REPLACING DRIVE PLATE FOR TORQUE CONVERTER

Remove the transmission, see Group 24.  
Hold the flywheel with Special Tool 11 2 170.  
Unscrew the bolts and remove the flywheel.

Installation:

Clean the tapped bores.


Replace and install the new expansion bolts with a bolt cement\*\*.

Tightening torque\*.


\* See Specifications

\*\* Source: HWB

## 11-219



M21 11 021



M21 11 020

### 11 23 010 REPLACING VIBRATION DAMPER

Remove the fan, see 11 52 000.  
Take the drive belt off of the alternator, power steering pump and, if applicable, air conditioner compressor.  
Unscrew the pulley.


#### Installation:

Tighten the drive belt and check tightness with Special Tool 11 5 020.


Take pulley and vibration damper off of the hub.

#### Installation:

The centering pin must fit in the bore of the vibration damper.



M21 11 019



M21 11 018

### 11 23 031 REPLACING HUB FOR VIBRATION DAMPER

Remove the radiator, see 17 11 000.  
Remove the vibration damper, see 11 23 010.  
Hold the hub with Special Tool 11 2 150.  
Unscrew bolt (3).  
Take off the collar washer (4).

#### Installation:


Tightening torque\*.

Screw in bolt (3) about three turns.  
Pull the hub off of the crankshaft with Special Tools 00 7 501 and 11 2 132.  
Remove bolt (3).

\* See Specifications

# 11-220


## 11 24 521 REPLACING CONNECTING RODS — Pistons Removed —



### Important!

Only install connecting rods of same weight class in one engine.  
Weight class is stamped in machined conrod cap surface.  
Connecting rods may not be machined.

Piston pin must slide through conrod bush under light pressure.



M 21 11 156

## 11 24 571 REPLACING CONROD BEARING SHELLS — Engine Disassembled —

Install red or blue conrod bearing shells according to color code on connecting rod.

### Important!

Check machined size (conrod bearing dia.).



M 21 11 15

In BDC position place Plastigage Type PG 1 on crankshaft wiped clean of oil and install conrod bearing caps that grooves are on one side.


Pairing code (0 ... 99) must be the same on cap and connecting rod.

Source for Plastigage:

Cartool

Alfred-Brehm-Str. 5

D-8070 Ingolstadt



M 21 11 156

Tighten bolts in two steps (using old conrod bolts):

Step 1 - 20 Nm (14. ft. lbs.)

Step 2 - 70° torque angle

### Important!

Do not turn the connecting rod or crankshaft. Remove bearing caps.


Read bearing play\* from width of flattened Plastigage with help of supplied scale.

Correct bearing play by installing new bearing shells, bearing shells with different machined size or different color code.

For final installation, use new conrod bolts and tighten conrod cap bolts in two steps (see above).



M 21 11 156



M 21 11 157

\* See Specifications




# 11-221


## 11 25 000 REMOVING AND INSTALLING PISTON



M 21 11 156




M 21 11 104



11 2 050

M 21 11 119



M 21 11 008

Remove the engine  
Take off the cylinder head, oil pan and oil pump.  
Remove the conrod bearing cap.  
*Important!*  
Mark the installed position of the connecting rod to the crankshaft, if the conrod bearing shells do not have to be replaced.

*Important!*  
Engine oil is injected through the oil spray jet (3) into the annular port (4) to cool the pistons.  
Even slight damage on the oil spray jet (3) could mean that the oil stream would not align with bore (4) for the annular port, which would result in an immediate engine defect.

To avoid damage on the oil spray jet (3), bolt Special Tool 11 2 050 on the connecting rod. Press out the piston upwards.


Lift out circlip (1).  
Press out the piston pin.  
*Installation:*  
The piston pin is matched with the piston and must not be mixed up.




M 21 11 009



28 11 064



28 11 507



28 11 508

Only install a piston of the same make and same weight group.  
The weight group is stamped in the piston crown with a "+" or "-" sign.  
*Important!*  
Check the machined size\* (piston diameter).

Check the piston installed clearance\*.

Engine	Make	Checkpoint A
M 21 D	Alcan	15.00 mm (0.591")
	KS	18.00 mm (0.709")
	Mahle/König	12.00 mm (0.472")


Set the internal calipers on the micrometer to zero with the measured piston diameter.

Measure the cylinder bore at the bottom, middle and top with the internal calipers in forward and rotating directions.  
Measure the piston installed clearance\*.

\* See Specifications


## 11-222

Lubricate piston and piston rings with oil.  
Offset piston ring end gaps by 120°.  
Compress piston rings with Special Tool  
11 2 260.




M 21 11 010

Screw Special Tool 11 2 050 on connecting  
rod to avoid damaging oil spray jet (3).



M 21 11 102



M 21 11 011


Install piston that arrow faces toothed belt.  
Install connecting rod, see 11 24 521.



M 21 11 012


### 11 25 651 REPLACING PISTON RINGS OF ONE PISTON — Piston Removed —

Check side clearance\* of piston rings (only  
possible on rings 2/3).



M 21 11 521

Remove piston rings and check end clearance\*.




M 21 11 013

*Installation:*  
Install piston rings that word "TOP" faces  
piston crown.

- 1 Keystone ring
- 2 Taper face ring
- 3 Bevelled ring with rubber lined spring


\* See Specifications

## 11-223




### 11 31 000 REMOVING AND INSTALLING CAMSHAFT


Detach hose (1).  
Unscrew hose (2).  
Loosen clamp (3).  
Unscrew nut (4) and remove air cleaner.  
Remove fan 11 52 000.  
Remove vacuum pump 11 66 000.  
*Installation:*  
Turn arrow up.




Remove rocker arm of cylinder no. 2/exhaust and rocker arm of cylinder no. 3/intake, see 11 33 031, to remove tension on camshaft.  
Turn cylinder no. 1 to TDC – cylinder no. 6 overlaps.




Hold crankshaft with Special Tool 11 2 300.




Detach hose (5) and unscrew protective cover.




Loosen bolts (1 and 2) and nut (3).  
Loosen toothed belt and take off of camshaft sprocket.  
Unscrew bolt (1) and take off camshaft sprocket.  
*Installation:*  
Tightening torque\*.



*Installation:*  
Slide slot of sprocket and bore of washer (2) over pin in camshaft.



Unscrew camshaft.  
*Installation:*  
Replace rocker arms, if replacing camshaft because of worn cams!  
Slide steel ring on to cam for vacuum pump.  
Bearings are marked.  
Bearing no. 1 is at front end.  
Install radial oil seal together with bearing no. 1, see 11 12 240.  
Mount oil line.




*Installation:*  
Check camshaft axial play\*.  
Install and tighten toothed belt, see 11 31 110.

\* See Specifications




# 11-224




**11 31 100 TIGHTENING DRIVE BELT**


Disconnect hose (1).  
Turn out hose (2).  
Loosen clamp (3).  
Unscrew nut (4) and remove the air cleaner.  
Remove the fan, see 11 52 000.  
*Installation:*  
Turn the arrow to face up.




Turn crankshaft to have TDC in cylinder no. 1 and overlapping in cylinder no. 6.




Hold the crankshaft with Special Tool 11 2 300.




Remove hose (5) and protective cover.  
Remove the cylinder head cover, see 11 12 000.




Loosen bolts (1 and 2) and nut (3).



Hold the camshaft with Special Tool 11 3 090.  
Turn the crankshaft to have TDC in cylinder no. 1 and overlapping in cylinder no. 6.




**Important!**  
Tighten the drive belt at a coolant temperature of 15 to 35° C (60 to 95° F).  
Place a 2.5 mm thick feeler gage blade on the exhaust end for new drive belts or drive belts used less than 15,000 km (10,000 miles).



Press tensioning roller toward outside with a torque wrench (analog display).  
Tightening torque for toothed belts  
up to 15,000 km (10,000 miles)  
42 + 3 Nm (30.5 + 2 ft. lbs.)  
from 15,000 km (10,000 miles) on  
30 to 35 Nm (22 to 25 ft. lbs.).  
Tighten nut (3).  
Tighten bolts (1 and 2).  
Check tightening torque of bolt (1).  
Crank engine once in turning direction and recheck timing.  
Adjust injection pump statically – see 13 51 005.

## 11-225




### 11 31 110 REMOVING AND INSTALLING DRIVE BELT


Disconnect hose (1).  
Turn out hose (2).  
Loosen clamp (3).  
Unscrew nut (4) and remove air cleaner.  
Remove fan 11 52 000.

*Installation:*


Turn the arrow to face up.




Cylinder no. 1 at TDC — cylinder no. 6 overlapping.




Hold the crankshaft with Special Tool 11 2 300.



Remove hose (5) and protective cover.  
Remove vibration damper, see 11 23 010.  
Remove cylinder head cover, see 11 12 000.



Loosen bolts (1 and 2) and nut (3).  
Mark the running direction of the drive belt and take off the belt.



*Installation:*


Hold the camshaft with Special Tool 11 3 090.  
Cyl. 1 at TDC — cyl. 6 overlapping.



Hold the injection pump gear with Special Tool 13 5 340 for a rough adjustment of the injection pump.

Install drive belt in opposite direction of the engine's running direction — turning the loose camshaft sprocket against the drive belt.  
Remove Special Tool 13 5 340.

Tighten the drive belt, see 11 31 100.




Drive Belt Layout

Adjust injection pump statically — see 13 51 005.

## 11-226

### 11 33 050 REPLACING ROCKER ARM

Remove vacuum pump 11 66 000.  
Pull off spring clip (1).  
Pertinent cams of camshaft must be turned up for removal of rocker arms.




M 21 11 180

Press down valve springs with Special Tool 11 3 120 and remove rocker arm – watching out for valve collets.

*Important!*

Install rocker arm with same ball-headed bolt. When replacing rocker arms, it is always necessary to also replace the ball-headed bolts.




M 21 11 057

Pull out ball-headed bolt with Special Tool 11 3 140.

*Installation:*


Install ball-headed bolt with a bolt cement\*\* and press in against stop.



M 21 11 186

*Installation:*

Press spring clip into groove of ball-headed bolt. Adjust valve clearance 11 34 004.



M 21 11 065


\*\* Source: HWB

### 11 34 004 ADJUSTING VALVE CLEARANCE

Remove cylinder head cover 11 12 000.  
Turn engine to TDC with a wrench socket used on crankshaft (vibration damper).  
Apply a 12 mm open-end wrench on nut (1) for counterholding and unscrew nut on adjusting eccentric (2).  
Adjust valve clearance "V" – eccentric always turned toward outside.  
Make adjustments in firing order (1-5-3-6-2-4) and in compression TDC.  
Tighten nut with Special Tools 11 1 180 and 00 2 050.  
Tightening torque\*.

### 11 34 509 CHECKING VALVES FOR LEAKS – Camshaft Removed –


Fill intake and exhaust ports with gasoline outdoors or indoors with strict conformance of fire prevention regulations. Valves and valve seats must be inspected if the gasoline runs past the valve heads. Remove and install valves 11 34 550. Machine valve seats 11 12 607.



M 21 11 066


\* See Specifications

## 11-227



### 11 34 550 REMOVING AND INSTALLING VALVES

Remove cylinder head, see 11 12 000.  
Unscrew the thermostat housing and mount the cylinder head on Special Tool 11 1 065 with Special Tool 11 3 135.  
Unscrew the intake manifold and exhaust manifold.  
*Installation:*  
Replace the gaskets.



Remove the camshaft, see 11 31 000.  
Install Special Tool 11 3 131 / 133 and place tray 11 3 132 in the assembly stand.  
Remove the drag lever.




Press down valve springs and remove the valve keepers.




Take off the upper spring retainer, valve springs and lower spring retainer.  
Take tray out of the assembly stand and pull out the valve.  
*Installation:*  
Only install valve springs with same color code, wire gage size and length.  
Lubricate the valve guide and valve stem with oil.  
Measure the valve retraction  $R^*$ , see 11 12 607.


\* See Specifications




Pull off the valve stem seal with Special Tool 11 1 250.



Install the valve.  
Use assembly sleeves to avoid damage on the valve stem seal.  
Lubricate the valve stem seal with oil and install seal (1).  
Source for Assembly Sleeves:  
Cartool  
Alfred-Brehm-Str. 5  
D-8070 Ingolstadt / West Germany



Press on the valve stem seal against the stop with Special Tool 11 1 170.  
The new, improved valve stem seal (internal grooving) is pressed on by hand with Special Tool 11 1 200.  
Special Tool 11 1 200 has two diameters — for 7/8 mm (0.276/0.315") valve stem seals.




### 11 35 020 REMOVING AND INSTALLING INTERMEDIATE SHAFT

Remove the front end cover, see 11 14 175.  
Unscrew guide plate (1).  
Pull out intermediate shaft (2) and, if necessary, turn the crankshaft.  
*Installation:*  
Check the gear, replacing the intermediate shaft if necessary.  
Bearings in the crankcase cannot be replaced.




11-228



M21 11 086

# ENGINE OIL CIRCUIT

- |  |   |
|--|---|
| 1 Main distribution bore in crankcase  | 17 Spray oil for gears (oil pump drive)   |
| 2 Oil riser bore in cylinder head  | 18 Connecting rod bearing   |
| 3 Camshaft bearing, center   | 19 Spray oil  |
| 4 Distributor bore in cylinder head  | 20 Piston pin   |
| 5 Hollow camshaft  | 21 Cylinder wall  |
| 6 Camshaft bearing, front  | 22 Oil pan  |
| 7 Hollow camshaft  | 23 Intake with filter screen  |
| 8 Camshaft bearing, rear   | 24 Oil pump   |
| 9 Oil line with open jets for supply to cams from outside, valve guide and ball pin for drag lever | 25 Overload valve (oil pump) with cold oil (opens at 5.5 to 6.5 bar pressure)             |
| 10 Eccentric for vacuum pump   | 26 Oil filter, 1.2 ltr. volume  |
| 11 Overflow from cylinder head   | 27 Safety valve (opens at 2.5 bar pressure/ oil supply guaranteed when filter is clogged) |
| 12 Drain into oil pan  | 28 Filter cartridge   |
| 13 Oil trap (crankcase vent)   | 29 Thermostat   |
| 14 Turbocharger  | 30 Oil cooler   |
| 15 Crankshaft bearing  | 31 Conn. for oil pressure transmitter of indicator lamp                                   |
| 16 Bearing of intermediate shaft and guide plate   | 32 Oil spray jet (piston cooling) (opens at 1.5 to 2.0 bar pressure)                      |



**11 40 000 CHECKING ENGINE OIL  
PRESSURE**

Disconnect wires on oil pressure switch.  
Unscrew oil pressure switch (1).


*Installation:*

Check gasket, replacing if necessary.

Screw in Special Tool 11 4 060.

Connect 10 bar (142 psi) pressure tester of  
BMW service test unit.

Check oil pressure\*.





\* See Specifications


## 11-230

### 11 41 000 REMOVING AND INSTALLING OIL PUMP


Remove the oil pan, see 11 13 000.  
Remove the oil pump.



*Installation:*  
Guide drive shaft (1) into the bearing.  
Replace the bearing, see 11 11 160.




*Checking and Servicing:*  
Unscrew cap (2) and clean oil filter screen (3).




Check whether the gears run easily by turning the drive shaft.



Unscrew the oil pump cover and inspect the oil pump for wear.  
— Scoring in body/cover  
— Wear of gears



The engine oil control valve regulates the engine oil pressure\*.  
Check movement of piston (5).  
Check length of spring (6) = 71.6 mm (2.819").




*Installation:*  
Press in and hold spring (6) and washer (7) with a screwdriver.  
Install circlip (8).

\* See Specifications



## 11-231



### 11 42 020 REPLACING OIL FILTER

Unscrew oil drain plug in oil filter and drain oil.

*Installation:*

Tightening torque\*.

Unscrew cover and pull out oil filter (1).

*Installation:*

Check seal, replacing if necessary.


Add oil\* and \*\*\*.

Tightening torque\*.

### 11 42 650 REMOVING AND INSTALLING/ REPLACING OIL SPRAY JET — Crankshaft Removed —


Engine oil is injected into annular bore (4) of piston via oil spray jet (3) for piston cooling. A guarantee that oil stream meets bore (4) could not be given were oil spray jet (3) even slightly damaged. Follow-up damage would be immediate engine failure.

Unscrew screws and take out oil spray jet (3).



\* See Specifications

\*\*\* See Service Information of Gr. 00



### 11 51 000 REMOVING AND INSTALLING WATER PUMP

Detach hose (1).

Unscrew hose (2).

Loosen clamp (3).

Unscrew nut (4) and remove air cleaner.

*Installation:*

Turn arrow up.

Remove fan 11 52 000.


Remove water hose (5).

Take off drive belt and unscrew pulley.

Unscrew screws and remove protective cover.

*Installation:*

Tighten drive belt and check tightness with Special Tool 11 5 020.



Detach water hose.

Unscrew water pump.

*Note:*

Only push toothed belt to one side.


*Installation:*

Replace gasket (1).

# 11-232


## 11 51 502 OVERHAULING WATER PUMP — Water Pump Removed —

Pull off hub (1) with Special Tool 00 8 500.  
Lift out circlip (8).



M 21 11 166

Press out water pump bearing.




M 21 11 167


Drive out seal (4).

Installation:

Lubricate seal (4) with oil and press in with Special Tool 00 5 550.



M 21 11 168



Replace bearing (3) and seal (4).  
Check impeller (6), replacing if necessary.


(1) = Hub

(7) = Water pump body

Installation:


Press in bearing (3) against stop.

Press on impeller (6).




Check assembled distances.

## 11-233



### 11 52 000 REMOVING AND INSTALLING FAN

Remove fan cowl.  
Hold pulley with Special Tool 11 5 030 and unscrew coupling nut (1).  
*Important!*  
Left-hand threads — nut turned clockwise to unscrew.  
*Installation:*  
Tightening torque\*.





### 11 53 000 REMOVING AND INSTALLING COOLANT THERMOSTAT

Remove fan, see 11 52 000.  
Drain coolant partially.  
Remove covers (1).  
Remove thermostat.


#### *Installation:*

Clamp on thermostat faces out.  
Replace rubber ring (2) and gasket.  
Loosen bleeder screw (3) with engine at operating temperature, heater set to "warm" and engine running at fast idle speed, and tighten bleeder screw again when escaping coolant is without air bubbles.



### 11 52 020 REPLACING FAN CLUTCH

Remove fan 11 52 000.  
Replace fan clutch, if  
a) hub has seized — fan of stopped engine cannot be turned or is hard to turn,  
b) fan clutch has axial/radial play or is losing oil.  
Check the switching points\* with a Vibrocard \*\*\*.  
Unscrew fan mounting bolts and take off the fan clutch.



#### Checking Thermostat:

Does the thermostat begin to open at the temperature quoted in the Specifications? Check opening temperature in hot water and compare with the stamped value.

### 11 53 080 REPLACING TEMPERATURE TRANSMITTER

Pull off plug.  
Unscrew transmitter.  
*Installation:*  
Replace seal.  
Tightening torque\*.  
Testing see Group 12.




\* See Specifications  
\*\*\* See Workshop Equipment Catalog

\* See Specifications

## 11-234

### 11 61 450 REMOVING AND INSTALLING CHARGING AIR PRESSURE BLOWOFF VALVE


The control valve limits charging air pressure.  
If this system fails, the blowoff valve protects  
the engine against overcharging — the oil  
indicator lamp comes on.  
Opening pressure\*.  
Pull off wire (1).  
Unscrew bolts.



\* See Specifications

# 11-235

## 11 65 015 CHECKING BEARING PLAY OF TURBOCHARGER




Excessive bearing play could be causing excessive oil in the turbocharger (which is also noticed by blue smoke) or noise.  
**Axial Play\*:**  
 Apply dial gage on turbocharger shaft and press from stop to stop without turning the shaft.  
 Turn turbocharger shaft and repeat check.




**Radial Play\*:**  
 Apply dial gage on turbocharger shaft.  
 Press turbocharger shaft on both ends uniformly from stop to stop, while turning it.

\* See Specifications

## 11 65 018 CHECKING CHARGING AIR PRESSURE OF TURBOCHARGER



Connect pressure tester 13 5 000 between collector and hose for injection pump.



Place pressure tester 13 5 000 in passenger compartment.  
 Be careful not to clamp the hose.  
 Measure charging air pressure by driving car in load range (braking) or on a dynamometer. The system is okay, if the charging air pressure\* stabilizes.  
 If charging air pressure is not correct, check control valve — see 11 65 060.  
 If charging air pressure is too low, check hose connections (leak spray) and movement of turbocharger shaft.

\* See Specifications

## 11-236

### 11 65 020 REMOVING AND INSTALLING TURBOCHARGER





The turbocharger receives oil from the engine oil circuit. Conformance with the following points is important to guarantee sufficient lubrication of the high speed turbocharger.

- Perfect engine oil circuit (specified engine oil, oil level, crankcase vent, etc.).
- Engine speed not too high before engine oil pressure has been built up (indicator lamp)
  - engine running at high speed also not stopped (turbocharger runs on).
- Engine not started immediately after an oil change. Instead first build up oil pressure by cranking the engine with the starter (disconnect wire for fuel shutoff, see 11 00 039).
- Excessively old engine oil will cause carbon deposits in the turbocharger. Carbon can be seen on the turbocharger shaft after taking off the oil line. In this case it would be necessary to replace the engine oil and oil filter.

#### Important When Working on Turbochargers:

- Even the most minute particles of dirt could lead to destruction of the turbocharger — consequently never run the engine without its air cleaner.
- If the hose is pulled off of the control valve, this could lead to overcharging and destruction of the engine when operating with the throttle wide open.

No repairs may be performed on turbochargers.



Disconnect hose (1).  
Turn out hose (2).  
Loosen clamp (3).  
Unscrew nut (4) and remove air cleaner.  
*Installation:*  
Turn arrow to face up.

Remove pipe (5).  
Unscrew exhaust pipe on turbocharger.  
Remove EGR valve, see 11 71 501.  
*Installation:*  
Check gaskets, replacing if necessary.  
Coat studs with copper paste "CRC"\*\*.  
Replace self-locking nut.  
Tightening torque\*.

Unscrew oil lines.  
*Installation:*  
Replace seals.  
Tightening torque\*.  
Check engine oil level.


Unscrew bolts and remove turbocharger.  
*Installation:*  
Check levelness of sealing surface.  
Tightening torque\*.

\* See Specifications  
\*\* Source: HWB


## 11-237

### 11 65 059 CHECKING AND ADJUSTING CONTROL VALVE

The control valve limits charging air pressure — see 11 65 018 for testing procedures.  
A control valve opening too early will be noticed by a drop in power and richening of the mixture (soot in exhaust).  
If the bypass valve opens too late, this will cause excessive charging air pressure — see 11 65 018.



Pull off hose (1) and connect pump 11 7 010. The control valve begins to open with a pressure of  $0.840 \pm 0.035$  bar — the regulating rod of a closed control valve must rest on pin (3) without tension.




Unscrew lock nut (2).  
Remove circlip on pin (3).  
Adjust control valve opening time as described.  
*Note:*  
One turn of the linkage is equal to 0.05 bar.  
*Installation:*  
Lock nut (2) with clear lacquer\*\*.

The regulating linkage is locked on a standard installed turbocharger and therefore cannot be turned.  
Such control valves with locked regulating rods must be replaced when the beginning of opening is not correct, see 11 65 060.

\*\* Source: HWB, No. 81 229 407 404


### 11 65 060 REMOVING AND INSTALLING CONTROL VALVE

Remove circlip (1) and disconnect linkage.  
Pull off hose (2).  
Unscrew screws (3).  
*Installation:*  
Replace screws (3).  
Adjust control valve, see 11 65 059.




### 11 66 000 REMOVING AND INSTALLING VACUUM PUMP


Remove cylinder head cover 11 12 000.  
Turn cams for vacuum pump to face down (with socket applied on crankshaft).  
Unscrew nuts and take off vacuum pump.



*Installation:*  
Install vacuum pump that pipe adapter is at rear and cam runs in opening of plunger.  
Insert seal (1).  
*Caution!*  
Never run engine without attached vacuum pump — loose cam ring.




Checking Vacuum Pump Pressure\* and Throttle:  
Connect BMW service test unit on throttle and check with engine running.



\* See Specifications





M21 11 192

EMISSION CONTROL LAYOUT DRAWING - 524 td


- 1 Pressure converter (7.20.680.12)
- 2 Filter
- 3 Damping container
- 4 Throttle (black side faces electric switching valve)
- 5 Electric switching valve (black - 7.20.939.13)
- 6 EGR valve (7.20.905.00)
- 7 Temperature switch (1 288 474) - open above + 78° C (172° F)
- 8 Control unit for VP-20 (0 281 001 018)
- 9 Idle switch

- 10 Altitude transmitter for ALDA (0 460 997 002) see Gr. 13
- 11 Vacuum pump
- 12 Atmospheric and charging pressure dependent control box for full load stop (ALDA) see Gr. 13
- 13 Venting valve (ALDA venting with EGR operation)
- 14 Speed/reference mark sensor - see Gr. 12
- 15 Coolant temperature sensor (0 280 130 037) see Gr. 12/13
- 16 Needle travel sensor in fuel injector - see Gr. 13
- 17 Valve for injection timing control - see Gr. 13
- 18 Air cleaner - see Gr. 13

## 11-239

### 11 70 009 CHECKING EMISSION CONTROL

Exhaust gas recirculation (EGR) is working at idle speed and partial load.




Perform following test with a coolant temperature  $> 78^{\circ}\text{C}$  ( $172^{\circ}\text{F}$ ) and the engine running.

- Vacuum on EGR Valve (6) –  
Connect hose (1) of the BMW service tester.


Measure the vacuum at idle speed and speeds of 1,000 to 2,800 rpm.

Min.:  $- 320\text{ mbar}$

Max.:  $- 430 \pm 10\text{ mbar}$



Pressure Converter (1)  
Apply Special Tool 13 2 000.



Provide  $- 600 \pm 10\text{ mbar}$  inlet pressure (2) with an external vacuum pump. Measure outlet pressure (3) with the BMW service tester.

Testing value:  $- 360 \pm 25\text{ mbar}$ .

If necessary, adjust the outlet pressure with linkage (4).

Adjusting value:  $- 360 \pm 5\text{ mbar}$ .

Defective:

- Check the vacuum pump pressure\* and throttle, see 11 66 000.
- Check EGR at idle speed.
- Check EGR at partial load.

\* See Specifications

# A.) EGR at Idle Speed:


EGR is working at idle speed and with a coolant temperature of  $> 78^{\circ}\text{C}$  ( $172^{\circ}\text{F}$ ).

— Temperature Switch (7) —

Switching-on temp.:  $78 \pm 3^{\circ}\text{C}$  ( $172 \pm 5^{\circ}\text{F}$ )

Switching-off temp.:  $60 \pm 3^{\circ}\text{C}$  ( $140 \pm 5^{\circ}\text{F}$ )

Check with BMW service test unit (ohmmeter).




— Idle Switch (9) —

Switching-off point: 0.5 mm (0.020") after idle stop.

Check with BMW service test unit (ohmmeter).

Loosen screw (1) to adjust.




— EGR Valve (6) —

Apply about - 400 mbar pressure (BMW service test unit) on EGR valve (6).

Pull off and reconnect hose (1) — closing and opening clicks will be heard.

Also refer to 11 71 501.




— Electric Switching Valve (5) —

Check with ignition on and a coolant temperature of  $> 78^{\circ}\text{C}$  ( $172^{\circ}\text{F}$ ) or a bridged temperature switch (7).

Apply about - 400 mbar pressure (BMW service test unit) on electric switching valve (5).

The operation of the electric switching valve (5) and EGR valve (6) will be heard when operating the idle switch (9).



# B.) EGR at Partial Load:


EGR is working at speeds of 1000 to 2800 rpm and a coolant temperature of  $> 78^{\circ}\text{C}$  ( $172^{\circ}\text{F}$ ) (coolant temperature sensor 15).

— Control Unit (8) —

Check with a coolant temperature of  $> 78^{\circ}\text{C}$  ( $172^{\circ}\text{F}$ ) and engine running.

Connect BMW service test unit and check signal output on control unit (8).

There should be battery voltage at speeds of 1000 to 2800 rpm.




Defect:

Check control unit and wire harness with an universal adapter, see Group 13.

## 11-241

— Venting Valve (13) —  
The ALDA regulation will be vented, i.e. altitude compensation will be stopped, with EGR operation.



Apply vacuum (1) from BMW service test unit.  
Pull off hose (2) and blow in air.  
Venting valve (13) is open completely with a pressure of  $-290 \pm 34$  mbar.



### 11 71 501 REPLACING EGR VALVE

Pull off vacuum hose (1).  
Loosen pipe clamp (2).  
Unscrew EGR valve.

Installation:

Replace gasket.  
Coat studs with copper paste "CRC"\*\*\*.

#### Checking Valve Travel:

Test Step	Pressure mbar	Travel mm (inch)
1	$-340 \pm 3$	1 (0.040)
2	$-400 \pm 3$	$4 \pm 0.5$ (0.157 $\pm$ 0.020)
3	$-470 \pm 20$	—
4	$-300 \pm 20$	0

#### Note:


The EGR valve is open in case of acceleration smoke and acceleration hesitation.  
Check installed position of throttle (4) in case of excessive smoke.  
EGR valve must not squeak while opening and closing!

\*\* Source: HWB

# 11 Engine


## BMW 533i, BMW 535i

11 00 006	Diagnosis with BMW service tester .....	see nominal value microfiche
039	Compression of all cylinders – check .....	11- 302
050	Engine – remove and install .....	11- 303
091	Exchange engine – replace .....	11- 306
11 12 000	Cylinder head cover – remove and install .....	11- 306
100	Cylinder head – remove and install .....	11- 307
101	Cylinder head gasket – replace .....	11- 310
561	Valve guide – replace (valve removed) .....	11- 310
595	Valve guide – check for wear .....	11- 311
600	Valve guide – ream out .....	11- 311
607	Valve seats and valves – machine (cylinder head disassembled) .....	11- 311
719	Cylinder head sealing surface – grind (cylinder head disassembled) .....	11- 312
729	Cylinder head – check for cracks in water test (cylinder head disassembled) .....	11- 312
11 13 000	Oil pan – remove and install .....	11- 313
11 14 100	Timing case cover, upper – remove and install/seal .....	11- 314
120	Timing case cover, lower – remove and install/seal .....	11- 315
131	Radial oil seal in upper timing case cover – replace .....	11- 316
141	Radial oil seal in lower timing case cover – replace .....	11- 316
605	Radial oil seal in clutch end cover – replace .....	11- 317
11 21 000	Crankshaft – remove and install .....	11- 318
501	Crankshaft – replace (crankshaft removed) .....	11- 319
531	Crankshaft main bearing shells – replace (engine disassembled) .....	11- 319
571	Pilot bearing in crankshaft – replace .....	11- 320
11 22 000	Flywheel – remove and install .....	11- 321
051	Drive plate for torque converter – replace .....	11- 321
541	Starter gear ring – replace .....	11- 321
11 23 000	Vibration damper with hub – remove and install .....	11- 322
010	Vibration damper – replace .....	11- 322
031	Vibration damper hub – replace .....	11- 322
11 24 521	Connecting rod – replace (piston removed) .....	11- 323
571	Connecting rod bearing shells – replace (engine disassembled) .....	11- 323
11 25 000	Piston – remove and install .....	11- 324
651	Piston rings of one piston – replace (piston removed) .....	11- 325
11 31 000	Camshaft – remove and install (cylinder head removed) .....	11- 326
001	Camshaft – replace (camshaft removed) .....	11- 327
051	Timing chain – replace .....	11- 327
061	Sprocket set – replace (timing chain removed) .....	11- 328
090	Chain tensioner piston – remove and install .....	11- 328
601	Tensioning rail / guide rail – replace (timing chain removed) .....	11- 329
11 33 020	Rocker arm shafts – remove and install .....	11- 330
031	Rocker arms – replace .....	11- 331
11 34 004	Valve clearance – adjust .....	11- 331
509	Valves – check for leaks (camshaft removed) .....	11- 331
550	Valves – remove and install (rocker arm shafts removed) .....	11- 332
	Engine oil circuit .....	11- 333
11 40 000	Engine oil pressure – check .....	11- 334
11 41 000	Oil pump – remove and install .....	11- 334
151	Oil pump drive chain – replace .....	11- 335
11 42 021	Full flow oil filter – replace .....	11- 336
11 43 101	Oil dipstick guide tube – replace .....	11- 337
11 51 000	Water pump – remove and install .....	11- 337
502	Water pump – overhaul (water pump removed) .....	11- 338
11 52 000	Fan – remove and install .....	11- 339
020	Fan clutch – replace .....	11- 339
11 53 000	Coolant thermostat – remove and install .....	11- 339
11 76 010	Catalytic converter – remove and install .....	11- 340
11 78 010	Oxygen sensor – check .....	11- 340
510	Oxygen sensor – replace .....	11- 341



28 11 127


M 30 B 32 = BMW 533 i  
M 30 B 34 = BMW 535 i



28 11 083

## 11 00 039 CHECKING COMPRESSION OF ALL CYLINDERS


Pull off relay (1).




28 11 296

M 30 B 32:

Pull off plug (2) and lift out wires.  
Pull out hoses (3 and 4).  
Unscrew hose clamp (5).  
Unscrew pipe (6).  
Disconnect vent hose (7).  
Unscrew nuts (8) and remove air cleaner with  
air flow sensor.



28 11 297



28 11 337

M 30 B 34:

Pull off plug (2) and lift out wires.  
Loosen hose clamp (3).  
Open clips (4).  
Pull off hose (5).  
Unscrew nuts (6) and remove air cleaner with  
air flow sensor.



28 11 147

Unscrew spark plugs.  
Check compression\*  
Installation:  
Check tightening torque\*\*\*


\* See Specifications  
\*\*\* See Specifications of Gr. 12



## 11-303


### 11 00 050 REMOVING AND INSTALLING ENGINE

Disconnect negative and positive leads on battery.  
Unscrew lead on positive terminal.



28 11 298


Unscrew ground strap for hood.  
Disconnect or remove gas pressure props and insert Special Tool 51 2 110 to prop up the engine hood.  
*Caution!*  
Use locks (1).



51 2 110

28 11 007

Remove transmission — see Gr. 23 or 24.  
Unscrew plug and drain coolant.  
Remove fan 11 52 000.  
Remove radiator 17 11 000.




28 11 004

Unscrew power steering pump.  
Pressure hoses remain connected.  
*Installation:*  
Tighten drive belt and check tightness with Special Tool 11 5 020.



28 11 005




M 88 11 162


Unscrew compressor — see Group 64.  
Refrigerant hoses remain connected.  
*Installation:*

Tighten drive belt and check tightness with Special Tool 11 5 020.


## 11-304




**M 30 B 32:**  
Pull off plug (2) and lift out wires.  
Pull out hoses (3 and 4).  
Unscrew hose clamp (5).  
Unscrew pipe (6).  
Disconnect vent hose (7).  
Unscrew nuts (8) and remove air cleaner with air flow sensor.




Pull off plugs on idle control unit and DME control unit in glove box and pull wires into engine compartment.  
Disconnect ground wire.  
Disconnect plug for oxygen sensor.  
Disconnect wire harness on firewall.




Pull off wire (4).  
Disconnect wires (1 and 15).  
Pull off wire (5) on solenoid.  
Disconnect wire harness.




**M 30 B 34:**  
Disconnect wire harness for oxygen sensor on floor plate.




Pull off plug (2) and lift out wires.  
Loosen hose clamp (3).  
Open clips (4).  
Pull off hose (5).  
Unscrew nuts (6) and remove air cleaner with air flow sensor.



Pull off plug (7) on DME control unit in glove box.  
Disconnect plug (8) and run wire harness into engine compartment.  
*Note:*  
Refer to 13 61 000 or a wiring diagram for the meaning of plug connection (A).




Unscrew ground wire (9).  
Disconnect wire harness.




Pull off wire (4).  
Unscrew wires (1 and 15).  
Disconnect plugs (5).


# 11-305




All Models:  
Remove cover (10) and cap (11).  
Pull off plug (12) and lift out relay.  
Disconnect wire harness (13).




Disconnect accelerator cable (3) and cruise control cable (4).  
*Installation:*  
Adjust accelerator cable, see 35 41 421.  
Adjust cruise control cable, see Group 65.




Unscrew water hose (5) for expansion tank.  
Disconnect fuel return line (6).  
Take wires out of clips.



Disconnect fuel feed line (7) and heater hoses (8 and 9).




Pull off vacuum hose (8).



Disconnect water hose (2) and apply Special Tool 11 0 020.




Unscrew left engine mount.  
*Installation:*  
Tightening torque\*.



Disconnect ground strap.  
Unscrew right engine mount.  
Lift out engine.  
*Installation:*  
Tightening torque\*  
Only M 30 B 32:  
Adjust engine idle speed/CO 13 00 054.

\* See Specifications

## 11-306



### 11 00 091 INSTALLING EXCHANGE ENGINE

Remove engine 11 00 050.  
Exchange Engine Identification on Crankcase:  
1 = Type designation  
2 = "A" for exchange or "N" for new part  
3 = Month of manufacture  
4 = Year of manufacture (1982)  
5 = Year of manufacture (1982)

Stamp the engine number (5).

Drive in the supplied oil dipstick guide tube (see 11 43 101) and transfer parts from the old to the exchange engine.  
Add engine oil\*\*\*.


*Important!*

Remove the pilot bearing in the crankshaft (see 11 21 571), if the car has an automatic transmission.

Install engine.

Only M 30 B 32:

Adjust the engine idle speed and CO level, see Group 13.





### 11 12 000 REMOVING AND INSTALLING CYLINDER HEAD COVER

M 30 B 32:

Pull off plug (2) and lift out wires.  
Pull out hoses (3 and 4).  
Unscrew hose clamp (5).  
Unscrew pipe (6).  
Disconnect vent hose (7).  
Unscrew nuts (8) and remove the air cleaner with the air flow sensor.

M 30 B 34:


Pull off plug (1) and lift out the wires.  
Pull off plug (2) and unscrew nut (3).  
Pull off hoses (4 ... 7).  
Open clips (8).  
Loosen hose clamp (9).  
Unscrew nuts (10) and remove the air cleaner with the air flow sensor.



Pull off hose (7).  
Unscrew ignition lead tube (8).  
Loosen nuts (9).  
Unscrew and remove nuts (10).  
Unscrew clamp (11).

*Installation:*

First tighten nuts (10) and then (9).




Unscrew the cylinder head cover.

*Installation:*

Check gasket, replacing if necessary.  
Make sure that the gasket is positioned correctly and tighten the bolts in order of 1 through 9.  
Mount the clamp with bolt (9).  
Tightening torque\*.

\*\*\* See Service Information of Gr. 00

\* See Specifications




# 11 12 100 REMOVING AND INSTALLING CYLINDER HEAD

Unscrew exhaust pipes on exhaust manifolds and pipe clamp on transmission.

*Installation:*


Check gaskets, replacing if necessary.  
Coat studs with copper paste "CRC"\*\*\*  
Replace self-locking nuts.  
Tightening torque\*.



Unscrew plug and drain coolant.  
Disconnect battery ground lead.

*Installation:*


Fill cooling system with coolant\*\*\* and bleed 17 00 039.  
Replace engine oil\*\*\*.



Disconnect accelerator cable (7), cruise control cable (8) and throttle cable (9).

*Installation:*

Adjust accelerator cable, see 35 41 421.  
Adjust cruise control cable, see Group 65.  
Adjust throttle cable, see Group 24.




Remove cover (10) and cap (11).  
Pull off plug (12) and lift out relay.  
Disconnect wire harness (13).

\* See Specifications

\*\* Source: HWB

\*\*\* See Service Information of Gr. 00



M 30 B 32:

Pull off plug (2) and lift out wires.

Pull out hoses (3 and 4).

Unscrew hose clamp (5).

Unscrew pipe (6).


Disconnect vent hose (7).

Unscrew nuts (8) and remove air cleaner with air flow sensor.


Pull off plug.

Disconnect fuel return line (8) and water hoses (10).







M 30 B 34:  
Pull off plug (1) and lift out wires.  
Pull off plug (2) and unscrew nut (3).  
Pull off hoses (4 ... 7).  
Open clips (8).  
Loosen hose clamp (9).  
Unscrew nuts (10) and remove air cleaner with air flow sensor.




Pull off plug.  
Disconnect fuel return line (11) and coolant hose (12).




All Models:  
Disconnect fuel feed line and heater hoses (8 and 9).  
Disconnect water hose for expansion tank.  
Pull off vacuum hose.



Remove bolt (13).  
Disconnect wires (14 and 15) on alternator and starter.  
Lift out and disconnect plugs (16).




Unscrew ignition lead tube (10) and distributor cap.  
Unscrew diagnosis socket.  
Remove bolts (11).  
Disconnect DME plugs (13 and 17).  
Pull off hose (15).  
Take off cylinder head cover.  
*Installation:*  
Check that gasket seats correctly.




Connect DME plugs for reference mark and speed signals in such a manner, that gray plug (17) is connected with the plug marked with a ring.


## 11-309




Pull off plugs on fuel injectors (1 ... 6), cold start valve (7), idle positioner (8), oil pressure switch (9) and throttle (10). Unscrew clamp (11) and ground lead (12). Disconnect engine wire harness and place aside to the right.



Remove upper timing case cover 11 14 100. Remove chain tensioner piston 11 31 000. Open lockplates. Unscrew sprocket.  
*Note:*  
Lockplates are not used again. Tightening torque\*.






*Installation:*  
Install timing chain that dowel pin (1) is at bottom left when tapped bores are perpendicular to the engine.



Unscrew cylinder head bolts in order of 14 through 1. Insert Special Tools 11 1 063 as shown in picture, to prevent moving or turning of rocker arm shafts. Lift off cylinder head.

\* See Specifications



### *Installation:*

Keep oil out of cavities, since otherwise bolts would not exert sufficient pressure on the cylinder head even though they are tightened to correct torque.  
Engine block could also be cracked.  
Clean cylinder head bolts.  
Lubricate threads and bearing surfaces of bolts heads with a light coat of oil.  
Replace cylinder head gasket – see 11 12 101.

Tighten bolts in order of 1 through 14 to correct torque\* in three steps.

### *Important!*


New cylinder head bolts without collar (better quality):  
First tighten bolts 1 ... 6 with  $60 \pm 2$  Nm ( $43.4 \pm 1.4$  ft. lbs.) – remove Special Tools 11 1 063 – then tighten bolts 7 ... 14 in first step.

Adjust valve clearance -- see 11 34 004.  
Only M 30 B 32:  
Adjust engine idle speed/CO – see Group 13.  
Tighten cylinder head bolts to torque angle\* with Special Tool 11 2 110 regardless of engine temperature in the third step (cylinder head cover removed again after engine was run warm).

\* See Specifications



## 11-310



28 11 129

### 11 12 101 REPLACING CYLINDER HEAD GASKET


Remove cylinder head 11 12 100.  
Clean sealing surfaces on cylinder head and crankcase with a sealant remover\*\* and hard wood scraper.  
Check levelness with a standard steel ruler, grinding cylinder head sealing surface if necessary — see 11 12 719.

#### Installation:

Only use original cylinder head gaskets, of which openings for coolant match precisely.

#### Stamped Identification:

Engine	Code	Bore Dia.
M 30 B 32	3.0/3.0E/3.2E	89 mm (3.504")
M 30 B 34	3.4	92 mm (3.622")



28 11 038


#### Important!

A 0.3 mm (0.012") thicker gasket can be used on a ground cylinder head, to avoid reducing the specified combustion chamber size.  
This gasket may also be used, if poor fuel grade is causing engine knock.

#### Important!

Coat bores with a brush-on universal sealant / Three Bond Silicon 1207\*\* prior to installation of the timing case cover.


\*\* Source: HWB



28 11 108


### 11 12 561 REPLACING VALVE GUIDE — Valve Removed —

Check valve guide wear\* with Special Tool 00 4 510.



28 11 084


Drive out valve guide (cold) with Special Tool 11 1 000.



520 11 141

Check bore in cylinder head with Special Tool 00 4 520.

Ream out bore with a standard reamer and install an oversize\* valve guide, if permissible diameter (A) is exceeded.



28 11 085

#### Heat cylinder head\*

Drive valve guide into cylinder head from the camshaft side with Special Tool 11 1 160. Stepped end of valve guide faces camshaft.

#### Important!


Bore in special tool determines protrusion B\* of valve guide.

Ream out valve guide to specified inside diameter\* with Special Tool 00 4 500.

Machine valve seats — see 11 12 607.


\* See Specifications

# 11-311




## 11 12 595 CHECKING VALVE GUIDE FOR WEAR — Valve Removed —

Check by inserting a new valve, that the end of the valve stem is flush with the valve guide. Attach dial gage and measure tilt play. Max. permissible tilt play\*.




## 11 12 607 MACHINING VALVE SEATS AND VALVES — Valves Removed —

Replace valve, if edge thickness  $A^*$  is less than specified.




Produce valve seat diameter  $M^*$  and valve seat width  $B^*$  by machining correction angles\* after machining the valve seat angle\*. Grind in valves with grinding paste and check for leaks — see 11 34 509.



## 11 12 600 REAMING OUT VALVE GUIDE — Valve Removed —


Ream out valve guide and install a valve with a larger stem diameter " $S^*$ ", if there is excessive play between the valve guide and valve stem — see 11 12 595. The valve seat must also be machined in conjunction with this step — see 11 12 607. Press guide pad (1) on to valve seat and ream out valve guide beginning from the combustion end — turn down reamer once.



\* See Specifications


\* See Specifications

## 11-312




### 11 12 719 GRINDING CYLINDER HEAD SEALING SURFACES —CYL. HEAD DISASSEMBLED—

Not more than 0.3 mm (0.012") may be ground off of cylinder head's original total thickness (A) = 129 ± 0.1 mm (5.079 ± 0.004").  
Install a 0.3 mm (0.012") thicker gasket on a reground cylinder head (also refer to 11 12 101).




Machine upper timing case cover accordingly when grinding the cylinder head.



### 11 12 729 CHECKING CYLINDER HEAD FOR CRACKS IN WATER TEST —CYL. HEAD DISASSEMBLED—

Mount Special Tools 11 1 012 on cylinder head.  
Plug water circuit on cylinder head with Special Tools 11 1 016 and 11 1 017.



Fill cylinder head with compressed air.  
Testing pressure: 4.5 bar (64 psi).  
Place cylinder head in water bath and check for cracks.  
*Note:*  
Relax water bath with a detergent if necessary.


# 11-313

## 11 13 000 REMOVING AND INSTALLING OIL PAN

Take off drive belt for alternator.  
Unscrew alternator and swing aside.  
Unscrew bolt (1).  
Loosen bolts (2 and 3).

*Installation:*

Tighten drive belt and check tightness with Special Tool 11 5 020.




28 11 040

Take off drive belt for power steering pump.  
Unscrew power steering pump and remove bolts (5).

*Installation:*

Do not tension console when installing — use spacers (4), see 32 41 131.  
Tighten drive belt and check tightness with Special Tool 11 5 020.




28 11 159

Unscrew plug and drain coolant partially.

Drain engine oil.

*Installation:*


Add coolant\*\*.  
Add engine oil\*\*.




28 11 004

Unscrew bolts (6) and nut (7).

Remove holder toward inside.




28 11 175



28 11 530

Unscrew cover / reinforcement plate.  
Unscrew and remove oil pan bolts.




28 11 161

Unscrew both engine mounts.

Disconnect wire (8).

*Installation:*

Tightening torque\*.




28 11 021

Disconnect water hose (2) and apply Special Tool 11 0 020.  
Lift engine.


\*\* See Service Information of Gr. 00

\* See Specifications

## 11-313a




Swing out the console and tie down.  
Unscrew remaining oil pan bolts.



Turn connecting rods of cylinders 5 and 6 to the highest position and remove oil pan.




*Installation:*  
Clean sealing surfaces.  
Replace oil pan gasket.  
Coat joint surfaces on timing case cover and



end cover with a brush-on universal sealing compound\*\*


\*\* Source: HWB

# 11-314




## 11 14 100 REMOVING AND INSTALLING/ SEALING UPPER TIMING CASE COVER




Remove cylinder head cover 11 12 000.  
Drain coolant partially.  
*Installation:*  
Bleed cooling system 17 00 039.  
Unscrew cover (1) on thermostat housing.



*Installation:*  
Replace gasket (2) and seal (3).  
Clamp on thermostat faces out.  
From model '86 on:  
new Thermostat, with gasket on cover,  
see 11 53 000.



For DME with Inserted Distributor Arm:  
Take off distributor cap (4).  
Pull off distributor arm (5) and remove  
cover (6).  
*Installation:*  
Check rubber ring (7).



For DME with Screwed Distributor Arm:  
Take off distributor cap (4).  
Unscrew distributor arm (5).  
Unscrew adapter (6) and remove cover (7).  
*Installation:*  
Check rubber ring (8).  
Place seal on screw (6) and install screw with a  
bolt cement\*\*  
Tightening torque\*


Unscrew timing case cover.  
*Installation:*  
Tighten screws (4 and 5) finger tight.  
Now tighten screws (6 ... 11) (8 and 9 are  
longer).  
If applicable, replace damaged cylinder head  
gasket — see 11 12 000.  
Check that radial oil seal fits correctly on  
the distributor rotor adapter (12).

*Important!*  
Coat bores with a brush-on universal sealing  
compound/Three Bond Silicone 1207\*\* prior  
to installation of the timing case cover.

\* See Specifications  
\*\* Source: HWB




## 11-315




### 11 14 120 REMOVING AND INSTALLING/ SEALING LOWER TIMING CASE COVER


Remove fan 11 52 000.  
Remove vibration damper with hub 11 23 000.  
Remove upper timing case cover 11 14 100.  
Remove chain tensioner piston 11 31 090.  
Unscrew water pump pulley.




Unscrew and swing alternator aside.  
Unscrew bolt (1).  
Loosen bolts (2 and 3).



Unscrew power steering pump and remove bolts (5).  
*Installation:*  
Do not tension console while installing – use spacers (4), see 32 41 131.



Swing away and tie down console.  
Unscrew oil pan bolts.




Unscrew bolts on timing case cover and oil pan.  
Only loosen other oil pan bolts.


*Installation:*

Mount TDC transmitter (6) and suspension eye (7).

Check length of bolts.



Pry oil pan gasket off of timing case cover carefully with a knife.  
If oil pan gasket is damaged, remove oil pan 11 13 000.



Take off timing case cover.

*Installation:*

Coat mating surfaces between oil pan and crankcase with a brush-on universal sealing compound/Three Bond Silicone 1207\*\*.


*Important!*

Take-up for tensioner piston must be in oil pocket.

\*\* Source: HWB




## 11-316



730 11 207

### 11 14 131 REPLACING RADIAL OIL SEAL IN UPPER TIMING CASE COVER

Remove upper timing case cover 11 14 100.  
Lift out radial oil seal.  
Drive in new radial oil seal with Special Tools 11 1 280 and 00 5 500.  
Lubricate sealing lip with oil.




730 11 208

If distributor rotor adapter is scored, unscrew bolt (1) and replace adapter.

#### Installation:


Fit bolt (1) with a seal and install bolt with a bolt cement\*\*.  
Tightening torque\*.



730 11 209

#### Installation:


When installing the distributor rotor adapter, make sure that machined surfaces mesh with each other.



30 11 065

### 11 14 141 REPLACING RADIAL OIL SEAL IN LOWER TIMING CASE COVER

Remove vibration damper with hub 11 23 000.  
Lift out radial oil seal with a screwdriver.



28 11 045


Lubricate sealing lip of radial oil seal with oil.  
Press in radial oil seal with Special Tools 11 1 273 and 11 1 272.

\* See Specifications

\*\* Source: HWB


# 11-317

## 11 14 605 REPLACING RADIAL OIL SEAL IN CLUTCH END COVER — Transmission Removed —



Remove flywheel 11 22 000.  
Drain engine oil.  
Loosen oil pan.  
Pry off gasket carefully with a knife in area  
of end cover/oil pan joint.  
Take off end cover.  
Replace gasket.  
If oil pan gasket was damaged, remove oil pan  
11 13 000.  
*Installation:*

Coat end cover/oil pan joint with a brush-on  
universal sealing compound/Three Bond  
Silicone 1207\*\*.  
Use Special Tool 11 2 213 to avoid damaging  
the radial oil seal.



Press in radial oil seal with Special Tools  
11 1 260 and 00 5 500.  
Press in new radial oil seal approx. 1 to 2 mm  
(0.039 to 0.079"), in contradiction to the  
standard radial oil seal which had been pressed  
in flush.  
Lubricate sealing lip with oil.

\*\* Source: HWB

## 11-318




### 11 21 000 REMOVING AND INSTALLING CRANKSHAFT


Remove engine 11 00 050.  
Unscrew right engine mount console.  
Mount crankcase on Special Tool 00 1 490 with help of Special Tool 11 0 120.



Remove clutch 21 21 000.  
Remove cylinder head 11 12 100.  
Remove timing chain 11 31 051.  
Remove oil pump 11 41 000.  
Check axial play\* before removing the crankshaft.  
Check or replace thrust bearing, if max. permissible play is exceeded.




Remove flywheel 11 22 000.  
Unscrew end cover.  
*Installation:*  
Replace gasket.  
Use Special Tool 11 2 213 to avoid damaging the radial oil seal.  
Cut off gasket on oil pan sealing surface.



Mark position of conrod bearing caps to connecting rods and unscrew.

*Installation:*

Replace conrod bearings and measure conrod bearing play – see 11 24 571.



Remove crankshaft bearing caps and lift out crankshaft.

*Installation:*

Bearing cap no. 1 is on sprocket end.  
Also mount oil pump console (2) with thrust bearing cap (4).  
Install bearing shells and check bearing play – see 11 21 531.

*Installation:*


Measure axial play with crankshaft installed – unscrew thrust bearing cap no. 4 again.  
Center thrust bearing by applying knocks from a plastic hammer on the rear and front ends of the crankshaft.

Tighten thrust bearing cap to specifications.  
Measure axial play\*.

If crankcase is replaced, clean oil and water bores thoroughly to remove casting sand.

\* See Specifications


\* See Specifications




# 11 21 501 REPLACING CRANKSHAFT — Crankshaft Removed —

Take out woodruff key (1).  
Pull off sprocket with Special Tool 11 2 000.  
*Installation:*  
Heat sprocket to max. 200° C (390° F) for installation.

28 11 132



28 11 133



630 11 161

## Identification of Crankshafts:

Engine	Throw (mm)	Paint Dot or Code in Center
M 30 B 32	86.0	blue K
M 30 B 34	86.0	blue K

Reground crankshafts are marked with stripes of paint.  
Check machined sizes!

## Connecting Rod Bearing Journal (A):

1 paint stripe	size 1*
2 paint stripes	size 2*
3 paint stripes	size 3*


## Main Bearing Journal (B):

1 paint stripe	size 1*
2 paint stripes	size 2*
3 paint stripes	size 3*

## Important!

Crankshafts are surface treated and may only be reground in the plant.  
Crankshafts are supplied with corresponding bearing shells.  
Install bearing shells and check bearing play, see 11 21 531.  
Install pilot bearing for cars with manual transmission, see 11 21 571.


\* See Specifications




28 11 053

# 11 21 531 REPLACING CRANKSHAFT MAIN BEARING SHELLS — Engine Disassembled —

Bearing shells are marked with color codes.  
Double classification: red / blue.  
Triple classification: yellow / green / white.  
1 = Bearing shell 1 2 3 5 6 7  
2 = Bearing shell 4 (thrust bearing)  
Check machined size (main bearing diameter).



M 88 11 060




M 88 11 061

Bearing shells are installed in crankcase according to color code of crankcase.  
If color code has been washed off of the crankcase, both shells are installed according to the crankshaft color code.  
Install crankshaft.

Bearing shells are installed in bearing caps according to color code of the crankshaft.  
Only Double Classification:  
If red and blue bearing shells are required on one bearing journal, bearing shells must be installed that all shells of same color on all bearing journals are in one plane (down or up).  
Place Plastigage (Type PG-1) on crankshaft wiped clean of oil and bolt down bearing caps to specified torque\*.  
Don't turn the crankshaft.

Source for Plastigage:  
Cartool  
Alfred-Brehm-Str. 5  
D-8070 Ingolstadt



M 88 11 062

Take off bearing caps.  
Read bearing play\* from width of flattened Plastigage with help of supplied scale.  
Correct bearing play by installing new bearing shells, bearing shells of different machined size or with different color codes.

\* See Specifications

## 11 21 571 REPLACING PILOT BEARING IN CRANKSHAFT

Remove clutch disc 21 21 000.

Pull out ball bearing with Special Tool

11 2 010.

Cars with Automatic Transmission:

Pull out adapter sleeve with Special Tool

11 2 020.

Installed Order:


Ball bearing (1), cover (2), felt ring (3) and  
capsule (4).

Insert cover (2) with embossment facing out.


Pack bore in crankshaft with approx. 1 gram  
of lubricating grease.

Drive in pilot bearing with Special Tools


11 2 030 and 00 5 500.



28 11 054




20 11 128




20 11 148

# 11-321



## 11 22 000 REMOVING AND INSTALLING FLYWHEEL


Remove clutch disc 21 21 000.  
Hold flywheel with Special Tool 11 2 160.  
Unscrew bolts and take off flywheel.  
*Installation:*  
Clean tapped bores.  
Insert ring (1).  
Replace and install expansion bolts with Loctite No. 270\*\*.  
Tightening torque\*




Check axial runout\* of flywheel.

Friction surface may be machined to minimum thickness A\*.  
If machining the friction surface reduces distance "h" to zero, the flange surface distance "h" has to be machined.

M 88 11 072




\* See Specifications  
\*\* Source: HWB




## 11 22 051 REPLACING TORQUE CONVERTER DRIVE PLATE

Remove transmission — see Group 24.  
Hold flywheel with Special Tool 11 2 160.  
Unscrew bolts and take off flywheel.  
*Installation:*  
Clean tapped bores.  
Replace and install expansion bolts with Loctite No. 270\*\*.  
Tightening torque\*.




## 11 22 541 REPLACING STARTER GEAR RING

Drill a 6 mm (0.236") dia. hole about 8 mm (0.315") deep below a tooth gap, to make breaking the gear ring easier.



Break gear ring at drilled point with a chisel.




*Installation:*  
Heat new gear ring to 200 ... 230° C (390 ... 445° F).  
Check temperature with a thermochrome pencil.  
Tooth bevelled surface faces engine end.  
Install starter gear ring to fit snugly with a brass mandrel.

\* See Specifications  
\*\* Source: HWB




# 11-322




## 11 23 000 REMOVING AND INSTALLING VIBRATION DAMPER WITH HUB


Unscrew reinforcement plate.



Hold flywheel with Special Tool 11 2 100/  
11 2 120.  
Remove fan 11 52 000.




Take off drive belts on alternator, power steering pump and, if applicable, compressor for air conditioner.  
Unscrew nut (1) with Special Tool 11 2 180.  
*Installation:*  
Tightening torque\*.  
Tighten drive belts and check tightness with Special Tool 11 5 020.




Pull off vibration damper with hub.  
*Important!*  
Make sure key (1) is installed in correct position.  
Check seal, replacing if necessary.  
*Installation:*  
If hub is scored seriously, install seal that its lip makes contact in front of or behind the scored groove.

\* See Specifications



## 11 23 010 REPLACING VIBRATION DAMPER

Take off drive belts on alternator, power steering pump and, if applicable, compressor for air conditioner.  
Unscrew pulley and take off vibration damper.  
*Installation:*  
Centering pin (1) must be in bore of vibration damper.  
Tightening torque\*.  
Tighten drive belts and check tightness with Special Tool 11 5 020.




## 11 23 031 REPLACING HUB FOR VIBRATION DAMPER

Remove vibration damper with hub 11 23 000.  
Unscrew pulley and take off vibration damper.  
*Installation / Arrangement:*  
- Dowel pin (1) with bore (2).  
- Bore (3) with bore (2).  
Tightening torque\*.

\* See Specifications




## 11 24 521 REPLACING CONNECTING RODS — PISTONS REMOVED —



*Important!*  
Only install connecting rods of same weight class in one engine.  
Weight class is stamped in the machined conrod bearing cap surface or indicated by a color code.  
Machining of connecting rods is not approved.


28 11 275



520 11 167

Piston pin must slide through connecting rod bushing under light pressure.  
Install connecting rod bearing shells, see 11 24 571.

## 11 24 571 REPLACING CONNECTING ROD BEARING SHELLS — ENGINE DISASSEMBLED —



Install bearing shells in connecting rods and bearing caps.  
Double Classification:  
Install red or blue conrod bearing shells according to color code on connecting rod.  
*Important!*  
Check machined size (connecting rod bearing diameter).

28 11 304



28 11 306


In BDC position place Plastigage Type PG 1 on crankshaft wiped clean of oil.  
Connecting rods and bearing caps are marked with the same pair number (0 --- 99).  
All pair number codes must be on the same side in one engine.  
Mount connecting rod bearing caps.  
Tightening torque\*.  
Source for Plastigage:  
Cartool  
Alfred-Brehm-Str. 5  
D-8070 Ingolstadt/West Germany

*Important!*  
Don't turn connecting rods or crankshaft.  
Remove bearing caps.  
Check bearing play\* by measuring width of flattened Plastigage with the supplied scale.  
Correct bearing play by installing new bearing shells, bearing shells of different machined size or with different color codes.  
Use new conrod bolts for final installation and mount conrod bearing caps.  
Tightening torque\*.


28 11 061



\* See Specifications



28 11 049



28 11 062



28 11 063



28 11 064

# 11 25 000 REMOVING AND INSTALLING PISTON

Remove engine.  
Take off cylinder head, oil pan and oil pump.  
Remove connecting rod bearing cap and press out piston with connecting rod upwards.  
*Important!*  
Mark installed position of connecting rod to crankshaft, if conrod bearing shells do not have to be replaced.

Remove circlip (1).  
Press out piston pin.  
*Installation:*  
Piston pins and pistons are matched and must not be mixed up.  
Install connecting rod, see 11 24 521.  
Only install pistons of same make and same weight class.  
Weight class is stamped with "+" or "-" in piston crown.


*Important!*  
Check machined size (piston diameter)\*  
Identification:

Engine	E*	Piston Cup (mm)	Dia. (mm)
M 30 B 32	8.8	0 (flat piston)	89
M 30 B 34	8.0	5.3	92

Check piston installed clearance\*.

Engine	Make	Checkpoint A mm (in.)
M 30 B 32	Mahle	26.00 (1.024)
	KS	33.95 (1.337)
M 30 B 34	Mahle	14.00 (0.551)


\* See Specifications  
\*\*\* AUS/CH/S




28 11 507



28 11 508



28 11 065



28 11 066

Set internal calipers to zero on micrometer with the measured piston diameter.

Measure cylinder bore with internal calipers at bottom, center and top in forward and rotational directions.  
Check piston installed clearance\*.

Lubricate piston and piston rings with oil.  
Offset piston ring end gaps by 120°.  
Compress piston rings with Special Tool 11 2 260.

Install piston that arrow faces timing chain.

\* See Specifications

# 11-325


## 11 25 651 REPLACING PISTON RINGS OF ONE PISTON — PISTON REMOVED —

Measure side clearance\* of piston rings.



28 11 135

Remove piston rings and measure end clearance\*.




28 11 521

### Installation:

Install piston rings that word "TOP" faces piston crown.

- 1 Plain compression ring
- 2 Tapered face ring
- 3 Oil scraper ring




28 11 068

\* See Specifications


## 11-326

### 11 31 000 REMOVING AND INSTALLING CAMSHAFT —CYL. HEAD REMOVED—

Mount Special Tool 11 1 060 on Special Tool 00 1 490.  
Mount cylinder head on special tool assembly.




28 11 090



28 11 091



28 11 092



28 11 093

Unscrew oil line.

*Installation:*

Replace seals (1 and 2).

Mount oil line that arrow faces forward.

Tightening torque\*.


Adjust valve clearance of all valves to the greatest value.  
Turn camshaft approx. 15° and mount Special Tool 11 1 061.

Push rocker arms of cylinders 2 and 4 (intake) forward and align special tool in such a manner that tabs rest on eccentrics of rocker arms.


*Important!*

To avoid contact between valve heads, first tighten nuts (3) on exhaust side to stop and then tighten nuts (4) on intake side slightly. Procedures are reversed when taking off the special tool.

\* See Specifications



28 11 094



28 11 095

Unscrew bolts (5).

Pull out camshaft.

*Important!*

If nuts (4) on the intake side have to be retightened, make sure that contact between valve heads is avoided.

*Installation:*

It must be possible to turn the camshaft easily after installation of the guide plate.

Set valves of cylinder no. 6 to overlap before releasing the special tool.

Tapped bore in flange must be aligned with the cast boss.

*Installation:*

Adjust valve clearance 11 34 004.

*Important!*

Install a hexagon nut with a drive pin\*\* as a service sector solution for a camshaft with a damaged drive pin.

\*\* See Service Information of Gr. 11

# 11-327

## 11 31 001 REPLACING CAMSHAFT — Camshaft Removed —

Cars with Plugged Distributor Rotor:  
Unscrew bolt (5) and take off adapter (6).  
*Installation:*  
Make sure milled surfaces engage with each other when installing adapter.  
Place seal on bolt (5) and screw in bolt with Loctite No. 270\*\*.  
Tightening torque\*.

28 11 134

Transfer flange for sprocket.  
Guide plate (1)  
Flange (2)  
Lockplate (3)  
Nut (4)  
Tightening torque\*.

28 11 143

### Camshaft Identification:

Engine	Degrees	Code
M 30 B 32	260	H
	since 5.83:	L
M 30 B 34	260	M

28 11 138

*Installation:*  
Check axial play\* of camshaft, replacing guide plate if necessary.

28 11 110

\* See Specifications  
\*\* Source: HWB


## 11 31 051 REPLACING TIMING CHAIN

Remove upper timing case cover 11 14 100.  
Remove lower timing case cover 11 14 120.  
Set cylinder no. 1 to TDC.  
Take off sprocket.  
*Caution!*  
Don't run engine after removing timing chain.  
Lockplates can be omitted.

*Installation:*  
Install chain that dowel pin (1) is at bottom left when tapped bores are perpendicular to the engine.  
Cylinder no. 1 must be at TDC.  
Tightening torque\*.


Remove timing chain from bottom sprocket and guide it out of guiding rail carefully.  
*Note:*  
Timing chains are pre-stretched.

\* See Specifications




# 11 31 061 REPLACING SPROCKET SET -TIMING CHAIN REMOVED-

Remove oil pan 11 13 000.  
Unscrew sprocket (1) on oil pump.  
Take off chain.  
Lift out woodruff key (2).





Pull off sprocket with Special Tool 11 2 000.  
*Installation:*  
Heat sprocket to max. 200° C (392° F) for installation.  
Tighten oil pump chain, see 11 41 000.




# 11 31 090 REMOVING AND INSTALLING CHAIN TENSIONER PISTON

Unscrew plug (1).  
*Caution!*  
Strong spring force.  
Remove spring and piston.  
*Installation:*  
Replace seal (2).

*Installation:*  
Check spring length\*.  
Tapered end of spring faces plug.



*Checking Piston:*  
Shake to check whether ball (3) moves easily.  
Check operation of valve by blowing in air.  
- in direction A = closed  
- in direction B = open  
If necessary, drive out and clean valve (4) in sleeve (5).  
Are vent slots (6) clogged?



Remove cylinder head cover (see 11 12 000) to bleed the piston.  
Loosen plug (1) and move tensioning rail (6) back and forth until oil escapes past plug (1) and resistance is noticed.  
*Causes for Unusual Chain Noise:*  
a) Piston bled insufficiently  
b) Piston seized  
c) Vent slots clogged  
d) Ball valve in piston not working  
e) Spring force excessive or insufficient


\* See Specifications




## 11-329

### 11 31 601 REPLACING TENSIONING RAIL/GUIDE RAIL —TIMING CHAIN REMOVED—


Unscrew water pump and console.  
*Installation:*  
Replace gasket (1).



Remove lock washers (2 ... 4).




Swing in and remove tensioning rail.



Unscrew bottom bearing bolt (5) and swing  
the guide rail aside.




Pull off guide rail.






## 11 - 330




### 11 33 020 REMOVING AND INSTALLING ROCKER ARM SHAFTS


Remove camshaft 11 31 000.  
Unscrew end cover.  
*Installation:*  
Replace seal (1) and gasket (2).




Push back rocker arms and thrust rings.  
Lift out circlips (5).  
Remove locating pin (4).




Rocker Arm Shafts with Welded Plugs:  
Drive out rocker arm shafts with Special Tool  
11 3 050.  
*Caution!*  
Springs pop out!




Rocker Arm Shafts with Screw-in Plugs:  
Unscrew plugs (3).  
If applicable, hold turning rocker arm shafts  
with locating pin (4).  
*Installation:*  
Screw in plugs (3) with Loctite 270\*\*.



Screw Special Tool 13 3 060 in rocker arm  
shaft.  
Drive out rocker arm shafts with the impact  
sleeve.  
*Caution!*  
Springs pop out!



*Installation:*  
The longer rocker arm shafts belong on the  
sprocket end.  
The openings face bores for cylinder head  
bolts.  
Oil bores face valves.  
Plug threads face out.



*Installed Order:*  
spring (9), washer (8), rocker arm (7), thrust  
ring (6) and circlip (5).  
A = Exhaust side  
E = Intake side  
Align rocker arm shafts that cylinder head bolts  
fit in openings.  
Insert locating pins (4).  
*Important!*  
The new, shorter springs (9) could be installed  
mixed with the conventional long springs (9).

\*\* Source: HWB


# 11-331



## 11 33 031 REPLACING ROCKER ARMS

Remove rocker arms 11 33 020.  
Replace worn rocker arms or rocker arms with loose guides.  
Loose guides will be noticed as excessively loud valve noise.

28 11 102




18 11 103

Transfer screw (1), eccentric (2), washer (3) and nut (4) to new rocker arm.  
Replace worn eccentrics.

*Important!*

Screw and nut have M 6 x 0.75 fine threads.  
Bore faces out and thick side down.  
Bevelled surface of screw faces boss on the rocker arm.




28 11 144

## 11 34 004 ADJUSTING VALVE CLEARANCE

Remove cylinder head cover 11 12 000.  
Crank engine with Special Tool 11 3 110.

Adjusting order is same as the firing order (1 5 3 6 2 4) in compression top dead center (TDC).  
Adjust valve clearance\* between valve and eccentric after loosening nut (1).



28 11 120

Tighten nut (1) with Special Tools 11 1 150 and 00 2 050.  
Tightening torque\*.




28 11 121


## 11 34 509 CHECKING ALL VALVES FOR LEAKS — CAMSHAFT REMOVED —

Spark plugs remain installed.  
Fill combustion chamber with gasoline outdoors or indoors in compliance with safety regulations.  
Check valve seats and valves, if gasoline runs past the valve heads.  
Remove and install valves 11 34 550.  
Machine valve seats 11 12 607.

\* See Specifications



28 11 122




**11 34 550 REMOVING AND INSTALLING VALVES**  
— Rocker Arm Shafts Removed —

Place Special Tool 11 1 064 (tray) in Special Tool 11 1 060.




Press down valve springs with Special Tool 11 1 060 and remove valve collets.




Take off upper spring retainer, valve springs and lower spring retainer.  
Take tray out of special tool and pull out valve.

**Installation:**

Only install valve springs with same color code, wire gage size and length.  
Lubricate valve guide and valve stem with oil.




Pull off valve stem seal with Special Tool 11 1 250.




Insert valve.  
Use Special Tool 11 1 340 to avoid damaging the valve stem seal.  
Lubricate valve stem seal (1) with oil and install.

Source for Special Tool Sleeves:  
Cartool  
Alfred-Brehm-Str. 5  
D-8070 Ingolstadt




Press on valve stem seal against stop with Special Tool 11 1 090 for diameter A =  $14 \pm 0.2$  mm ( $0.551 \pm 0.008$ ") or Special Tool 11 1 070 for diameter A =  $14.3 \pm 0.2$  mm ( $0.563 \pm 0.008$ ").



The new, improved valve stem seals (internal grooves) are pressed on by hand with help of Special Tool 11 1 200.  
Special Tool 11 1 200 has two diameters for 7 mm ( $0.276$ ")/8 mm ( $0.315$ ") valve stem seals.

# 11-333

## ENGINE OIL CIRCUIT



- 1 Oil pan
- 2 Intake with filter screen
- 3 Oil pump
- 3a Pressure relief valve
- 4 Oil filter
- 4a Safety valve (oil filter)
- 5 Main distribution bore
- 6 Oil bore in cylinder head, front

- 7 Oil bore in cylinder head, rear
- 8 Crankshaft bearing
- 9 Connecting rod bearing
- 10 Hollow rocker arm shaft, front
- 11 Hollow rocker arm shaft, rear
- 12 Transmitter for oil pressure indicator lamp
- 13 Front camshaft bearing
- 14 Camshaft bearing

- 15 Camshaft bearing
- 16 Rear camshaft bearing
- 17 Rocker arm bearing (exhaust)
- 18 Spray jets for cam lubrication
- 19 Rocker arm bearing (intake)
- 20 Valve guide
- 21 Bore in distributor drive
- 21a Spray oil for distributor drive


- 22 Overflow from cylinder head
- 23 Oil pocket for chain lubrication
- 24 Spray oil for piston pin
- 25 Oil drain bore
- 26 Oil dipstick
- 27 Oil filler neck
- 28 Oil drain plug

## 11-334

### 11 40 000 CHECKING ENGINE OIL PRESSURE

Pull off wires on oil pressure switch.  
Unscrew oil pressure switch (1).  
*Installation:*  
Check gasket (2), replacing if necessary.

Screw in Special Tool 11 4 050.  
Connect hose 13 3 063 in conjunction with pressure tester 13 3 061.  
Check oil pressure\*.



\* See Specifications

### 11 41 000 REMOVING AND INSTALLING OIL PUMP

Pull out oil dipstick.  
Remove oil pan 11 13 000.  
Unscrew nut (1) and take off sprocket.  
Unscrew bolts (2).

Unscrew holder (3) and remove oil pump.  
*Installation:*  
Mount holder without tension.


*Installation:*  
Push on sprocket after mounting oil pump.  
Tightening torque\* for nut.

*Installation / Chain Tightness:*  
Adjust chain tightness with shims (4 and 5) that chain will give at center under light thumb pressure.  
Shims (4 and 5) must have the same thickness.




\* See Specifications

## 11-335



M88 11020

**Testing and Servicing:**  
Check whether oil pump runs easily by turning the drive shaft.




M88 11021

**Disassemble oil pump and clean the oil filter screen (5).**



M88 11022


**Check oil pump for wear.**  
– Scoring in body  
– Wear on rotors



M88 11023

The pressure relief valve is installed in the main bore and regulates the engine oil pressure\*, see 11 40 000.  
Check whether piston (6) moves easily.  
Check length of spring (7) = 68 mm (2.677").

\* See Specifications




M88 11024

The 8 bar (112 psi) pressure relief valve regulates the oil pressure in front of the oil filter and prevents oil filter leakage.  
Check piston seat (8).  
Check length of spring (9) =  $44 \pm 0.4$  mm (1.732  $\pm$  0.016").



M88 11025

**Installation:**  
Press in spring (9) and washer (10) with a wrench socket and install circlip (11).



M88 11063

### 11 41 151 REPLACING OIL PUMP DRIVE CHAIN

Remove oil pan 11 13 000.  
Remove timing chain 11 31 051.  
Unscrew nut (1) and take off sprocket.

**Installation:**  
Adjust chain tightness, see 11 41 000.  
Chain with a green color code is longer than chains with a red color code.  
Tightening torque\*.

\* See Specifications




# 11-336

## 11 42 021 REPLACING FULL FLOW OIL FILTER

Unscrew oil drain plug (1) and drain oil.  
Unscrew bolt (2).  
Replace oil filter (5).

### Installation:

Check seals (3 and 4), replacing if necessary.  
Mount oil filter housing that arrow faces forward (FRONT).  
Tightening torque\*,  
Add engine oil\*\*\*.





M88 11 026




M88 11 027

- 1 Feed from oil pump
- 2 Return to main oil bore
- 3 Bypass valve  
— opening pressure =  $2.5 \pm 0.25$  bar ( $35 \pm 3$  psi)
- 4 Return flow inhibiting valve  
— opening pressure =  $0.1 \pm 0.05$  bar ( $1.4 \pm 0.7$  psi)
- 5 Thermostatic activator for switching oil cooler
- 6 Oil cooler



28 11 236


- ➔ Unfiltered oil
- ➔ Filtered oil



28 11 237

\* See Specifications  
\*\*\* See Service Information of Gr. 11






# 11 43 101 REPLACING GUIDE TUBE FOR OIL DIPSTICK

Transfer clamp (1).  
Install guide tube with Loctite No. 270\*\* and drive in against stop.

*Important!*

Eyelet grip of oil dipstick must always face left when looking forward in car to check the oil level.

Non-conformance could cause incorrect readings, i.e. engine oil volume would not be as specified\*.




# 11 51 000 REMOVING AND INSTALLING WATER PUMP


Remove fan 11 52 000.  
Take off drive belt and unscrew pulley.

*Installation:*

Tighten drive belt and check tightness with Special Tool 11 5 020.



Unscrew suspension eye (1) and disconnect water hose (2).



Unscrew water pump.

*Installation:*

Replace gasket.


\* See Specifications

\*\* Source: HWB

# 11-338


## 11 51 502 OVERHAULING WATER PUMP

Check dimensions after assembling!



630 11 246

Pull off hub with Special Tool 00 8 500.  
Lift out circlip (1).




630 11 247

Press out water pump bearing.

*Installation:*

Press in water pump bearing against stop.  
Press on impeller.





630 11 248

Drive out seal (1).

*Installation:*

Press in seal (1) with Special Tool 00 5 500.






## 11 52 000 REMOVING AND INSTALLING FAN

Hold pulley with Special Tool 11 5 030 and unscrew coupling nut (1).

*Important!*

Left-hand threads — nut turned clockwise to unscrew.

Tightening torque\*.




## 11 53 000 REMOVING AND INSTALLING COOLANT THERMOSTAT

Drain coolant partially.

Unscrew cover (1).

*Installation:*

Bleed cooling system 17 00 039.




Remove thermostat.

Replace gasket (2) and seal (3).

*Installation:*


Clamp on thermostat faces out.



From model '86 on — Letter "A" cast in housing:

Fit new thermostat, no. 1 713 040 with

gasket (4) on cover.



## 11 52 020 REPLACING FAN CLUTCH

Remove fan 11 52 000.

Replace fan clutch, if

- a) hub has seized (fan of stopped engine cannot be turned or difficult to turn),
- b) fan clutch has axial and radial play or is losing oil.

Check switching points\* with a Vibrocard\*\*\*.

Unscrew fan mounting bolts and take off fan clutch.



Check Thermostat:


Check whether opening temperature agrees with specifications.

Check opening temperature by placing thermostat in hot water and compare with stamped opening temperature.

\* See Specifications

\*\*\* See Workshop Equipment Catalog

## 11-340



### 11 76 010 REMOVING AND INSTALLING CATALYTIC CONVERTER

Remove the exhaust assembly, see 18 00 020.  
Unscrew the triangular flanges.  
Pull off the catalytic converter.


*Installation:*

Replace the gasket.

Inspect the catalytic converter for damage or cracks on the outside and loose parts on the inside.

*Important!*

Replace the oxygen sensor and catalytic converter, if the car had been operated with leaded gasoline.




### 11 78 010 CHECKING FUNCTION OF OXYGEN SENSOR

Unscrew plug (1).


Screw in Special Tool 13 0 100 and attach the Special Tool 13 0 090.

Connect the BMW service tester.



Measure the CO level.

Specifications: 0.2 to 1.2 % by volume.  
Refer to 13 00 054 for other information.



Pull off vacuum hose (1) on the pressure regulator and plug.

The CO level will rise briefly and is immediately regulated back to the original value = the oxygen sensor is working.

If Not:

Check the power supply to the oxygen sensor from the relay according to the wiring diagram.

See Group 13 for additional information.

# 11-341

## 11 78 510 REPLACING OXYGEN SENSOR

- Do not clean oxygen sensors or let them come in contact with lubricants.
- Only coat the threads with "Anti-Seize"\*\*\*.
- Cover oxygen sensors when undercoating the car.

### M 30 B 32:



The oxygen sensor has to be replaced at intervals of 30,000 miles. However, the "O<sub>2</sub> SENSOR" sign will only light up after the first 30,000 miles. Disconnect plugs.

Pull off plate (2).

Unscrew oxygen sensor (3).

Installation:


Coat the threads with "Anti-Seize"\*\*\*.



28 11 524



28 11 526




28 11 527

Lift out the check control.

Remove the lamp for the "O<sub>2</sub> SENSOR" sign.

\*\*\* Source: HWB, No. 81 22 9 400 088



28 11 320



28 11 321

### M 30 B 34:

The heated oxygen sensor has to be replaced at intervals of 50,000 miles - there is no sign or indicator lamp.

Unscrew plate (1) and disconnect plug (2).

Unscrew oxygen sensor (3).

Installation:

Coat the threads with "Anti-Seize"\*\*\*.

\*\*\* Source: HWB, No. 81 22 9 400 088

## 12 Engine electrical equipment

	Information for working on ignition systems .....	12-	0
	Survey of engine electrical equipment – 528 e .....	12-	1
	Survey of engine electrical equipment – 535 i .....	12-	3
	Survey of engine electrical equipment – 524 td .....	12-	5
	Diagnosis plug connections .....	12-	7
	Engine wire harness plug connections .....	12-	8
12 11 031	TDC position sensor – replace/check .....	12-	9
091	Distributor cap – replace/check .....	12-	10
111	Distributor rotor – replace .....	12-	11
12 12 072	Spark plug connector – replace .....	12-	12
12 13 009	Ignition coil – check .....	12-	13
011	Ignition coil – replace .....	12-	13
12 14 160	Speed sensor – replace/check (524 td) .....	12-	14
510	Reference mark and speed sensors – replace/check .....	12-	15
515	Reference mark and speed sensors – replace/check .....	12-	15
	DME troubleshooting .....	12-	20
	DME troubleshooting test points .....	12	21
12 21 . . .	Preheating system – troubleshoot .....	12-	30
. . .	Preheating system – check .....	12-	31
12 23 000	Heater plugs – check .....	12-	32
505	Heater plugs – replace .....	12-	32
12 62 . . .	Temperature sensor / preheating time – check .....	12-	33
. . .	Temperature sensor – coolant (VP-20) – check .....	12-	33
12 31 . . .	Alternator – troubleshoot .....	12-	40
009	Alternator and voltage regulator – check .....	12-	41
020	Alternator – remove and install (BMW 528 e / 533 i / 535 i) .....	12-	42
020	Alternator – remove and install (BMW 524 td) .....	12-	43
299	Alternator drive belt – check and tighten .....	12-	43
201	Carbon brushes – replace / slip rings – grind .....	12-	44
513	Alternator – disassemble and assemble .....	12-	44
581	Ball bearing – replace .....	12-	45
691	Diode plate – replace .....	12-	45
. . .	Alternator components – inspect .....	12-	46
12 32 000	Voltage regulator – remove and install/replace .....	12-	47
12 41 . . .	Starter – troubleshoot .....	12-	50
020	Starter – remove and install .....	12-	51
041	Solenoid switch – replace .....	12-	53
. . .	Starter components – inspect .....	12-	53
103	Starter – disassemble and assemble .....	12-	54
551	Carbon brushes – replace .....	12-	57
12 63 . . .	Speed signal – check .....	12-	60
12 64 . . .	Fuel heating – check .....	12-	61
12 64 005	Fuel heating element – replace .....	12-	61
12 81 . . .	Coolant heater – replace/check .....	12-	62


## 12-0

### INSTRUCTIONS FOR WORKING ON TRANSISTORIZED COIL-TYPE IGNITION (TCI) AND DIGITAL MOTOR ELECTRONICS (DME)

- o Always disconnect battery or interrupt power supply to ignition control unit and ignition coil when working on the electrical system (charging battery or welding, etc.) – dangerous primary and secondary voltage as well as danger of destroying the ignition system.
- o Never start the engine after removal of distributor cap and/or disconnection of wire on ignition coil term. 4 – pull off plug on ignition control unit.
- o Never disconnect the battery or leads on the alternator and starter while engine is running.
- o Only install specified original BMW parts.
- o Never connect a shielded capacitor or test lamp on term. 1 of the ignition coil.
- o Never connect wire of ignition coil term. 1 on ground or B +. Consequently the ignition coil term. 1 wire must not be used to prevent engine starting when service installing a burglar alarm system. In this case, for example, the wire on term. 50 of the starter could be used.
- o When checking the compression, pull off plug on control unit for TCI or master relay for fuel injection (relay no. 2) for DME.
- o The secondary side (high voltage side) of the ignition system must be shielded with at least 4 k-ohms, whereby the original distributor rotor with 1 k-ohm shielded resistor must be installed. Do not use a 5 k-ohm distributor rotor for the shielding of radio and/or communication equipment!



## 12-1




### SURVEY OF ENGINE ELECTRICAL EQUIPMENT FOR BMW 528 e


- 1 DME control unit
- 2 Idle control unit (in glove box)
- 3 Plug for transmission — disconnected for cars with automatic transm. (mixture leaned)
- 4 Plug for car electrical system




Air flow sensor  
(air temperature sensor is integrated in air flow sensor)




Throttle switch



Speed transmitter (1) and reference mark transmitter (2)




Temperature time switch (1)  
Coolant temperature sensor (2)  
Temperature switch (3)



Electric fuel pump




Fuel injectors



Cold start valve


## 12-2



Idle valve  
(control element)




Oxygen sensor




Relays and fuses  
1 Fuel pump relay  
2 Injection system relay  
3 Fuse for fuel pump



Ignition coil




High voltage distributor




# **SURVEY OF ENGINE ELECTRICAL EQUIPMENT FOR BMW 535 i**


DME control unit in glove box  
 Plug Connections:  
 6-pin — car electric system  
 2-pin — transmission  
 (not used for automatics)  
 1-pin — fuel injection  
 (not used for automatics)



Master relay for DME (relay 2), fuel pump relay (relay 1).  
 Oxygen sensor relay (3).  
 Extra fan relay — stage I / stage II.  
 Check control relay (4) for low beams.




Plug connections for reference mark sensor (B) and speed sensor (D).  
 Ground point for DME.




Ignition coil (1).  
 High voltage distributor (2).  
 Charcoal canister (3).

## **12-3**




Temperature time switch (1), temperature gage (2), coolant temperature sensor (3)




Diagnosis plug

## 12-5



**SURVEY OF ENGINE ELECTRICAL EQUIPMENT FOR BMW 524 td**


Control unit for VP-20 fuel injection in glove box




Plug connections for timing valve (3), initial injection jet (2) and speed sensor (1)




Relay for fuel transfer pump (4), VP-20 injection control (5), fuel heating (6) and heating time control (7)




Relay for extra fan (stage I), extra fan (stage II) and low beam check control (8)




Plug connection for coolant level sensor (9), temperature switch for fuel heating (10), connection for heating adapter (11)



Ground point for engine electrical system



VP-20 coolant temperature sensor (12), temperature gage/heating time sensor (13)



Plug for coolant heater

# DIAGNOSIS PLUG CONNECTIONS



## BMW 528 e / 533 i / 535 i

No. Term. Application

1	31	Ground
2	—	—
3	—	—
4	FT	Temperature gage
5	L	Oxygen sensor signal
6	A	Airbag
7	SI	Service indicator
8	P+	Position transmitter
9	S	Shielding
10	P—	Position transmitter
11	50	Starter
12	61	Alternator
13	1	Ignition signal
14	30	Battery +
15	15	Ignition supply

Connection Deviations for BMW 524 td, as  
Compared with Above Models

2	SB+	Fuel injector - initial injection sensor
3	SB—	Fuel injector - initial injection sensor
13	TD	Speed signal





## 12-8

### CONNECTION PLAN FOR ENGINE WIRE HARNESS PLUG



BMW 528 e, 533 i, 535 i

No. Term. Description

1	D+	Alternator charge indicator
2	sta	Oil level-static
3	—	—
4	FT	Coolant temperature gage
5	—	—
6	15s	Power supply with ignition turned on - fuse protected
7	EP	Electric fuel pump
8	50	Voltage while starting
9	—	—
10	A	Diagnosis lead for airbag
11	—	—
12	15u	Power supply with ignition turned on - no fuse protection
13	dyn	Oil level dynamic
14	Öl	Oil pressure
15	SI	Service indicator
16	—	—
17	—	—



28 12 127



21 12 075

BMW 524 td

No. Term. Description


1	D+	Alternator charge indicator
2	sta	Oil level-static
3	EP	Electric fuel pump
4	FT	Coolant temperature gage
5	TD	Speed signal
6	15s	Power supply with ignition turned on - fuse protected
7	15u	Power supply with ignition turned on - no fuse protection
8	50	Voltage while starting
9	L1	Heating time indicator
10	A	Diagnosis lead for airbag
11	L2	Readiness to start after heating
12	Dia	Diagnosis lead for injection-system
13	dyn	Oil level - dynamic
14	Öl	Oil pressure
15	SI	Service indicator
16	W	Water - In - Fuel indicator
17	—	—

# 12 11 031 REPLACING / CHECKING TDC POSITION TRANSMITTER

BMW 528 e / 533 i / 535 i:

Unlock clips and pull diagnosis plug out of holder.

Remove protective hose.



28 12 030

Press plug receptacles out of chambers 8, 9 and 10 with special tool\*\*.




28 12 031

Installation:

Connect new position transmitter as shown.

Number	Wire Color
8 (P+)	yellow
9 (S)	shielding
10 (P-)	black



28 12 125


BMW 528 e:

Press position transmitter out of holder.

Installation:


Mount wire.

Provide spacing (A) of 0.2 to 2.0 mm (0.008 to 0.079").



28 12 056

\*\* Source: HWB (= Division of BMW)



730 12 033

BMW 533 i / 535 i:

Unscrew position transmitter.

Installation:

Mount wire.

Provide distance of 0.2 to 2.0 mm (0.008 to 0.079") to vibration damper.




28 12 031

BMW 524 td:

Take diagnosis socket out of holder.

Press out plug receptacles 8, 9 and 10 with special tool\*\*.

Number	Wire Color
8	yellow
9	shielding
10	black



M 21 12 115

Unscrew and pull out position transmitter.

Installation:


Mount wire.

Coat seal with Molykote paste.

Keep grease off of face!

Checking:

Measure resistance\* of transmitter on diagnosis socket terminals 8 and 10.



28 12 125

\* See Specifications

\*\* Source: HWB (= Division of BMW)



## 12-10

### 12 11 091 REPLACING / CHECKING DISTRIBUTOR CAP

#### Important!


Refer to working instructions on page 12-0.

BMW 528 e:


Take off protective cap.

Installation:


Engage protective cap in holder correctly.




28 12 009



733 12 046



733 12 047



730 12 023

Pull out shielded connectors.

Installation:

Check firing order.

Unscrew screws and take off distributor cap.

Caution!

Protect hands — danger of injury on sharp cooling fins.

Installation:

Check seal (6), replacing if necessary.

Transfer protective caps (1 and 2).

Arrangement:

1 Protective cap


2 Protective cap

3 Distributor cap

4 Distributor rotor

5 Protective cap (inside)


6 Seal




630 17 010



630 12 139



630 12 132



630 12 134

BMW 533 i / 535 i:

Unscrew fan — left-hand threads.

Unscrew and lift out fan cowl.

Take off or unscrew protective cap.  
Unscrew distributor cap screws.

Installation:

Screw in all screws finger tight and then attach holder for water hose.


Checking:

Check inside and connection cover for hairline cracks and traces of burning.


## 12 11 111 REPLACING DISTRIBUTOR ROTOR

### Caution!

Refer to page 12 - 0 for instructions for working on ignition system.  
Remove distributor cap 12 11 091.



630 12 135




730 12 024

Loosen distributor rotor by pressing in both directions (radial) and pull off.

### Installation:


Check seal (1), replacing if necessary.



28 12 096

Since 1984 Models:

The distributor rotor of these models is bolted.



630 12 136

### Checking:

Measure the resistance\*.


Check casting compound (brittleness, burnt).

\* See Specifications

## 12-12


### 12 12 072 REPLACING ONE SPARK PLUG CONNECTOR

(non-disconnectable version – 30 kV system)  
Cut off ignition lead as shown.




28 12 106

Strip ignition lead end by 6 mm with a stripping pliers (1.5 mm wire cross section size).




23 12 031

Place connector on ignition lead and insert in Special Tool 12 1 091 as shown. Move clamping jaws together by turning screw against stop.



23 12 032

After squeezing, release jaws and take out the ignition lead. Perform tear-out test by hand (tearing-out force: = 200 N / 44 lbs.).




23 12 033

Spray a thin coat of lubricant 12 1 098 on guiding sleeve of Special Tool 12 1 092.



23 12 034

Unscrew screw (1). Slide in ignition lead against stop (see picture), follow with pliers and slide in ignition lead further until connector is heard to engage.



28 12 109


Tighten screw (1) enough, that the pliers can be pulled back.

*Caution!*

Opening the pliers too much could cause the plug receptacle to break. The plug receptacle is shown cut open for better illustration.


*Note:*

The required special tools 12 1 091/092/098 are also available as a complete set 12 1 090.




28 12 110


## 12 13 009 CHECKING IGNITION COIL



Connect BMW service test unit.  
Carry out engine test step 09.  
Observe oscilloscope — ignition voltage and  
ignition voltage deviation must agree with  
nominal values\*\*.



Multimeter Test (M 06):  
Measure resistance\* of primary coil (term. 1/  
15) and secondary coil (term. 15/4).




Check for hairline cracks and signs of burning.  
Check plug (S) for tight fit — if pressed out,  
replace ignition coil.

## 12 13 011 REPLACING IGNITION COIL

*Caution!*

Always turn off ignition before working on the  
ignition system — dangerous high voltage!  
Refer to page 12 - 0 for instructions for working  
on ignition system.



Pull off protective cap and ignition lead (term.  
4).  
Unscrew connections (term. 1 and 15).  
Unscrew holder and take off ignition coil.

*Installation:*

Check new ignition coil for correct code number\*  
and color label\*.


\* See Specifications

\*\* See nominal value microfiche

\* See Specifications


# 12 14 160 REPLACING/CHECKING SPEED SENSOR

BMW 524 td:  
Disconnect plug (1).




21 12 017

Unscrew holder from below.




21 12 026

Turn speed sensor up, unscrew socket head screw and pull out speed sensor.





21 12 025

**Installation:**  
Coat seal with Molykote paste — keep grease off of face!  
Adjust speed sensor distance \*).



M 21 12 111

\*) See Specifications




28 12 069

**Checking:**  
Measure coil resistance\* and insulation resistance\*.  
See engine electrical equipment wiring diagram for wire routing and connection.  
+ and - = coil.  
S = shielding.  
Check alternating current voltage\* (M 02) with plug disconnected and engine running at idle speed, adjusting speed sensor distance\* if necessary.


## 12 14 ... ADJUSTING SPEED SENSOR

Unscrew fan cowl and fan (left-hand threads) — see 11 52 000.  
Turn crankshaft up to 40 mm (1.575") after TDC — measured on vibration damper.




21 13 195

Unscrew brake fluid tank — hoses remain connected.  
Loosen speed sensor and check whether pin is exactly in front of the speed sensor, correcting the flywheel position if necessary.  
The sensor may be pushed in by about 2 mm (0.079").



M 21 12 110

Push in speed sensor against stop and measure distance (A).  
Pull out speed sensor until distance (B) is reached.  
A = Speed sensor rests on pin  
B = Distance A + speed sensor distance\*



M 21 12 111

\* See Specifications

## 12-15

### 12 14 510/ REPLACING/CHECKING SPEED 515 AND REFERENCE MARK SENSORS

BMW 528 e / 533 i / 535 i  
Unscrew shield.




733 12 020

Unscrew screws of speed and reference mark sensors (D and B) and pull out sensors.

*Installation:*

Mark new reference mark sensor (B) with a piece of tape.



630-12-195

Pull off plugs on speed sensor (D) and reference mark sensor (B).

Press plug of sensor lead out of holder.

*Installation:*

Plug marked with tape belongs to gray plug.



733 12 010


Pull off protective sleeve (1).

Lift out clip (2).


*Installation:*

Coat seals with Molykote paste.

Keep grease and dirt off of face surface on sensors.



733 12 054



733 12 010


Testing:

Disconnect plug.  
Connect BMW service test unit to operating instructions (M 06/22/23).  
Use universal test leads.


B = Reference mark sensor

D = Speed sensor


Measure resistance\* of sensor coil (M 06) on + and - of plug.



28 12 089



Connect oscilloscope (M 22/23) on + and connections of speed sensor.  
Turn engine with the starter.  
Signal shown in the figure should be displayed.  
Only the shape is important when evaluating the signal — not the amplitude height.



Check reference mark sensor in same manner.  
If oscillograph deviates, remove sensor and check for dirt (grease, burrs, dust), cleaning if necessary.  
Check reference mark, replacing pin for flywheel if necessary.

\* See Specifications



— See application information on next page.

Testing Requirements:

Engine in perfect running condition (timing, compression, oil carbon deposits, etc.).

Starting system in perfect condition (battery voltage, starter, ignition lock, etc.).

Correct fuel in tank (octane rating, leaded/unleaded, dirt, etc.).  
Connections, plugs and ground points according to wiring diagram.

Refer to "Troubleshooting Fuel Injection" in Group 13 for other test positions.

[illegible]



## TEST POSITIONS TO TROUBLESHOOT DIGITAL MOTOR ELECTRONICS

## Application Information:

This survey can be applied for troubleshooting and consequently finding sources of defect more quickly.

The checked causes of malfunction might not always be sufficient to eliminate a defect, so that under certain circumstances additional tests could be necessary.




Testing instructions refer to the BMW SERVICE TEST, e.g. engine test/test step 05 (P 05) or a multimeter function (M). See operating instructions for connections.

Test 1 – SPEED AND REFERENCE MARK SENSORS

Check wires for tight fit and damage.  
Check connections and arrangement of plug connections.  
Reference mark sensor (B) is marked with a ring – see 12 14 510 / 515.

Turn engine with the starter. Check resistance (M 06) and oscillograph (M 22/23) on disconnected pulse sensor plug with BMW service test unit, see 12 14 510.

Check wires leading to DME control unit:  
Take off trim panel.  
Pull off plug on control unit and connect on universal adapter\*\* with (35-pin) test lead – see illustration.  
Check power flow (M 06) in wires on specified pins\*\*\*.



\* See Specifications

\*\* Source: HWB




\*\*\* See engine wiring diagram

## Test 2 – IGNITION COIL

Check wires for tight fit.  
Check connection plate and ignition lead contacts for traces of burning, cracks and oxidation.  
Check code number\* of ignition coil – see 12 13 009.

Check resistance\* (M 06) and inductivity\* (M 07) of primary and secondary coils – see 12 13 009.

12-22



## Test 3 – SPARK PLUGS

Check spark plugs for tight fit and leaks.  
Check insulator for signs of leakage current.

Check spark plug type\* and electrode gap\*.  
Check resistance\*.




\* See Specifications

Test 4 – HIGH VOLTAGE DISTRIBUTOR

Check distributor cap and rotor for correct fit, damage and hairline cracks as well as signs of burning.  
Check wire connections for oxidation and good contact – see 12 11 091 / 111.

Check resistance\* (M 06) from distributor peak to corresponding contact in distributor cap.  
Resistance must be approximately 0 ohm.

Check resistance\* (M 06) of distributor rotor.

Test 5 – IGNITION LEADS AND LEAD CONNECTORS

Check spark plug connectors and shielded connectors for damage, tightness and good contact.  
Bend ignition leads in a tight radius and check for cracks.

Check resistance\* (M 06) of spark plug connectors and ignition leads.

\* See Specifications

Test 6 – DME CONTROL UNIT AND POWER SUPPLY

Check code number\* and manufacturing date\* of DME control unit – see Group 13.

Check power supply\*\*:

Pull off plug on control unit and connect universal adapter\*\*\* with (35-pin) test lead.

Car wire harness plugs remain connected.

Turn on ignition.

Check voltage on pins\*\*, e.g. on connections 17 (–) and 35 (+).

If test results indicate the necessity to replace the control unit, first make the periphery test with an universal adapter\*\*\*.

Pull off relay 2 and bridge terminals 87 and 30 with a piece of wire.



This supplies power to the control unit.

Check activation\*\* for relay 2:

Turn on ignition.

Terminals 85 (–) and 86 (+) should have voltage (approx. 12 V).

If necessary, check ground point and plug connection (near DME control unit) – see figure.

Test 6a – IGNITION TIMING

Check ignition - timing <sup>1)</sup> (P 06)

no

Check code number\* and manufacturing date – see Group 13

Replace DME control-unit.

\* See Specifications

\*\* See engine wiring diagram

\*\*\* Source: HWB (= Division of BMW)

<sup>1)</sup> See nominal value microfiche

Test 17/18 – EXHAUST SYSTEM / CATALYTIC CONVERTER




Check exhaust system and catalytic converter for damage, tight fit and leaks – see Group 18.

Test 19 – CRANKCASE VENT/AIR HOSES

Check hoses for crankcase vent and oil dipstick for tight fit and leaks.

Test 20 – COOLING SYSTEM

Check coolant level and concentration\*\*.  
If necessary, fill and bleed cooling system – see Group 17.



\*\* See Service Information of Gr. 00

## TROUBLESHOOTING HEATING SYSTEM

## Testing Requirements:

- Charged battery.
- Connections and wires on indicator lamps, heating time control unit and heater plugs correct.

Ignition key turned to "DRIVE" before each test.

Yellow and green indicator lamps do not come on


Check fuse (S) on heating time control unit.

Check light bulb(s) in instrument carrier, replacing if necessary — see 62 99 . . .

Pull off plug (1) on heating time control unit. Connect plug receptacle LA 1 (for yellow lamp) and LA 2 (for green lamp) with ground — indicator lamps must come on. If necessary, check power supply for indicator lamps.

Yellow indicator lamp does not come on  
— coolant temp.  $< 60^{\circ}\text{C}$  ( $140^{\circ}\text{F}$ )

Check coolant temperature sensor, replacing if necessary — see 12 62 . . .



Green indicator lamp does not come on

Cold engine hard to start.  
One or more heater plugs defective.

Pull off plug on control unit (2). Connect BMW service test unit (M 03) and supply battery voltage to connections G 1 through G 6 5 seconds each and measure power consumption\* of heater plugs. Replace defective heater plugs — see 12 23 . . .


Yellow indicator lamp flashes

Pull off plug on heating time control unit (2).


Check heater plugs, replacing if necessary — see 12 23 . . .  
Replace control unit.

\* See Specifications


## 12 21 ... CHECKING FUNCTION OF HEATING SYSTEM




**Normal Operation:**  
With the ignition key in "DRIVE" (term. 15) heating (G) begins and yellow lamp (L 1) in instrument panel comes on. Green lamp (L 2) comes on when engine is ready to be started. Heating continues during the engine starting phase and stops shortly after. Green lamp (L 2) comes on immediately with a coolant temperature of  $> 60^{\circ}\text{C}$  ( $140^{\circ}\text{F}$ ).




**Heating for Subsequent Start:**  
If the engine is started after lamp (L 2) has gone out (cancelled by the safety circuit), heating continues during the starting phase and stops after a brief delay.




**Heating without Start:**  
Heating is stopped by the safety circuit in control unit (7) after 8 to 13 seconds.




The yellow indicator lamp does not come on when the 80 ampere fuse (S) blows or the control unit is defective (below  $60^{\circ}\text{C}$  /  $140^{\circ}\text{F}$  coolant temperature).



Green indicator lamp (L 2) no longer comes on when one or more heater plugs are defective.




**Heating when Engine is Started Too Early:**  
If the engine is started before lamp (L 2) comes on, this will only mean longer starting time.




A flashing yellow indicator lamp (L 1) indicates the continued heating of the heater plugs replace control unit and check heater plugs.





### 12 23 000 CHECKING HEATER PLUGS — Installed in Car —


Lift cover off of heating time control unit.  
Pull off plugs (1 and 2).



#### Measuring Resistance:

Measure resistance\* of heater plugs with leads with BMW service test unit (M 06) or an ohmmeter.

Apply test lead tips on plug receptacles of plug (2) G1 through G6 and ground (battery —) separately.



#### Measuring Current:

Hold test leads on battery + and plug receptacles G1 through G6 five seconds each.  
Connect BMW service test unit (M 03) or an ammeter and measure current input


#### Important!

Do not measure current after removal of heater plugs — danger of injury and burns!  
See diagram for temperature curve of heater plugs during operation.




M 21 12 074

\* See Specifications




### 12 23 505 REPLACING ALL HEATER PLUGS

Unscrew connections.  
Unscrew heater plugs with Special Tool 12 2 100.



#### Installation:

Coat threads with copper paste "CRC"\*\*\*.  
Don't twist leads when tightening plugs.  
Check tightening torque\* of heater plugs and connections.



M 21 12 075


\* See Specifications  
\*\* Source: HWB



## 12 62 ... CHECKING TEMPERATURE SENSOR FOR COOLANT (Heating Time/Temperature Gage)

Remove temperature sensor only when coolant temperature is below 40°C (104°F) danger of scalding!

Installation:  
Use new seal.  
Tightening torque\*.



### Connections:

G 1 = for coolant temp. indicator (temperature gage)  
G 2 = for heating time control (to heating time control unit)

Dip removed temperature sensor in heated coolant up to hexagon and measure resistance\* on G 1 / G 2 and ground at specified temperature\*.




## 12 62 ... CHECKING TEMPERATURE SENSOR FOR COOLANT (VP-20)

Pull off plug.  
Measure resistance\* at testing temperature\*.



To check sensor with wire, pull off plug on control unit and connect universal adapter\*\* Measure resistance\* on terminal 6/13 also refer to Group 13.  
Troubleshooting injection system.



\* See Specifications

\* See Specifications  
\*\* Source: HWB

# 12-40

## TROUBLESHOOTING ALTERNATOR

Test Requirements: — Correct connections on battery, starter and alternator.  
— Good ground connection between engine and body.  
— Tight drive belt.

Charge Indicator Lamp NOT On with Ignition Turned On

Pull off connection plug D+/61 and connect with ground (term. 31).

Charge lamp on.

Take off voltage regulator. Check carbon brushes, replacing if necessary — see 12 32 000. Check slip rings for dirt or oxidation coat.

Connect BMW service test unit and perform engine test — see 12 31 009.

Charge lamp not on.

Check connections and wires\*\* for charge ind. lamp or replace light bulb — see 62 99 . . .

Charge Indicator Lamp ON with Ignition Off

Remove alternator. Replace diode plate — see 12 31 691.

Charge Indicator Lamp GLOWS or ON with Engine Running

Connect BMW service test unit and perform engine test (P 02)

Check regulating voltage\*  
Check charging current\*.

not okay

Replace voltage regulator — see 12 32 000.

Check oscillograph and harmonic wave ratio — see 12 31 009.

not okay

Replace or disassemble alternator and inspect components.

Battery is CHARGED INSUFFICIENTLY  
Charge Indicator Lamp Off with Engine Running

Connect BMW service test unit and perform engine test (P 02).

not okay

Regulating voltage not as specified.

Replace voltage regulator — see 12 32 000.

okay

Check battery, replacing if necessary. Check power drain with equipment switched off.

Charging current\* with equipment on too low.

Replace or disassemble alternator and inspect components — see 12 31 020

\* See nominal value microfiche


\*\* See wiring diagram

## 12-41

### 12 31 009 CHECKING ALTERNATOR AND VOLTAGE REGULATOR

#### Testing Requirements:


- Correct connections on charged battery
- Correct connections on alternator and starter
- Good ground connection between engine and body.
- Tight drive belt



30 12 033

#### Indicator Lamp On Continuously:

Remove voltage regulator and check carbon brushes, replacing if necessary - 12 31 200. Distance "V" for new condition = approx. 12 mm (0.472").



30 12 049




M 21 12 080

#### Installation:


Check slip rings for wear, fine grinding and polishing if necessary. Connect BMW service test unit. Start engine and compare test values with nominal values\*.

If the battery charge indicator lamp goes out while engine is running and the regulating voltage\* is not reached - harmonic wave ratio and oscillograph okay (as shown) - the voltage regulator has to be replaced, see 12 32 000.



630 11 025


\* See nominal value microfiche



30 12 035


#### Repeat test.

If the specified charging current is not reached, remove and disassemble alternator, and inspect components - 12 31 020 / 513.




630 11 031

Oscillographs of Defective Alternator: Defective power or exciter diode.



630 11 032

Shorted turn of stator coil.



630 11 027

Break in one exciter diode.

## 12-42



### 12 31 020 REMOVING AND INSTALLING/ REPLACING ALTERNATOR

Model 528e/533i/535i


Disconnect battery.

*Caution!*


Always stop engine before disconnecting wires on battery, alternator and starter. Also disconnect negative and positive leads when charging battery with a charger.



Remove air cleaner and air flow sensor.  
(528e only)



Unscrew nut and remove bolt with tensioning wheel.  
Remove drive belt.



Loosen line on power steering pump, if necessary.


*Installation:*

Install line, that it cannot rub on engine carrier.

Tightening torque\*.

533 12 003


\* See Specifications



Unscrew nut and pull out bolt.  
Remove alternator.


*Installation:*

Tighten drive belt – 12 31 299.



Unscrew wires on connection B + (term. 30)  
and D + (term. 61).  
Unscrew ground wire.

## 12-43



### 12 31 020 REMOVING AND INSTALLING/ REPLACING ALTERNATOR

BMW 524 td:

Disconnect battery.


*Caution!*

Always stop engine before disconnecting leads on battery, alternator and starter.

Also disconnect positive and negative leads when charging battery with a charger.




Unscrew and swing away fuel filter.



Disconnect wires on connection B + (term. 30) and D + (term. 61).

Unscrew ground wire (term. 31).




Unscrew bolts (1 and 3).

Remove alternator.

*Installation:*

Tighten drive belt — see 12 31 299.




### 12 31 299 CHECKING AND TIGHTENING ALTERNATOR DRIVE BELT

Check belt tightness with Special Tool 11 5 020, tightening belt if necessary.

Pulling hook (2) must be in middle of teeth.

Gage needle must be above green or yellow field of scale.




*Tightening Belt:*

Unscrew nut (1) and turn tensioning wheel (2) with a torque of approx. 7 Nm (5 ft. lbs.).

Tighten nut (1).

Recheck tightness with a tester, correcting if necessary.



M 21 12 034

## 12 31 201 REPLACING CARBON BRUSHES

Remove voltage regulator 12 32 000.  
Unsolder leads on carbon brush holder.  
*Note:*  
Only use a small amount of solder for soldering to prevent hardening of leads.




M 21 12 080

*Installation:*  
Check slip rings for wear.  
If necessary, remove the rotor and fine grind as well as polish the slip rings — see 12 31 201.



630 12 036

Avoid excessive out-of-true.  
Max. slip ring out-of-true = 0.03 mm (0.0012").




630 12 170

## 12 31 513 DISASSEMBLING AND ASSEMBLING ALTERNATOR — Alternator Removed —

Remove voltage regulator 12 32 000.  
Take off the fan.  
Remove the pulley, using Special Tool 12 3 000.  
Since 1986 Models:  
Hold the rotor shaft with a socket wrench.  
*Installation:*  
Tightening torque\*.

\* See Specifications



M 21 12 093

Mark housing sections to each other.  
Unscrew bolts.  
Pull housing sections apart.




M 21 12 091

Unscrew bearing cap bolts.  
Take off the end plate.



M 21 12 031

Unscrew the shielded capacitor.  
Unscrew nuts on B + and D + terminals.  
Take off the diode plate with stator coil.  
*Installation:*  
Check condition of insulating sleeves and washers, replacing if necessary.



M 21 12 030


Unsolder stator coil on the diode plate.  
*Caution!*  
Excessive heat from soldering iron would destroy the diodes.  
Inspect components of the alternator.



## 12-45


### 12 31 581\* REPLACING BALL BEARING — Alternator Removed and Disassembled —

Alternator — 65 A:  
Pull off bearing with Special Tool 00 7 500.




630 12 171

Unscrew bearing cap and press out bearing.  
*Installation:*  
Check installed position of washer — collar  
faces bearing.




M 21 12 091

Alternator — 80 A:  
Pull off bearing with Special Tool 00 7 500.




630 12 171

*Installation:*  
Replace cover for bearing, if it had been  
damaged through application of special tool.



630 12 172



30 12 039

*Installation:*  
Check installed position of washer — collar  
faces bearing.


### 12 31 691 REPLACING DIODE PLATE — Alternator Removed and Disassembled —

Unsolder stator coil on diode plate.  
*Caution!*  
Excessive heat from soldering iron would  
destroy the diodes.




630 12 176

Unscrew bolts.  
Remove diode plate.



630 12 173


*Installation:*  
Check condition of insulating sleeves and  
insulators.



630 12 179


## 12 31 ... INSPECTING COMPONENTS OF ALTERNATOR

Perform tests with the BMW service test unit.  
 Checking Rotor Coil for Breaks and Shorted Turns:  
 Connect test leads for resistance test on slip rings.  
 For 80 A alternator: 2.8 to 3.0 ohms.




M 21 12 083

Checking Rotor Coil for Ground Contact:  
 Connect test leads for resistance test on slip ring and rotor shaft.  
 Nominal value:  $\infty$  = 999 k-ohm display.  
 Check slip rings, fine grinding if necessary — see 12 31 200.




M 21 12 084

Checking Stator Coil for Ground Contact:  
 Connect test leads for resistance test on solder point and stator (coil carrier).  
 Nominal value:  $\infty$  = 999 k-ohm display.




M 21 12 085

Checking Stator Coil for Breaks:  
 Compare resistance values of wires 1/2, 1/3 and 2/3 with an ohmmeter — they should be identical.  
 The shorted turn test can be performed with a standard tester.




M 21 12 086



M 21 12 087


Checking Negative Diodes:  
 Connect test leads for diode test.  
 Negative lead on cooler and positive lead on one of the negative diode connections.  
 Display with perfect condition diodes: polarity "—".



M 21 12 088

Checking Positive Diodes:  
 Connect negative lead on B + connection pin and positive lead on one of the positive diode connections.  
 Display with perfect condition diodes: polarity "+".

If a diode is defective, replace entire diode plate — 12 31 691.




M 21 12 089




13 32 000 REMOVING AND INSTALLING/  
REPLACING VOLTAGE  
REGULATOR


Unscrew bolts (1) and take off regulator (2)  
carefully.



Check slip rings for wear, fine grinding if  
necessary.



Clean contact surfaces and check tension of  
spring contacts, correcting if necessary.






*Installation:*  
Mount regulator at first with one bolt screwed  
in finger tight, then press alternator to final  
installed position carefully, install and tighten  
all bolts.


# 12-50

## TROUBLESHOOTING STARTER

Testing Requirements: – Correct connections on battery and starter  
– Good ground connection between engine and body  
– Charged battery




## 12-51




### 12 41 020 REMOVING AND INSTALLING STARTER


BMW 528 e:  
Disconnect battery.  
Remove air cleaner with air flow sensor



Disconnect leads (term. 30 and 50).  
Unscrew support.




Unscrew nuts.  
A ring wrench can be bent subsequently to improve accessibility – see figure.  
Unscrew 2nd starter bolt from below.  
Take off starter from below.




BMW 533 i / 535 i:  
Disconnect battery ground lead.  
Drain coolant and take off expansion tank.

*Installation:*  
Add coolant \* and bleed cooling system – see 17 00 039.




Detach heater hose.



Disconnect leads (term 30 and 50).  
Remove mounting bolts.  
Unscrew top bolt with the bent ring wrench and take off starter.


\* See Service Information of Gr. 00



## 12 41 020 REMOVING AND INSTALLING STARTER

BMW 524 td:  
Disconnect battery ground lead.  
Take off expansion tank and drain coolant.


*Installation:*  
Add coolant\* and bleed cooling system – see 17 00 039.




Unscrew bolts and remove starter from above.



Detach heater hose.



Unscrew wires (B +/Term. 30 and Term. 50).




Unscrew support for air collector and support plate.  
Note ground wire on bolt (1).

\* See Service Information of Gr. 00.

## 12 41 041 REPLACING SOLENOID SWITCH

Remove starter — 12 41 020  
Take off cover.




M 21 12 095

Unscrew solenoid switch (1 and 2).

*Installation:*

Don't bend wire connector while tightening switch — danger of short circuit.




28 12 044

Take off solenoid switch (1) and spring (2).  
Disconnect pin (3).

*Installation:*


Check pin (3) for wear and lubricate with grease.



28 12 045


## 12 41 ... INSPECTING COMPONENTS OF STARTER (Electric Test)

Check power input\* of activating and holding coils in solenoid switch.




630 12 186

Check exciter coil, carbon brush holder and armature coil for ground connection.  
Check armature for coil short — use conventional tester.



316 12 049



316 12 053

\* See Specifications



## 12-54

### 12 41 103 DISASSEMBLING/ASSEMBLING STARTER

Model 528 e / 533 i / 535 i

Remove starter – see 12 41 020.

Remove solenoid switch – see 12 41 041.

Unscrew dust cap (2).


Take off circlip (3), shims (4) and seal (5).

*Installation:*

Check axial play of armature, correcting with shims if necessary.



630 12 052




630 12 147

Unscrew housing bolts and take off cover.

*Installation:*

Align openings for housing bolts and insulator to each other.

Check bearing sleeve, lubricating with oil before installing.



630 12 151

Lift springs and pull out carbon brushes.

Remove holder.

*Installation:*

Check carbon brushes and commutator for wear, repairing if necessary – see 12 41 551.




630 12 174

Remove pole housing.

Unscrew engaging lever bolt and remove rubber seal.

\* See Specifications




630 12 175

Lift out armature with drive pinion and engaging fork.

*Installation:*

Lubricate guide for engaging fork with grease.

Check bearing sleeve in drive bearing bracket, lubricating with oil before installing.



2B 12 049

Push back bearing race (1) with a piece of suitable pipe.

Pry circlip (2) apart and pull it off of the shaft.

Remove burrs with a file.

Take off drive pinion (3).

*Installation:*

Use new circlip (2).


Lubricate bearing surface for drive pinion with grease.



630 12 144

*Installation:*

Check pinion for wear (on teeth, bearings, one way clutch), replacing if necessary.



630 12 187

Check sleeve in intermediate bearing, replacing if necessary.

## 12-55

### 12 41 103 DISASSEMBLING/ASSEMBLING STARTER

Model 524td:


Remove starter 12 41 020.

Remove solenoid 12 41 041.


Unscrew both bolts.

*Installation:*

Clean all parts thoroughly before assembling.



M 21 12 039




M 21 12 040

Disconnect motor (1) on gearbox (2).

*Installation:*

Groove (3) must be aligned with rubber part (4).




M 21 12 043

Take off protective cap.

Remove retainer (1) and shims (2).

*Installation:*

Check axial play\*, correcting if necessary.



M 21 12 044

Check armature shaft, removing burrs if necessary.

Take off cover.

\* See Specifications



M 21 12 045

Insert a size 22 mm wrench socket or piece of pipe with approx. 30 mm (1.181") outside diameter to prevent carbon brushes from springing out.




M 21 12 046

*Installation:*


Use wrench socket or pipe again to make installation easier.

Place entire unit on transmission case and then tighten wire connector.



M 21 12 021

Remove cover and rubber pad.



M 21 12 054

Pull out transmission assembly.

Take off toothed ring on planet gear and release.

1 Planet gear

2 Release

3 Pinion


4 Transmission case

## 12-56




*Installation:*  
Openings and bores must be aligned.

M 21 12 057




M 21 12 096

Check bearings, driving out with a suitable mandrel if necessary.  
*Installation:*  
Lubricate new bearing with grease and press in.  
Distance A = approx. 1 mm (0.039").




M 21 12 059

Pull off circlip (1) and remove washers.  
2 Metal washer  
3 Plastic washer




M 21 12 060

Remove bearing cap (4) and washers (5).  
Check bearing sleeve (6), replacing if necessary.  
*Installation:*  
Lubricate sleeve with oil after pressing in.




M 21 12 097

Turn drive pinion against stop.  
Pinion can be turned very easily when one-way clutch is worn.  
Check bearing sleeve and teeth of pinion for wear.




M 21 12 098

Check bearing sleeve, removing with a suitable puller if necessary.  
Check planet gears for wear.  
*Installation:*  
Lubricate sleeve with oil after pressing in.



M 21 12 067

Knock back thrust ring (1) and pull off circlip (2) toward front.  
If applicable, remove burrs and then take off drive pinion.  
*Installation:*  
Clean pinion bearing surface thoroughly and lubricate with grease.



## 12 41 551 REPLACING CARBON BRUSHES – Starter disassembled –


Model 528e/533i/535i:  
Lift springs and pull out carbon brushes.



Remove holder and pole housing.  
Unsolder or cut off all carbon brushes.  
When soldering in new carbon brushes, make  
sure that copper leads are not hardened with  
flowing solder.




630 12 060



630 12 065


Check commutator for wear, fine grinding if  
necessary.  
Diameter must be at least 33.5 mm (1.319").  
Machine insulation between plates approx.  
0.5 to 0.7 mm (0.020 to 0.028") deep.

Check armature for shorted turns after  
repairing.




21 12 001

Push carbon brush holder to middle and lift off.



M 21 12 050

Installation:  
Engage hooks of carbon brush holder fully.



21 12 002


Two carbon brushes have to be cut off on the  
leads.  
Solder in new carbon brushes.

Model 524td:  
Fine grind and polish commutator on armature.  
File or machine insulation between commutator  
plates 0.5 to 0.7 mm (0.020 to 0.028") deep.  
Check for shorted turns after repairing.


## 12-60

### 12 63 ... CHECKING SPEED SIGNAL FOR TACHOMETER

Remove cover in glove box.  
Pull off plug on control unit VP-20.




21 12 016



21 13 029


Connect universal adapter\*\*.  
Connect test leads for control unit and periphery.



Connect oscilloscope on terminals 17 (—) and 21 (+).  
Start and run engine at idle speed.  
The illustrated oscillograph must appear on the screen.  
If necessary, check speed sensor — see 12 14 160.

\*\* Source: HWB


# 12 64 ... CHECKING FUEL HEATING



2113 037


Fuel is heated when its temperature is less than + 5° C (41° F) in ignition key position "DRIVE".  
Temperature switch (T) activates relay (R), which supplies current to heating element (H) — see engine electrical equipment wiring diagram.

Measure coil resistance\* with an ohmmeter replacing heating element if necessary.  
Check switching temperature\* of temperature switch.



2113 038

Pull off relay and apply battery voltage on terminal 87 (black wire) approx. 10 seconds.  
Measure power input\* — must drop as temperature of heating element rises.




2113 039

\* See Specifications


# 12 64 005 REPLACING FUEL HEATING ELEMENT

Unscrew fuel lines.  
Pull off plugs for temperature switch, water level sensor and heating element.



2113 040

Unscrew filter cartridge with a standard filter strap.  
Unscrew filter head and take off unit.




M 21 13 313

Unscrew filter cartridge.  
Unscrew heating element with Special Tool 13 2 010.



2112 066


**Installation:**  
Insert heating element seal correctly — note dowel pin.  
Tighten nut to correct torque\*.  
Tighten filter cartridge to instructions on filter.  
Bleed fuel filter, see 13 32 051.



M 21 13 315

\* See Specifications






12 81 ... REPLACING / CHECKING  
COOLANT HEATER

*Caution!*  
Heater is operated with 120 AC voltage –  
never work on a connected heater.

Remove rod.




Remove retainer and pull off plug.  
Drain coolant from engine.




Loosen heater on engine block by applying  
knocks from the side with a plastic hammer.  
Clean sealing surface.

*Installation:*  
Coat sealing surface with Loctite No. 573.  
Knock in heater uniformly until seated well,  
not necessarily against stop.




Fill cooling system with specified coolant\*\*  
and bleed cooling system – see 17 00 039.

\*\* See Service Information of Gr. 00



*Caution!*  
Never operate heater before filling the cooling  
system – danger of destruction.



*Checking:*  
Open socket and check resistance \* and insu-  
lation of heater, replacing cable or heater if  
necessary.

Never repair single components (connecting  
lead and cable, as well as socket and heater);  
always replace only a complete part.

\* See Specifications



## 13 Fuel system

<b>BMW 524 td</b>	
	Working instructions / explanations of abbreviations ..... 13- 1
13 00 050	Engine idle speed – check/adjust ..... 13- 2
550	Cold running device (temperature dependent idle speed boost) – check/adjust ..... 13- 3
13 31 028	Fuel feed pressure – check ..... 13- 4
13 32 ...	Fuel filter – draining water ..... 13- 4
051	Fuel filter – remove and install/replace ..... 13- 5
	Troubleshooting survey for engine electrical, fuel and injection systems ..... 13- 10
	Testing instruction for VP-20 fuel injection ..... 13- 11
13 51 000	Injection pump – remove and install ..... 13- 15
001	Injection pump – replace ..... 13- 19
002	Injection pump internal pressure – check ..... 13- 20
506	Injection pump static adjustment – check/correct ..... 13- 21
006	Injection begin (dynamic) – check ..... 13- 23
290	Pressure valve – replace ..... 13- 24
...	Timing valve in injection pump – replace ..... 13- 25
13 51 300	Electric fuel shut off – check ..... 13- 26
301	Electric fuel shut off – replace ..... 13- 26
320	Fuel system – bleed ..... 13- 27
340	Operating lever of injection pump – check /adjust ..... 13- 28
13 51 ...	Atmospheric and charging air pressure dependent regulation (ALDA) – check ..... 13- 29
13 63 320	Fuel injectors – remove/install/replace ..... 13- 30
13 63 ...	Injection nozzle – flush ..... 13- 31
800	Injection nozzle – check ..... 13- 32
13 71 000	Air cleaner – remove/install ..... 13- 33

<b>BMW 528 e/A</b>	
13 00 054	Engine idle speed / CO level – adjust ..... 13- 008
13 31 029	Fuel delivery pressure – check ..... 13- 312
...	Fuel delivery rate – check ..... 13- 312
030	Fuel pump – remove and install ..... 13- 319
13 32 051	Fuel filter – remove and install ..... 13- 324
13 41 000	Idle speed control valve – remove and install ..... 13- 411
010	Control unit for idle speed control valve – remove and install ..... 13- 418
13 51 200	Fuel pressure regulator – remove and install ..... 13- 512
...	Fuel pressure regulator (fuel injection pressure) – check ..... 13- 512
13 54 030	Throttle housing – remove and install ..... 13- 521
051	Throttle shaft return springs – remove and install ..... 13- 532
13 61 000	Control unit – remove and install ..... 13- 613
13 62 000	Air flow sensor – remove and install ..... 13- 621
050	Temperature time switch – remove and install/check ..... 13- 626
080	Pressure sensor – remove and install ..... 13- 627
531	Coolant temperature sensor – remove and install/check ..... 13- 629
13 63 544	Throttle switch – adjust ..... 13- 631
551	Throttle switch – remove and install ..... 13- 634
13 64 030	Cold start valve – remove and install/check ..... 13- 642
501	Fuel injector – remove and install ..... 13- 643
12 63 051	Temperature switch 0° C (32° F) – remove and install ..... 13- 701
060	Temperature switch 45° C (113° F) – remove and install ..... 13- 704

<b>BMW 533 i/A, 535 i/A</b>	
13 00 020	Adaptive initial control – check ..... 13- 01
050	Engine performance – check/adjust ..... 13- 05
054	Engine idle speed / CO level – adjust ..... 13- 010
13 31 029	Fuel delivery pressure – check ..... 13- 313
...	Fuel delivery rate – check ..... 13- 313
030	Fuel pump – remove and install ..... 13- 319
13 32 051	Fuel filter – remove and install ..... 13- 324
13 41 000	Idle speed control valve – remove and install ..... 13- 412
010	Idle speed control valve control unit – remove and install ..... 13- 418
13 51 200	Fuel pressure regulator – remove and install ..... 13- 512
...	Fuel pressure regulator (fuel injection pressure) – check ..... 13- 512
13 54 030	Throttle housing – remove and install ..... 13- 524
051	Throttle shaft return springs – remove and install ..... 13- 534
13 61 000	Control unit – remove and install ..... 13- 613
13 62 000	Air flow sensor – remove and install ..... 13- 623
050	Temperature time switch – remove and install/check ..... 13- 626
531	Coolant temperature sensor – remove and install/check ..... 13- 629
13 63 544	Throttle switch – adjust ..... 13- 632
551	Throttle switch – remove and install ..... 13- 633
13 64 030	Cold start valve – remove and install ..... 13- 644
501	Fuel injector – remove and install ..... 13- 645
12 63 051	Temperature switch 0° C (32° F) – remove and install ..... 13- 701
060	Temperature switch 45° C (113° F) – remove and install ..... 13- 701
	Hose routing plan ..... 13- 750

Testing instructions for electronic idle regulation ..... 13- 810
Troubleshooting fuel injection ..... 13- 900
Troubleshooting engine electronics ..... see group 12

## WORKING INSTRUCTIONS

These instructions concern cleanliness when working on fuel supply and control systems.


- Clean area around repair point thoroughly - e.g. before disconnecting lines, switches, etc..
- Place removed parts only on clean surfaces and cover with plastic sheet - never use cloths losing lint.
- Cover or inert plugs in open lines and openings in parts immediately - do not work with compressed air.
- Only install cleaned parts.  
Take new replacement parts out of their packaging only shortly before installing.
- Keep diesel fuel off of coolant hoses - or wash off immediately with water if applicable.

## EXPLANATIONS OF ABBREVIATIONS

Injection Pump Attachments:

- |      |  |
|------|--|
| TLA  | - Temperature dependent idle speed boost                         |
| ALDA | - Atmospheric and charging air pressure dependent full load stop |
| AGR  | - Exhaust gas recirculation (EGR)                                |

## 13-2



### 13 00 050 CHECKING / ADJUSTING ENGINE IDLE SPEED

#### Requirements:


- Engine at operating temperature (oil temperature  $> 60^{\circ}\text{C}$  /  $140^{\circ}\text{F}$ )
- Valve clearance okay
- All electric equipment switched off
- Speed lever resting on adjusting screw



Cars with Automatic Transmission:  
Check distance "X" in idle position, correcting if necessary – linkage basic adjustment – see 13 51 340.



Check or correct play "S" of  $0.5 \pm 0.3$  mm ( $0.020 \pm 0.012$ ") between knurled head screw (8) and speed lever (9).



Hold on hexagon (1) and unscrew nut (2).  
Turn knurled head screw (3) until play "S" is reached.



Start the engine.  
Check the idle speed\* and, if necessary, loosen nut (1) and turn adjusting screw (2) until the correct idle speed\* is reached.  
Tighten nut (1) again.  
Recheck play "S", correcting if necessary.


\* See Specifications

## 13-3

### 13 00 550 CHECKING / ADJUSTING COLD IDLE DEVICE (TEMPERATURE DEPENDENT IDLE SPEED BOOST)

#### Requirements:


Coolant temperature:  $< 20^{\circ}\text{C}$  ( $68^{\circ}\text{F}$ ).  
Idle speed (warm) okay.



M 21 13 243


#### Checking Expansion Element:

Spray housing for expansion element with a refrigerating spray\*\* about one minute.



M 21 13 287

Pull back the speed lever by hand slightly.  
The piston, with knurled head screw should be pulled back by 2 to 3 mm (0.079 to 0.118") by the action of the expansion element.  
Replace the expansion element, if necessary.




21 13 140

#### Checking Adjustment:

Unscrew holder (1) for the cable.  
Pinch hoses (2) with clamps and unscrew housing (3).

\*\* Source: HWB




21 13 141

Plate (P) must rest on the circlip by spring pressure.


#### Installation:

Make sure that expansion element (D) is seated correctly.



21 13 008


The adjusting device should now be pulled out.  
Distance "K" =  $5,5 \pm 0,4$  mm ( $0,216 \pm 0,016$ ").



21 13 007

#### Correction:

Loosen clamps (1 and 2) and turn until the distance "K" is reached.  
Apply a 10 mm fork wrench to help making adjustments.  
Tighten clamp (2) first and then (1).




21 13 009

Check/correct play "S" =  $0,5 \pm 0,3$  mm ( $0,020 \pm 0,012$ ") after making adjustments.  
Check / correct the engine idle speed — see 13 00 050.




## 13 31 028 CHECKING FUEL FEED PRESSURE

Unscrew coupling nut with Special Tool 13 5 020.  
Counterhold adapter with a fork wrench.



Connect pressure meter 13 5 390 with adapter.  
Turn start key to "DRIVE" position before tightening adapter on the injection pump, so the line can discharge itself.



Start engine and read feed pressure \* at test speed \*.  
If specified value is not reached, check  
- filter screen in tank,  
- fuel transfer pump,  
- fuel lines and  
- fuel filter.




Bleed feed line again after testing.


\* See Specifications

## 13 32 ... DRAINING WATER IN AND BLEEDING FUEL FILTER

Water in the fuel filter is detected by a water sensor and reported to check control where it is displayed.



Loosen bleeder screw.  
Hold an approx. 0.2 liter (0.4 pint) container underneath drain adapter (3), using a short hose if necessary.  
Press drain adapter (3) and drain fluid until pure fuel runs out.



Pull off relay for fuel transfer pump and connect tester 61 3 050 on terminals 30 and 87, and operate pump until fuel runs out of bleeder screw opening.



# 13-5

## 13 32 051 REMOVING AND INSTALLING/ REPLACING FUEL FILTER


Loosen bleeder screw and drain a little fuel through water drain connection – see draining water in fuel filter, 13 32 ...  
Disconnect plug on water level sensor.  
Unscrew filter with a standard tool, if necessary.

*Installation:*  
Replace seal.


Unscrew bolt with water level sensor (2) and install on new filter.



Operate fuel transfer pump until fuel runs out of bleeder screw opening and then tighten screw again.  
Start engine and check filter for leaks, tightening filter if necessary.




21 13 035



M 21 13 224

Coat seal with fuel and screw on filter against surface, and then tighten by hand with one half turn – see installing instructions on filter.



21 13 033


Pull off relay for fuel transfer pump and bridge terminals 30 and 87 with Special Tool 61 3 050.

\* See Specifications

TROUBLESHOOTING SURVEY FOR ENGINE ELECTRICAL, FUEL  
AND INJECTION SYSTEMS

**Requirements:**

- Starting system (battery voltage, starter, ignition lock, etc.) in perfect condition
- Engine in perfect running condition (timing, compression, charging air pressure)
- Specified fuel in tank (no contamination, winter-proof)
- Connections, plugs and ground points according to wiring diagram

[illegible]



## TESTING INSTRUCTIONS FOR VP-20 FUEL INJECTION




These instructions show a sequence of tests for time saving diagnosis and repairs.  
The listed test points only describe such jobs which are not contained in the troubleshooting survey.

### Testing Equipment:

- BMW service test unit, e.g. engine test step 05 (P 05) or multimeter 02 (M 02).
- Test adapter to measure beginning of injection, in conjunction with BMW service test unit.
- Universal adapter\* for periphery test and diagnosis in conjunction with check control

### Testing Requirements:

- Charged battery
- Starting system in perfect condition
- Specified fuel in tank
- Engine in perfect running condition (timing, toothed belt, compression etc.)
- Connections, plugs and ground points according to wiring diagram




## 13 - 12

Engine running, increase speed to approx. 2,000 rpm.  
"INJECTION" lamp goes out.


Check dynamic injection begin\*,  
correcting static adjustment of  
injection pump if necessary - see  
13 51 006 / 506.

no

Connect universal adapter with test lead  
for periphery and control unit as shown.  
Start engine and activate defect check control:  
Bridge term. 12 and 17 briefly (1 to 2 sec.)  
with test lead.  
Observe and count flash pulses of INJECTION  
lamp.  
Lamp remains on continuously after  
flashing.  
If INJECTION lamp is only on continuously  
at high speed, there must also be a defect  
check control at this speed.



21 13 041



21 13 075

0 - 2 - 4 - 6 - 8 flash pulses

VP-20 control unit defective.

Initial injection nozzle not working.

Speed sensor not working.




Check resistance \* of initial injection  
nozzle (term. 4/5) and insulation resistance  
(term. 4/17 and 5/17), replacing nozzle  
if necessary - see 12 53 ...

Check resistance \* of speed sensor  
(term. 8/27) and insulation resistance  
(term. 8/17 and 27/17) adjusting or  
replacing speed sensor if necessary -  
see 12 14 ...

Start engine and reactivate defect  
check control.


\* See Specifications

## 13-13



\* See Specifications

## 13-15



### 13 51 000 REMOVING AND INSTALLING INJECTION PUMP

#### Removing:

Unscrew drain plugs on engine and radiator, and drain coolant.


Unscrew and swing away expansion tank.

#### Installation:


Add coolant\* and bleed cooling system — see 17 00 039.




Unscrew fan cowl.  
Unscrew fan (left-hand threads).  
Hold with Spezial Tool 11 5 030 — see 11 52 000.




Turn crankshaft up to TDC mark (ignition position in cylinder no. 1).




Disconnect water hoses.  
Loosen alternator drive belt and take off toothed belt cover.




Hold adapter and unscrew line with Special Tool 13 5 020.  
Plug opening with cap.



Disconnect connection and unscrew return line.  
Loosen clamp for wire harness.




Unscrew holder for oil pipe.  
Disconnect hoses on T.L.A.  
Unscrew support for air collector.  
Pull off plug on blowoff valve.



Pull off hoses for  
charging air pressure (1),  
leak oil (2),  
vacuum (3) and  
altitude compensator (4).


\* See Service Information of Gr. 00

## 13-16




Unscrew charging air pressure pipe and oil trap.  
Pull off plugs for  
speed sensor (1),  
initial injection nozzle (2) and  
timing valve (3).

21 13 072




Disconnect plug for fuel shutoff.  
Pull off connections for idle switch (EGR).

21 13 048




Disconnect cables and take out of holders.

21 13 049




Unscrew all coupling nuts on injection nozzles.  
Plug openings in injection nozzles with caps.  
Important!  
Reposition special tool in good time to avoid  
bending injection lines.

21 13 045




M 21 13 207



21 13 042

Unscrew coupling nuts on injection pump and  
pull back lines.  
Plug openings with caps.

Unscrew nut on toothed belt sprocket.




13 5 010

13 5 061

21 13 143


Bolt Special Tool 13 5 061 with Tool 13 5 010  
on toothed belt sprocket.




21 13 044

Turn crankshaft until special tool can be  
bolted at top and bottom.  
Use M 6 x 20 mm screws.


# 13-17




Unscrew nuts (1 and 2).




Unscrew bolts (6 ... 8)




Press out injection pump toward rear with bolt.




Pull off hoses on pressure converter (EGR).  
1 Vacuum supply  
2 To solenoid valve




Take wire harness out of holders.  
Remove injection pump.



Installing:  
Loosen bolts (3 ... 5) before installing.




Check position of injection pump shaft,  
correcting as shown in picture with Special  
Tool 13 5 062 if necessary.  
Turning lever must be vertical.




Insert injection pump, being careful that the  
woodruff key does not fall out.


## 13-18



Tighten nuts (1 and 2) until injection pump rests firmly on holder.




After assembling, bleed fuel system — see 13 51 320.  
Check idle speed — see 13 00 050.  
Check dynamic injection begin — see 13 51 006



Remove Special Tool 13 5 010 and 13 5 061, mount toothed belt sprocket.  
Tightening torque\*.



Adjust injection pump statically — see 13 51 005.



Begin with connection (4) when tightening injection lines.


\* See Specifications




## 13-19

### 13 51 001 REPLACING INJECTION PUMP

Remove injection pump — see 13 51 000.  
Transfer following parts to new injection pump.




21 13 056




21 13 015

— Stopping lever and holder for wire harness.




21 13 057

— Holder and switching contact for idle switch (EGR).  
Pressure converter with linkage holder.  
After installation, make adjustments on EGR — see Group 11.




21 13 058

— Holders and reversing lever for cables.  
Tests and adjustments after installation:  
— On pull rod — see 13 51 340.  
— On throttle cable — see Group 35.  
— On transmission cable — see Group 24.




21 13 053

Turn injection pump shaft with Special Tool 13 5 062 as shown.  
Lever of special tool must be vertical.




M 21 13 398

Install and mount injection pump.  
The hollow union bolt "OUT" (fuel return orifice) is matched with an injection pump. Consequently it must not be mixed up or used with a different injection pump.



21 13 055

Adjust injection pump statically — see 13 51 005.  
Start at connection (4) when tightening injection lines.



21 13 059


After Assembling:  
Bleed fuel system — see 13 51 320.  
Check idle speed — see 13 00 050.  
Check dynamic injection begin — see 13 51 006.

## 13 – 20




### 13 51 002 CHECKING INJECTION PUMP INTERNAL PRESSURE


Unscrew and swing away expansion tank.  
Plug overflow hose.




Pull off plug on blowoff valve.  
Pull off leak oil hose on injection nozzle.  
Unscrew hollow union bolt (OUT).




Disconnect return hose on holder and pull out downward.



Install test hose (1) with adapter 13 5 380 and seals.  
Mount return hose on adapter with hollow union bolt (OUT).



Connect BMW service test unit (M 19).  
Use hose for pressure test.  
Start engine and read pump internal pressure\* at test speed\*.  
If specifications are not reached, check fuel feed pressure – see 13 31 028.  
If okay, replace injection pump.




Diagnosing Information:  
Internal Pressure Too Low  
– Pressure control valve (1) faulty.  
– Fuel delivery pump (2) performance insufficient.

Remedy:  
Replace injection pump.


Internal Pressure Too High  
– Hollow union bolt (OUT) for return hose plugged – clean, if necessary.  
– Pressure control valve faulty, replace injection pump if necessary.

Incorrect internal pressure will cause displacement of the injection timing.  
This will be noticed on insufficient pressure due to inadequate power or on excessive pressure with hard engine running.




## 13 51 506 CHECKING / CORRECTING STATIC ADJUSTMENT OF INJECTION PUMP


Requirements:  
Coolant temperature > 20° C (68° F) or  
speed lever not in cold running position —  
must rest on idle stop.



Unscrew and swing away expansion tank.  
Plug overflow hose.  
Unscrew support for air collector.




Unscrew plug.  
Installation:  
Use a new seal.  
Tightening torque\*.




Screw in Special Tool 13 5 330 and tighten  
by hand.  
Clamp dial gage with pre-load.


\* See Specifications




Unscrew fan cowl and fan (left-hand threads)  
— see 11 52 000.



Turn crankshaft in TDC direction (ignition  
control of cylinder no. 1) until dial gage  
needle has reached the highest value.




Set scale of dial gage to zero.  
Continue turning crankshaft up to TDC position  
and press Special Tool 11 2 300 into bore at  
same time until it engages.  
The displayed value should correspond with  
the static test value\*, correct static adjustment  
if necessary.  
*Important!*  
Test must only be made with ignition control  
in cylinder no. 1 — check through open oil  
filler cap.  
Only turn engine clockwise for testing.




\* See Specifications

## 13 - 22


**Correcting Static Adjustment:**  
Corrections will be necessary as soon as the test value is not within tolerances\* or the test value\* is not reached in the dynamic test.




Unscrew and swing away expansion tank.  
Plug overflow hose.  
Unscrew support for air collector.



Take wire harness out of holders.



Unscrew bolts (3 ... 5).  
Use a 3/8" joint ratchet with 120 mm long extension, joint and 13 mm socket.



Loosen hose clamp.  
Only loosen nuts (1 and 2) enough that the injection pump can be moved.




Mount dial gage (see testing) and turn injection pump accordingly.  
The beginning of injection will be advanced by turning toward the engine.  
After adjusting the injection pump, tighten in order of 1 through 5 and recheck adjustment.  
After Adjusting:  
Check dynamic injection begin - see 13 51 006


## 13 – 23

### 13 51006 CHECKING INJECTION BEGIN (DYNAMIC)

Connect diesel test adapter on diagnosis socket.  
Connect BMW service test plug (1) and trigger clips (2) to adapter.  
Use engine test – teststep 06.  
Insert number of cylinders.  
Guide in oil temperature sensor (3).  
Set selector switch on diesel test adapter to 06 (injection begin).  
The switch position must conform with the engine test step on the service test unit.



In case of wrong injection begin, make static adjustment – see 13 51 506



Lamp (4) comes on when power is supplied.  
Lamp (5) flashes in time with initial injection nozzle.




Start and run engine to operating temperature (oil temperature  $> 70^{\circ}\text{C} / 158^{\circ}\text{F}$ ).  
Rise speed slowly up to test speed \*, read injection begin \* (in crankshaft degrees before TDC).  
Right values only appear at constant revolutions.

\*) See Specifications




# 13 51 290 REPLACING PRESSURE VALVES

Disconnect battery.  
Loosen reservoir and turn aside.




Drain coolant, remove hose (1).  
Remove oil separator (2) and charger  
air pipe (3).

*Installation:*  
Fill up with correct coolant \*\*)  
bleed cooling system - see 17 00 039




Disconnect plugs and remove  
bracket.

- 1 Speed transmitter
- 2 Injection begin jet
- 3 Pulse valve.




Remove receptacle for oil dip stick  
and air collector bracket.  
Pull off charger pressure hose and  
plug of check valve.



\*\*) See service Information Group 00.


Remove air collector.  
Disconnect injection lines on injection  
pump and injectors with special tool  
13 5 020.

*Installation:*  
Note tightening torque \*).



Remove pressure valve bracket.



*Attention!*  
Parts come loose.  
Parts 1 to 5 are matched - don't mix.




Lift out washer (6) with a pin etc.

*Installation:*  
Note job descriptions on page 13 - 1.  
Use new washers (6) - note installed position.  
Note tightening torque \*).  
Bleed injection system after installa-  
tion - see 13 51 320.

- 1 pressure valve holder
- 2 pressure valve
- 3 pressure valve body
- 4 pressure spring
- 5 shim
- 6 washer




\*) See technical data




## 13 51 ... REPLACING PULSE VALVE FROM INJECTION PUMP

Remove injection pump - 13 51 000.  
Remove mounting plate.




Unscrew and pull out pulse valve.  
Lift out small O-ring from injection pump.  
Attention, place oil pan underneath  
Diesel fuel runs out of injection pump.  
See job information page 13 - 1




Installation:  
Fit new O-rings.  
Note tightening torque \*).

\*) see technical data



After installation of injection pump  
make static adjustment and dynamic  
test see 13 51 506





## 13 51 300 CHECKING ELECTRIC FUEL SHUTOFF


The fuel shutoff receives electric power from the ignition lock (key turned to "DRIVE"). A click is heard when shutoff switches on.

### Testing Requirements:


- Fuel in tank
  - Fuel filter in perfect condition
  - Fuel line bled up to injection pump
- Loosen plug two turns.



Turn ignition key to "DRIVE" or apply 12 V on fuel shutoff.



Crank engine with the starter. Fuel must run out of the plug bore. If not, replace fuel shutoff.




## 13 51 301 REPLACING ELECTRIC FUEL SHUTOFF


Open plug receptacle and pull off wire.

Installation:

Mount plug receptacle on wire harness.



Unscrew support for air collector. Pull off plug for blowoff valve.



Unscrew fuel shutoff with a 24 mm open-end wrench.


Caution!

Be careful that piston and spring do not fall out.

The spring will run the piston out when in no current condition -- fuel feed stopped.


Installation:

Check that O-ring fits correctly. Tightening torque\*.




\* See Specifications

## 13 - 27



### 13 51'320 BLEEDING FUEL SYSTEM

Pull off relay for fuel transfer pump.  
Bridge terminals 30 and 87 with Special Tool  
61 3 050.




Loosen bleeder screw.  
Operate fuel transfer pump with the special  
tool until fuel runs out.  
Tighten bleeder screw.



Bleed feed line by loosening coupling nut with  
Special Tool 13 5 020.


#### Installation:

Tighten coupling nut with correct torque\*.  
Operate fuel transfer pump with Special Tool  
61 3 050 to bleed the fuel line.



#### Bleeding Injection Pump:

Loosen plug two turns.  
Crank engine with starter until fuel runs out.  
Tighten plug with correct torque\*.



#### Bleeding Injection Lines:

Loosen all coupling nuts on fuel injectors with  
Special Tool 13 5 020.  
Crank engine with starter until fuel runs out of  
lines.  
Tighten coupling nuts with correct torque\*.

\* See Specifications


\* See Specifications

## 13-28


### 13 51 340 CHECKING / ADJUSTING OPERATING LEVER OF INJECTION PUMP

#### Requirements:


- Coolant temp.  $> 20^{\circ}\text{C}$  ( $68^{\circ}\text{F}$ )
  - Correct idle speed
- Unscrew and swing away expansion tank.  
Measure and note distance "A".




Press speed lever against full load stop.  
Measure distance "B" and subtract it from  
distance "A" to produce distance "Y".



Adjusting distance "C" can be found in the  
table with help of distance "Y".



Unscrew ball head and adjust accordingly to  
correct distance "C".



### ADJUSTING TABLE All dimensions in millimeters

Y	41	41.5	42	42.5	43	43.5	44	44.5	45	45.5	46	46.5
C	78.1	77.0	76.0	74.9	73.9	73.0	72.0	71.1	70.3	69.4	68.6	67.8
Y	47	47.5	48	48.5	49	49.5	50	50.5	51	51.5	52	52.5
C	67.0	66.3	65.6	64.9	64.2	63.5	62.9	62.3	61.6	61.0	60.5	59.9
Y	53	53.5	54	54.5	55	55.5	56					
C	59.4	58.8	58.3	57.8	57.3	56.8	56.4					

Example:	A	129.0 mm (5.079")
	- B	83.2 mm (3.276")
	Y	45.8 mm (1.803")


Consequently distance "C", measured from pivot point of speed lever to ball socket,  
is 69 mm (2.716").



In idle position distance "X" should be  
 $68 \pm 0.5$  mm ( $2.677 \pm 0.020$ ").  
If necessary, correct by changing length of  
pull rod.



In full load position distance "Z" must be  
 $29.1 \pm 0.5$  mm ( $1.146 \pm 0.020$ ").  
After adjusting check throttle cable adjustment  
for automatic transmission -- see 24 00 004.




## 13 51 ... CHECKING ATMOSPHERIC AND CHARGING AIR PRESSURE DEPENDENT REGULATION (ALDA)

Connect vacuum pump on connection (4) and produce at least - 300 mbar. This will pull diaphragm (10) down. The pushrod (8) will be heard knocking against adjusting screw (9) when pulling off the hose. If necessary, check connector and seals. Replace injection pump, if diaphragm leaks.


The vacuum pump (A) supplies vacuum to the chamber below the diaphragm (10).

21 13 092



The altitude compensator (5) bleeds the vacuum underneath the diaphragm in relation to atmospheric pressure. Check vacuum in hose 5 a - see example.


21 13 080



This regulation is switched off by a vent valve (8) during EGR operation - see EGR layout in Group 11. The altitude compensator is discharged via air cleaner (7). Check installed position; elbow hose must face down.

21 13 059

Example:  
Hose 6 - atmospheric pressure 1000 mbar (absolute)  
Hose 5 a - vacuum - 230 mbar  
Constant reference pressure below the diaphragm 770 mbar (absolute)




21 13 094

- 1 Fuel feed
- 2 Fuel return
- 3 Charging air pressure connection
- 4 Vacuum supply
- 5 Altitude compensator
- 6 Discharge
- 7 Air cleaner


- A Vacuum pump
- B Throttle
- C Distributor

## 13-30




### 13 53 320 REMOVING AND INSTALLING/ REPLACING ALL COMBINATION FUEL INJECTORS


Remove oil trap.  
Loosen clamps.



Pull off plug 1 and 2.  
Unscrew holder for diagnosis plug.




Pull off leak oil hoses with a pliers.  
Unscrew coupling nuts on injection lines with  
Special Tool 13 5 020.  
Plug openings with caps.



Unscrew lines on injection pump.  
Reposition Special Tool 13 5 020 in good time  
to avoid bending the injection lines.

\* See Specifications



Installation:  
First tighten injection line (4).  
Tightening torque\*.



Unscrew combination fuel injector with Special  
Tool 13 5 320 and plug with cap.  
Run wire plug through special tool in case of  
the initial injection jet.

*Important!*

Wire should come out of opening as close as  
possible to the middle to avoid clamping or  
tearing off.



Installation:  
Coat threads with copper paste "CRC".  
Tightening torque\*.  
Bleed fuel system — see 13 51 320.


Replacing:

Combination fuel injectors can only be replaced  
complete — never disassembly or make adjust-  
ments.

\* See Specifications


## 13 53 ... FLUSHING INJECTION NOZZLE — Installed in Car —

Engines producing loud knocking noise indicate nozzle needle (5) not closing completely because of combustion residue.




### Components of Combination Fuel Injector:

- 1 Nozzle holder
- 2 Nozzle body
- 3 Feed bore
- 4 Pressure chamber
- 5 Nozzle needle
- 6 Leak oil line




**Finding Defective Injection Nozzle:**  
Start engine and unscrew a coupling nut on one injection line after the other with Special Tool 13 5 020. Knocking noise will stop, when coupling nut of defective nozzle is loosened.




Run engine to operating temperature. Operate speed lever from idle speed to higher speeds (approx. 4,000 rpm) several times to flush the nozzle. If necessary, remove and replace defective combination fuel injector — see 13 53 320.






**13 53 800 CHECKING INJECTION NOZZLE**  
— Combination Fuel Injector Removed—

Set up tester 00 2 540 on steady place.  
Clean combination fuel injector with gasoline and mount on pressure line.  
Loosen handwheel for pressure gage — see operating instructions.





Fill tank with diesel fuel or test oil\*.  
*Caution!*  
Never use gasoline — danger of explosion.



**a) Opening Pressure Test:**  
*Caution!*  
Keep hands and fingers away from nozzle ejection — danger of injury!  
Press manual lever down slowly until injection nozzle ejects fuel.  
Read ejection pressure\* on pressure gage. Value must not be less than the minimum ejection pressure.  
The difference in opening pressure among the six injection nozzles may be max. 15 bar (213 psi).



*Important!*  
Press and release the manual lever slowly when working with a pressure gage, to avoid damaging the pressure gage.

\* See Specifications



**b) Injection Nozzle Leak Test:**  
Press down manual lever slowly and hold at point 20 bar (284 psi) below opening pressure. No drop of fuel should drip from nozzle within 10 seconds.

**c) Vibration Humming Test:**  
Tighten handwheel for pressure gage in tests c) and d).  
Operate lever 1 to 2 times per second.  
A perfect condition injection nozzle will hum (vibrate) while ejecting fuel.




**d) Spray Pattern Test:**  
Operate lever with short, fast strokes.  
Fuel must have an as tight as possible tapered spray pattern.  
Ejection must stop abruptly at end of each stroke.

If the results of one of the tests a) through c) are negative, the combination fuel injector has to be replaced.  
If only the results of test d) are negative, the combination fuel injector does NOT have to be replaced.




## 13 - 33




### 13 71 000 REMOVING AND INSTALLING AIR CLEANER

Unscrew hose clamps and nuts.




Turn intake neck 90° and pull off toward front — note arrow.



Lift out filter housing.


*Installation:*

Place housing exactly on rubber mounts.



### 13 72 001 REPLACING AIR FILTER CARTRIDGE

Turn intake neck 90° and pull off toward front. Open clamps and take out filter cartridge.



With the cover open insert filter cartridge in the middle (see note on housing) so that arrow points in direction of air flow. Close and secure cover.

13 00 054 ADJUSTING ENGINE IDLE SPEED / CO TEST


Requirements for All Adjustments:  
Engine at operating temperature, i.e. oil temperature at least 60° C (140° F).  
Ignition timing and valve clearance correct.  
All electric equipment switched off.  
BMW service test unit connected according to operating instructions.

1) Checking Engine Idle Speed\*\*

If nominal value is not reached, check idle control valve (1) and idle regulation control unit (2), replacing if necessary.



Note:

There is no adjusting screw for idle speed regulation.




2) CO Test:

Pull off hose (1) on throttle housing.  
Plugs are not inserted in open connections.




Unscrew screws (1).  
Connect Special Tools 13 0 070 and 13 0 100 on exhaust manifold.  
Check idle speed CO level\*.


\*\* See Nominal Value Microfiche




Disconnect oxygen sensor plug.



Drill hole in anti-tamper lock (1) with Special Tool 13 1 092.



Screw Special Tool 13 1 094 in anti-tamper lock.  
Drive special tool and anti-tamper lock out of air flow sensor with impact (1).




Adjust idle speed CO level\* with Special Tool 13 1 100.

\* See Nominal Value Microfiche


## 13 - 009

Install new anti-tamper lock (1) in air flow sensor.



13 00 014


Connect plug for oxygen sensor.




13 00 015

## 13-312

### 13 31 029 CHECKING FUEL DELIVERY PRESSURE





Install pressure gage 13 3 061 with connecting line and T-adaptor 13 3 064 in the fuel feed line, in front of fuel pressure regulator. Plug fuel return line with Special Tool 13 3 010.



Pull off fuel pump relay (1). Bridge terminals 87 and 30 with Special Tool 61 3 050. Check delivery pressure\*.

### 13 31 ... CHECKING FUEL DELIVERY RATE

Unscrew fuel return line and hold loose end in measuring glass 13 3 020.



Pull off fuel pump relay (1). Bridge terminals 87 and 30 with Special Tool 61 3 050. Check delivery rate\*.


\* See Specifications of Gr. 16

\* See Specifications of Gr. 16

# 13-319

## 13 31 030 REMOVING AND INSTALLING FUEL PUMP

Turn back protective caps (1).  
Loosen nuts (2 and 3) and take off cable.




28 13 012

Pinch suction hose (1) and pressure hose (2) with Special Tool 13 3 010. Cut open squeeze-hose clamp (3) and pull off hoses.



28 13 013

Unscrew bolt (1) and nuts (2).  
Remove fuel pump with filter.




28 13 014

Unscrew bolt (1) and take off clamp.




28 13 015



28 13 016

Loosen hose clamp (1) on fuel filter and pull off fuel hose.  
Remove rubber ring (2).  
*Installation:*  
Check direction of flow — IN and OUT are marked on filter.



28 13 017

Loosen hose clamp (1) on fuel pump and pull off fuel hose.  
Pull off rubber ring (3).

2 = Code number\*



20 13 311

*Installation:*  
Check code number (2)\*.

\* See Specifications


## 13-324

### 13 32 052 REMOVING AND INSTALLING FUEL FILTER

See "Removing and Installing Fuel Pump" --  
13 31 030.

*Installation:*

Check direction of flow (arrow).



20 13 321

## 13 41 ... MAKING BASIC ADJUSTMENT OF VDO IDLE CONTROL SYSTEM

### Requirements:


- Engine at operating temperature, i.e. oil temperature at least 60° C (140° F).
- Ignition timing and valve clearance correct.
- Air filter cartridge in perfect condition.
- All electric equipment switched off.
- Idle CO level correct.

### Note:

Basic adjustments are not made at certain intervals.




13 41 013




Connect tester 13 4 030 on car battery (B+/B-) and idle control valve.  
Set switch (2) to 140 Hz.  
Run engine at idle speed.  
Adjust idle speed to 700 ± 50 rpm with basic adjustment screw (1).

Remove tester 13 4 030.  
Connect plug from engine wire harness on idle control valve again.

## 13-411



28 13 061



13 41 012

## 13 41 000 REMOVING AND INSTALLING IDLE CONTROL VALVE

Loosen hose straps (1 and 2).  
Pull off plug (3).

Remove idle control valve.

Installation:

Check code number (4)\*.

Check idle speed\*.

Idle Control Valve with Adjusting Screw:

Disconnect retaining strap.

Loosen hose straps (1 and 2).

Pull off plug (3).

Remove idle control valve.

Installation:

Make basic adjustment.

Checking Idle Control Valve:

Apply battery voltage on idle control valve.  
Idle control valve must close and be tight.  
Idle control valve should be open when without voltage.


\* See Specifications and Nominal Values



# 13-418


## 13 41 010 REMOVING AND INSTALLING CONTROL UNIT FOR IDLE CONTROL VALVE

Open glove box.  
Pull out pins (1) of both retaining straps.




28 13 207

Disconnect cover (1).



733 13 082


Unscrew both screws on left and right sides of control unit.



28 13 026


Unscrew nuts (1).  
Pull off multiple pin plug (2).  
Remove control unit.

Installation:  
Check code number (3)\*.  
Check idle speed\*.



28 13 059

\* See Specifications and Nominal Value Microfiche



28 13 060

### Multiple Pin Plug Connections:


No.	mm <sup>2</sup>	Color	Connection To
1	0.5	BLRT	Idle control valve A
2	0.5	GNGE	Terminal 15
3	1.0	GN	DME contr. unit (pin 8)
4	0.5	BR	Terminal 31
5	0.5	BLSW	Idle control valve B
6	0.5	WS	Temp. switch 45°C/113°F
7	0.5	BLBR	Conn. transm. P
8	0.5	BLGE	Conn. transm. N
9	0.5	BLWS	Air conditioner
10	0.5	BLGN	Air temp. switch
11	0.5	BRRT	DME contr. unit (pin 13)
12	0.5	BRBL	DME contr. unit (pin 2)

### Wire Colors:

BL = Blue  
BR = Brown  
GE = Yellow  
GN = Green  
RT = Red  
SW = Black  
WS = White


## 13 51 200 REMOVING AND INSTALLING FUEL PRESSURE REGULATOR

Disconnect air hose (1) and fuel hose (2).




28 13 205

Unscrew bolts (1).  
Take off fuel pressure regulator.




23 13 011

Installation:  
Check seal (1), replacing if necessary.




28 13 51005

Installation:  
Check code number (1)\*  
(2) = Manufacturing date




28 13 51001

\* See Specification



13 31 013

Checking:  
Install pressure gage 13 3 060 with connecting line and T-adaptor 13 3 064 in fuel feed line, in front of fuel pressure regulator.



13 31 010


Pull off fuel pump relay (1).  
Bridge terminals 87 and 30 with Special Tool 61 3 050.  
Fuel injection pressure\*.

\* See Specifications/Nom. Value Microfiche


13 54 030 REMOVING AND INSTALLING THROTTLE HOUSING

Disconnect cables (1 ... 3).  
1 = Automatic transmission  
2 = Accelerator pedal  
3 = Cruise control


Installation:  
Adjust cables, see Groups 23, 35 and 65.





Disconnect water hoses (1 and 2).  
Disconnect air hoses (3 and 4).  
Installation:  
Filling and bleeding cooling system.



Disconnect hose (3).  
Pull off multiple pin plug (4) on throttle switch.




Unscrew nuts (1 ... 4) and take off throttle housing.




Installation:  
Replace gasket (1).



Unscrew bolts (1).  
Remove throttle switch (2).  
Installation:  
Adjust throttle switch 13 63 544.




Unscrew bolts (1) and take off cover (2).



Installation:  
Replace gasket.  
Check engine idle speed\* and CO\*.

\* See nominal value microfilm

## 13 54 051 REPLACING RETURN SPRINGS OF THROTTLE SHAFT



Disconnect cables (1 ... 3).


1 = Automatic transmission

2 = Accelerator pedal

3 = Cruise control

*Installation:*


Adjust cables — see Groups 24, 35 and 65.



Remove retainer (1).

Remove washer (2).

Disconnect linkage (3) on lever (4).



Lift and turn lever (1) to relax spring (3).

Take off lever (1).

*Installation:*

Check bearing sleeves (2), replacing if necessary.



Remove spring (1).



*Note:*

Check spring washer (1).




Disconnect spring (1).


Unscrew nut (2).

## 13-533



Take off washer (1) and lever (2).




Remove bushing (1) and spring (2).




Check corrugated washer (1) and plain washer (2).



Throttle Valve Basic Adjustment:  
Disconnect air hose on throttle housing.  
Mount dial gage 00 2 510 with extension (3) and holder 00 2 500 on throttle housing.  
Place dial gage tip on edge of throttle valve with pre-load.



Pull off anti-tamper lock (1) and loosen screw (2) until lever (3) no longer rests on screw (2).  
Screw in screw (2) until throttle valve starts to move.



Open throttle valve 0.2 mm (0.008") further with screw (1).  
Lock screw with clear lacquer.  
Install anti-tamper lock (2).  
Open and close throttle valve several times after finishing adjustment.  
Throttle valve must not hesitate.


Check adjustment of throttle switch.  
Check engine idle speed\* and CO level\*.

\* See Nominal Value Microfiche

## 13-613


### 13 61 000 REMOVING AND INSTALLING CONTROL UNIT

Open glove box.  
Pull out pins (1) of both retaining straps.



28 13 207

Unscrew trim panel.




733 13 082

Press back retainer (1) and pull off plug (2).  
Unscrew four mounting screws and take off control unit.




13 61 015


Connect plugs according to wiring diagram.



13 61 014




30 13 610



13 61 015

Installation:  
Check code number (1)\* and manufacturing date (2)\*.

\* See Specifications + Nom. Value Microfiche



# 13 62 000 REMOVING AND INSTALLING AIR FLOW SENSOR

Until Model '85:

Loosen hose clamp (1).

Unscrew nuts (2).

Pull off plug (3).


Pull air flow sensor out of air cleaner housing  
and remove.

4 = Code number\*




Installation:

Check seal (1), replacing if necessary.



Unscrew silent mounts (1 ... 3) on air flow  
sensor.

Check silent mounts, replacing if necessary.



Installation:

Check code number (1)\* and manufacturing  
date (2)\*.


Check engine idle speed\* and idle speed CO\*.

Check air flow sensor\*.

\* See Specifications and  
nominal value microfilm



## 13-622




13 62 000 REMOVING AND INSTALLING  
AIR FLOW SENSOR

From Model '86:

- Loosen hose strap (1).
- Loosen nuts (2).
- Pull off hose (4).
- Pull off plug (5).

13 62 006




- Cut off hose strap (3).
- Take off complete air cleaner.

*Installation:*


- Check rubber mount (1) and cushions (2),
- and check for correct seating.

13 62 007




- Open four clamps.
- Unscrew bolt (1).
- Separate housing sections.

13 62 008



- Unscrew nuts.

13 62 009




13 62 010

*Installation:*

- Check code number (1)\* and manufacturing date (2)\*.
- Check engine idle speed\* and idle speed CO level\*.
- Check gasket (3).
- Check air flow sensor\*.


\* See Specifications and Nominal Values

## 13-626




### 13 62 050 REMOVING AND INSTALLING/ CHECKING TEMPERATURE TIME SWITCH

The temperature time switch regulates the open time of the cold start valve in accordance with the coolant temperature.\*  
Open time (e.g. 8 seconds) and switching off temperature (e.g. 35° C/95° F) are stamped in the hexagon.



**Removing and Installing:**  
Pull off plug (1).  
Unscrew temperature time switch.  
**Installation:**  
Tightening torque\*.



**Installation:**  
Check code number (1)\*.  
Replace seal (2).  
FD = Manufacturing date  
Fill and bleed cooling system (Group 17).



**Checking:**  
Connect Jetronic test lead 61 1 440.  
Check nominal value\* with an ohmmeter.  
To check the entire temperature range, remove temperature sensor and place it in a water bath heated to testing temperature.  
Check resistance\* with an ohmmeter.

\* See Specifications


13 62 043

\* See Specifications

# 13-627


## 13 62 080 REMOVING AND INSTALLING/ CHECKING PRESSURE SENSOR

Pull off plug (1).  
Unscrew screw (2) and take off pressure sensor.  
FD = Manufacturing date




30 13 626

*Installation:*  
Check code number (1)\*.



30 13 627


*Checking:*  
There should be approx. 0 ohm between plug connections (1 and 2) with atmospheric pressure of  $\leq 880$  mbar.  
There should be approx.  $\infty$  ohms between plug connections (1 and 2) with atmospheric pressure of  $\geq 930$  mbar.



30 13 628

\* See Specifications

## 13-629




30 13 625

### 13 62 531 REMOVING AND INSTALLING/ CHECKING TEMPERATURE SENSOR FOR COOLANT


The temperature sensor measures the engine temperature and sends this information to the control unit in form of a resistance value. The resistance value drops as temperature rises (NTC).

- 1 Plug connection
- 2 Housing
- 3 NTC resistor




28 13 031

**Removing and Installing:**  
Pull off plug (1).  
Unscrew temperature sensor.  
**Installation:**  
Tightening torque\*.



13 62060


**Installation:**  
Check code number (1)\*.  
Replace seal (2).  
FD = Manufacturing date  
Fill and bleed cooling system (Group 17).



**Checking:**  
Connect Jetronic test lead 611 440.  
Check nominal value\* with an ohmmeter.  
To check the entire temperature range, remove temperature sensor and place it in a water bath heated to testing temperature.  
Check resistance\* with an ohmmeter.

\* See Specifications

## 13 63 544 ADJUSTING THROTTLE SWITCH



30 13 631


Check throttle switch.

There should be approximately 0 ohm betw. connections 2 and 18 when throttle is closed.

With the throttle wide open there must be approximately 0 ohm between connections 3 and 18.

LL = Idle

VL = Full throttle



28 13 063

Adjusting:


– Throttle Housing Removed –

There should be approximately 0 ohm betw. connections 2 and 18 when throttle is closed. Adjust by loosening screws (1) and turning the throttle switch.


Open throttle after finishing adjustments – resistance should rise immediately to  $\infty$  ohms. When releasing the throttle, the resistance must drop again to approximately 0 ohm.

## 13- 634

### 13 63 551 REMOVING AND INSTALLING THROTTLE SWITCH




Remove throttle switch 13 54 030.  
Unscrew screws (1).  
Take off throttle switch (2).



*Installation:*  
Check code number (1)\*.  
Adjust throttle switch 13 63 544.

\* See Specifications

# 13 64 030 REMOVING AND INSTALLING COLD START VALVE



28 13 053


Removing and Installing:  
Pull off plug (1).  
Unscrew fuel line (2).  
Unscrew bolts.  
Take off cold start valve.

## Installation:

Check code number (1)\*.  
Replace seal (2).


## Checking:

Unscrew cold start valve on intake housing.  
Fuel line remains connected.




13 64001

\* See Specifications




13 31 010

Checking - DME / E 28 /  
Unscrew cold start valve on intake housing.  
Fuel line remains connected.  
Pull off fuel pump relay (1).  
Bridge terminals 87 and 30 with Special Tool  
61 3 050.  
Fuel pump runs.



30 13 452

Leak Test:  
Check permissible leak rate\*.



30 13 453


Checking Fuel Flow Rate and Spray Angle:  
Hold cold start valve in measuring glass  
13 3 020.  
Plug Jetronic test lead 61 1 440 on cold start  
valve and connect with B + and B -.  
Check fuel flow rate\* and spray angle (1)\*.

\* See Specifications




# 13-643

## 13 64 501 REPLACING FUEL INJECTOR




Unscrew four mounting bolts (1) of injection pipe.  
Push up injection pipe until fuel injectors have cleared the guide on the intake manifold.

28 13 055



Pull off plug (1) on fuel injector.  
Lift out retainer (2) and pull fuel injector out of injection pipe.

28 13 056




30 13 122

### Installation:

Check O-rings (1), replacing if necessary.  
Check code number (2)\*.  
FD = Manufacturing date.  
Check position of plastic washer (3).  
Check color\* of plug receptacle (5) or injector guard (4).  
Only coat O-rings for installation with vaseline or SAE 90/SAE 80 gear lube.

\* See Specifications

## 13-701




### 12 63 051 REMOVING AND INSTALLING 0° C (32° F) TEMPERATURE SWITCH

E 28


Unscrew screws (1).  
Unscrew screws (2) on left and right sides.  
Pull off rubber guard.  
Fold cover forward.

Pull off plug (1).  
Unscrew temperature switch.  
*Installation:*  
Torque: max. 30 Nm (22 ft. lbs.).



*Installation:*  
Check code number (1)\* and switching  
point (2)\*.


20 13 633



*Checking:*

Connect ohmmeter (M 06) on temperature  
switch.  
Ohmmeter should display about 0 ohm with  
temperature < - 8° C (+ 18° F).  
Ohmmeter should display about ∞ ohms with  
temperature > 4° C (39° F).

## 13-704



### 12 63 060 REMOVING AND INSTALLING 45° C (113° F) TEMPERATURE SWITCH


Pull off plug (1).  
Remove temperature switch.

#### Installation:

Tightening torque: max. 30 Nm (22 ft. lbs.).  
Fill and bleed cooling system (Group 17).

#### Installation:

Check code number (1)\* and switching point  
(2)\*.



20 13 633



#### Checking:

Connect ohmmeter (M 06) on temperature  
switch.


Ohmmeter should display approximately 0 ohm  
for temperature < 30° C (86° F).

Ohmmeter should display approximately ∞  
ohms for temperature > 48° C (118° F).

20 13 634

\* See Specifications


## 13-01




### 13 00 020 CHECKING ADAPTIVE PILOT CONTROL (Integrated in DME Control Unit Since 1985 Models)

Testing Requirements:  
Engine, oxygen sensor and catalytic converter have operating temperature.  
Oxygen sensor is heated electrically.  
Unscrew screws (1).  
Mount exhaust tester 13 0 090 on exhaust manifold with adapter 13 0 100.  
Connect BMW service test unit.


Remove anti-tamper lock.  
Remove air cleaner with air flow sensor.  
Drill hole in anti-tamper lock with Special Tool 13 1 092.



13 00 012




13 00 013



13 00 016

Pull off and plug vacuum hose on fuel pressure regulator.  
Oxygen sensor must regulate the CO level back to nominal value\* after a brief rise.  
Oxygen sensor is okay.


\* See nominal value microfiche



13 00 011



13 00 015




13 00 011

Tighten air control screw in air flow sensor completely with Special Tool 13 1 100 richer mixture.  
Run engine at idle speed -- CO level will be regulated back to nominal value\*.

Disconnect oxygen sensor plug.  
CO level rises to approx. 2.0 % by volume.  
Note instantaneous actual value.  
Stop engine.  
Disconnect battery ground lead briefly.  
This will cancel the value stored in memory of DME control unit.

Start engine.  
If actual CO level value is considerably higher, adaptive pilot control is working.  
Connect vacuum hose again.  
Adjust CO level to nominal value\* with Special Tool 13 1 100.  
Connect oxygen sensor.  
Remove exhaust tester.



13 00 014

Remove and install air cleaner with air flow sensor.  
Insert new anti-tamper lock (1) in air flow sensor.

\* See nominal value microfiche


## 13-05

### 13 00 050 CHECKING / ADJUSTING ENGINE PERFORMANCE (9.84 ... 9.85)


Requirements for All Adjustments:  
Engine at operating temperature, which means  
oil temperature at least 60° C (140° F).  
Ignition timing and valve clearance okay.  
All electric equipment switched off.  
BMW service tester connected to instructions.  
Routine checking and adjusting is not neces-  
sary -- adaptive initial control.  
Following adjustments are only necessary for  
problem cases (troubleshooting).

#### 1) Engine Idle Speed

Check engine idle speed\*\*  
Check idle speed control valve, if nominal  
value is not reached.  
Check intake system for leaks.  
*Note:*  
There is no control screw for idle speed  
adjustments.




13 41 002




#### 2) CO Level Test (Basic Adjustment)

Disconnect oxygen sensor plug.  
Stop control unit power supply briefly (this  
stops operation of the adaptive initial control  
system).

Unscrew plugs (1).  
Connect Special Tools 13 0 090 and 13 0 100  
on the exhaust manifold.  
Check CO level at idle speed.  
Remove anti-tamper lock -- see 13 - 010.



\*\* See Nominal Value Microfiche



Switch off extraction system for time of  
measuring.  
Make sure that there are no faults on the engine,  
ignition or fuel injection systems (see trouble-  
shooting) before correcting the CO level.  
Remove end cap -- see 13 00 054.  
Adjust CO level\* with Special Tool 13 1 100  
applied on control screw in air flow sensor.

Check adaptive initial control see 13 00 020.


\* See Nominal Value Microfiche

## 13-010

### 13 00 054 ADJUSTING ENGINE IDLE SPEED / CO TEST


Requirements for All Adjustments:  
Engine at operating temperature, i.e. oil temperature at least 60°C (140°F).  
Ignition timing and valve clearance correct.  
All electric equipment switched off.  
BMW service test unit connected to operating instructions.

1) Engine Idle Speed:  
Check engine idle speed\*\*.  
If specified value is not reached, check idle control valve (1) and idle speed regulation control unit (2), replacing if necessary.  
*Note:*  
There is no adjusting screw for idle speed regulation.




30 11 400

2) CO Test:  
Pull off hose (1) on solenoid (2).  
Do not insert plugs in open connections.



13 00 017

Unscrew bolts (1).  
Connect Special Tool 13 0 070 on exhaust manifold with adapter 13 0 100.  
Check idle speed CO level\*\*.



13 00 040


\*\* See Nominal Value Microfilm



13 00 015

Pull off oxygen sensor plug.


Remove air cleaner with air flow sensor.  
Drill hole in anti-tamper lock with Special Tool 13 1 092.



13 1 092

13 00 012

Screw Special Tool 13 1 094 in anti-tamper lock.  
Knock special tool and anti-tamper lock out of air flow sensor with impact (1).  
Install air cleaner with air flow sensor.  
Run engine at idle speed.




13 1 094

1

13 00 013

Adjust CO to specified value\*\* with Special Tool 13 1 100.  
Connect oxygen sensor.  
Remove CO tester.




13 1 100

13 00 011


\*\* See Nominal Value Microfilm

## 13-011



13 00 014

Remove air cleaner with air flow sensor.  
Insert new anti-tamper lock (1) in air flow sensor.  
Install air cleaner with air flow sensor.




13 00 015

Connect oxygen sensor plug.




## 13-313




### 13 31 029 CHECKING FUEL DELIVERY PRESSURE

Install pressure tester 13 3 060 with connecting hose and t-adaptor 13 3 064 in fuel feed line — in front of fuel pressure regulator. Plug fuel return hose with Special Tool 13 3 010.




### 13 31 ... CHECKING FUEL DELIVERY RATE

Disconnect fuel return hose and hold loose end in measuring glass 13 3 020.



Pull off fuel pump relay (1). Bridge terminals 87 and 30 with Special Tool 61 3 050. Check delivery pressure\*.



Pull off fuel pump relay (1). Bridge terminals 87 and 30 with Special Tool 61 3 050. Check delivery rate\*.


\* See Specifications of Group 16

\* See Specifications of Group 16

## 13-319


### 13 31 030 REMOVING AND INSTALLING FUEL PUMP

Push back protective caps (1).  
Unscrew nuts (2 and 3) and take off wires.




Pinch suction hose (1) and pressure hose (2) with Special Tool 13 3 010.  
Loosen hose clamps (3) and pull off hoses.


*Note:*  
Do not use squeeze-hose clamps on pressure hose.



Unscrew bolt (1) and nuts (2).  
Take off fuel pump with filter.



Unscrew bolt (1) and take off clamp.




Loosen hose clamp (1) on fuel filter and pull off fuel hose.

Remove rubber ring (2).

*Installation:*

Check direction of flow – IN and OUT are marked on filter.

Do not use a squeeze-hose clamp.



Loosen hose clamp (1) on fuel pump and pull off fuel hose.

Pull off rubber ring (3).

2 = Code number\*



*Installation:*


Check code number (1)\*.

\* See Specifications

## 13-324


### 13 32 052 REMOVING AND INSTALLING FUEL FILTER

See "Removing and Installing Fuel Pump" —  
13 31 030.




20 13 321

*Installation:*  
Check direction of flow (arrow).




**13 41 000 REMOVING AND INSTALLING  
IDLE CONTROL VALVE**

Loosen hose clamps (1 and 2).  
Remove air hose (3).



Pull off plug (1).  
Loosen hose clamps (2 and 3) and pull off  
hoses.  
Unscrew nut (4) and take off idle control  
valve (5).



*Installation:*  
Check code number\*.  
Check rubber mount (1) for cracks or damage,  
replacing if necessary.  
Check idle speed\*.

**Checking Idle Control Valve:**  
Apply battery voltage\* on idle control valve.  
Idle control valve should close and be tight.  
Idle control valve should be open without  
voltage supply.

\* See Specifications and  
Nominal Value Microfiche

## 13 41 000 REMOVING AND INSTALLING IDLE CONTROL VALVE (Since 1985 Models)

Pull off plug (1).  
Disconnect retaining strap (2).  
Pull off idle control valve on hoses and  
remove.

### Installation:

Check code number (1)\*.  
Check idle speed\*.

13 41 002

### Note:


Whether or not the idle control valve is  
running can be felt by taking hold of valve  
with a hand (cycled power supply).

### Mechanical Test:



The rotating piston (1) in the idle control valve  
must move when turning the idle control valve  
suddenly.

13 41 003

\* See Specifications and  
Nominal Value Microfiche



13 41 001




13 41 004

### Electric Test:


Measure resistance between terminals (1 and 3).  
Nominal value: approx. 40 ohms.  
Measure resistance between terminals (2 and 1)  
or (2 and 3).  
Nominal value: each approx. 20 ohms.

### Dynamic Test:

Remove idle control valve.  
Plug remains connected.  
Open rotating piston (1) completely, or close.  
Turn on ignition.  
Rotating piston must take on a position of  
approx. 50 % the cross section opening and  
stay there.



13 41 005




## 13-414

Testing Procedures for Idle Speed Surging and Idle Speed of  $\leq 750$  rpm, But Perfect (Checked) Idle Control Valve:

### Requirements:

Engine at operating temperature.  
No leak in intake system.  
Idle speed CO level\* correct.  
All equipment (lights, air conditioner, etc.) switched off.  
BMW service test unit or digital tester connected.  
There is no oil dilution,

Oil dilution = gasoline in engine oil; possible in cold season of year and when car operated chiefly in stop-and-go traffic.



If the idle speed is  $\leq 750$  rpm, the throttle valve basic setting must be changed.

Loosen nut (1).


Adjust connecting plate (2) with stop (3) (engine running) until the idle speed is 800  $\pm$  50 rpm.

### Note:

If the fault is not eliminated after adjusting the throttle valve, the throttle valve must be returned back to its original setting.

Cars with Active Carbon Filter Venting (US / J):


There must not be vacuum in hose (4) at idle speed in spite of possible adjusted throttle valve — check.



28 12 001

Connect universal adapter between DME control unit and engine wire harness.  
Connect plug chambers (2/3/5) with each other (idle and full load contacts closed).  
Run engine at idle speed.

Proceed with troubleshooting, if idle speed is  $\geq 750$  rpm (fault is not within the idle regulation system).




\* See Nominal Value Microfilm

13 41 007 J

## 13-418


### 13 41 010 REMOVING AND INSTALLING CONTROL UNIT FOR IDLE CONTROL VALVE

Open glove box.  
Pull out pins (1) of both retaining straps.




28 13 207

Disconnect cover (1).




733 13 082

Unscrew both screws on left and right  
sides of control unit.




28 13 026

Unscrew nuts (1).  
Pull off multiple pin plug (2).  
Remove control unit.  
*Installation:*  
Check code number (3)\*.  
Check idle speed\*.



28 13 059

\* See Specifications and  
Nominal Value Microfiche



28 13 060


#### Multiple Pin Plug Connections:

No.	mm <sup>2</sup>	Color	Connection To
1	0.5	BLRT	Idle control valve A
2	0.5	GNGE	Terminal 15
3	1.0	GN	DME contr. unit (pin 8)
4	0.5	BR	Terminal 31
5	0.5	BLSW	Idle control valve B
6	0.5	WS	Temp. switch 45°C/113°F
7	0.5	BLBR	Conn. transm. P
8	0.5	BLGE	Conn. transm. N
9	0.5	BLWS	Air conditioner
10	0.5	BLGN	Air temp. switch
11	0.5	BRRT	DME contr. unit (pin 13)
12	0.5	BRBL	DME contr. unit (pin 2)

#### Wire Colors:


BL = Blue  
BR = Brown  
GE = Yellow  
GN = Green  
RT = Red  
SW = Black  
WS = White






### 13 51 200 REMOVING AND INSTALLING FUEL PRESSURE REGULATOR


Disconnect air hose (1) and fuel hose (2).



Unscrew bolts (1).  
Remove fuel pressure regulator.



28 13 51005




28 13 51001


*Installation:*  
Check seal (1), replacing if necessary.

*Installation:*  
Check code number (1)\*.  
(2) = Manufacturing date

\* See Specifications



*Checking:*  
Install pressure tester 13 3 060 with connecting hose and T-adaptor 13 3 064 in the fuel feed line — in front of fuel pressure regulator.



Pull off fuel pump relay (1).  
Bridge terminals 87 and 30 with Special Tool 61 3 050.  
Check fuel injection pressure\*.

\* See Specifications  
and Nominal Value Microfiche

## 13 - 524

### 13 54 030 REMOVING AND INSTALLING THROTTLE HOUSING

Disconnect cables (1 ... 3).



1 = Automatic transmission

2 = Accelerator pedal


3 = Cruise control motor

Installation:

Adjust cables — see Groups 24/35/65.




Loosen hose clamp (1) and push back hose (2).  
Pull off plug (3) on throttle switch.



Unscrew screws (1 ... 4).


Take off throttle housing.

5 = Gasket



Installation:

Replace gasket (1).



Unscrew screws (1 and 2).

Take off throttle switch.


Installation:

Adjust throttle switch 13 63 544.

Connect vacuum hoses again.


Check engine idle speed\* and CO\*.

## 13 - 534




### 13 54 051 REPLACING THROTTLE SHAFT RETURN SPRINGS - Throttle Housing Removed -


Unscrew nut (1).  
Remove retainer (2).  
Take off connector (3).  
*Important!*  
Watch out for shims (4) on both sides of the connector.




Unscrew nut (1).  
Pull off lever (2) with shim and spring.  
*Important!*  
Be careful not to turn the attached throttle switch beyond the permissible gap angle when unscrewing the nut.  
*Installation:*  
Use spacer between lever (2) and housing.  
Preload return spring with approx. 1/2 turn.



Disconnect connecting rod (1).



Remove lever (1) with plastic sleeve (2) and spring (3).  
*Caution!*  
Strong spring force.  
*Installation:*  
Preload spring with about 1/2 turn.




Basic Throttle Valve Adjustment:  
Adjustments are only necessary after repairing.  
Loosen screw (1).  
Adjust connector (2) with stop (3) until there is slight clearance between housing and throttle valve.


## 13-613

### 13 61 000 REMOVING AND INSTALLING CONTROL UNIT

Open glove box.  
Pull out pins (1) of both retaining straps.




28 13 207




733 13 082

Unscrew trim panel.




13 61 015


Press back retainer (1) and pull off plug (2).  
Unscrew four mounting screws and take off  
control unit.



13 61 014



30 13 610




13 61 017

*Installation:*  
Check code number (1)\* and manufacturing  
date (2)\*.

\* See Specifications + Nom. Value Microfiche


## 13-623



30 13 622


### 13 62 000 REMOVING AND INSTALLING AIR FLOW SENSOR

Remove and install air cleaner  
Take air flow sensor off of air cleaner.



30 13 623

Unscrew silent mounts (1 ... 3) on air flow sensor.  
Check silent mounts, replacing if necessary.



30 13 624

#### *Installation:*


Check code number (1)\* and manufacturing date (2)\*.  
Check engine idle speed\* and idle speed CO\*.  
Check air flow sensor\*.

\* See Specifications and nominal value microfilm


## 13-626

### 13 62 050 REMOVING AND INSTALLING/ CHECKING TEMPERATURE TIME SWITCH

The temperature time switch regulates the open time of the cold start valve, depending on the coolant temperature.  
The open time (e.g. 8 sec.) and switching-off temperature (e.g. +35°C / 95°F) are stamped on the hexagon.




320 13 158



**Removing and Installing:**  
Pull off plug (1).  
Unscrew temperature time switch.  
**Installation:**  
Tightening torque\*.

28 13 030



13 62 042

**Installation:**  
Check code number (1)\*.  
Replace seal (2).  
FD = Manufacturing date  
Fill and bleed cooling system (Group 17).




611440

**Checking:**  
Connect Jetronic test lead 61 1 440.  
Check nominal value\* with ohmmeter.  
To check the entire temperature range, remove and place temperature sensor in a water bath heated to testing temperature.  
Check resistance\* with an ohmmeter.

\* See Specifications

13 62 043 \* See Specifications

# 13 62 531 REMOVING AND INSTALLING/ CHECKING COOLANT TEMPERATURE SENSOR



30 13 625


The temperature sensor measures engine temperature and sends this information to the control unit in the form of a resistance value. The resistance value drops as temperature rises (NTC).

- 1 = Plug connection
- 2 = Housing
- 3 = NTC resistor




28 13 031

**Removing and Installing:**  
Pull off plug (1).  
Unscrew temperature sensor.  
**Installation:**  
Tightening torque\*.



13 62060

**Installation:**  
Check code number (1)\*.  
Replace seal (2).  
FD = Manufacturing date  
Fill and bleed cooling system (Group 17).




**Checking:**  
Connect Jetronic test lead 611 440.  
Check nominal value\* with ohmmeter.  
To check the entire temperature range, remove and place temperature sensor in a water bath heated to testing temperature.  
Check resistance with an ohmmeter\*.

\* See Specifications

13 62062 \* See Specifications



## 13-632




30 13 631

### 13 63 544 ADJUSTING THROTTLE SWITCH

Check throttle switch.  
There should be approximately 0 ohm between connections 2 and 18 with a closed throttle valve.  
There should be approximately 0 ohm between connections 3 and 18 with the throttle valve wide open.


LL = Idle speed  
VL = Full load



Checking/Adjusting Throttle Potentiometer:  
Pull off multiple-pin plug on transmission control unit.  
Connect test adapter with test lead between control unit and wire harness.  
Turn on ignition.  
Accelerator pedal in full load position as well as kickdown.


#### Transmission Control Unit:

Measure and note power supply value between terminals 9 (+) and 6 (-).  
Measure and note power supply value between terminals 7 (+) and 6 (-).  
The adjusting voltage should be  $0.22 \pm 0.04$  V less than the power supply voltage value.




28 13 033

Adjusting:  
There should be approximately 0 ohm between connections 2 and 18 with a closed throttle valve.  
Adjust by loosening screws (1) and turning the throttle switch.  
Open throttle valve after finishing the adjustment — resistance must rise immediately to  $\infty$  ohms.  
The resistance should drop back to approx. 0 ohm after releasing the throttle valve.



28 13 63 003

Adjusting Idle Speed Switch:  
Pull off rubber protective cap.  
Pull off plugs (1 and 2).  
Connect ohmmeter on plug connections.  
Loosen screws (4 and 3).  
Move switch until ohmmeter displays approx. 0 ohm.  
Tighten screws (4 and 3).  
Operating the throttle valve must cause the idle speed switch to switch immediately and have a resistance of approx.  $\infty$  ohms.




13 63 007

Adjusting:  
Correct by loosening screws (2) of throttle potentiometer and turning the throttle potentiometer.

- Checking Potentiometer:  
The voltage on the test point of the potentiometer must rise linear up to the adjusting value when opening the throttle valve from the idle stop to the full load stop.
- The throttle valve lever must bear on the full load stop when the accelerator pedal is floored (including kickdown).

## 13 - 633



### 13 63 551 REMOVING AND INSTALLING THROTTLE SWITCH


Pull off multiple pin plug (3).  
Unscrew screws.  
Remove throttle switch (2).



#### Installation:


Check code number (1)\*.  
Adjust throttle switch 13 63 544.

\* See Specifications



# 13 64 030 REMOVING AND INSTALLING COLD START VALVE

Removing and Installing:  
Pull off plug (1).  
Unscrew fuel line (2).  
Unscrew bolts.  
Take off cold start valve.




## Installation:


Check code number (1)\*  
Replace seal (2).

Checking:  
Unscrew cold start valve on intake housing.  
Fuel line remains connected.


13 64001



Checking -- DME / E 28 /  
Unscrew cold start valve on intake housing.  
Fuel line remains connected.  
Put off fuel pump relay (1).  
Bridge terminals 87 and 30 with Special Tool  
61 3 050.  
Fuel pump runs.




Leak Test:  
Check permissible leak rate\*.



Checking Fuel Flow Rate and Spray Angle:  
Hold cold start valve in measuring glass  
13 3 020.  
Plug Jetronic test lead 61 1 440 on cold start  
valve and connect with B + and B  
Check fuel flow rate\* and spray angle (1)\*.

\* See Specifications

\* See Specifications



# 13 64 501 REPLACING ONE FUEL INJECTOR


Unscrew four screws on injection tube.

*Installation:*

Mount ground wire with screw (1).




Push up injection tube (1) until fuel injectors have cleared the guide in the intake manifold.



Pull off plug (1).

Lift out retainer (2) and remove fuel injector.



*Installation:*

Check O-rings (1), replacing if necessary.

Check code number (2)\*.


FD = Manufacturing date.

Check position of plastic washer (3).

Check color\* of plug receptacle (5) or injector guard (4).

Only coat O-rings for installation with vaseline or SAE 90/SAE 80 gear lube.

## 13-701



### 12 63 051 REMOVING AND INSTALLING 0° C (32° F) TEMPERATURE SWITCH

Pull off plug (1).


Unscrew temperature switch.

*Installation:*

Tightening torque: max. 30 Nm (22 ft. lbs.).

*Installation:*

Check code number (1)\* and switching point (2)\*.



2013613



2013634

*Checking:*

Connect ohmmeter (M 06) on temperature switch.

Ohmmeter should display approximately 0 ohm for temperature < - 8° C (+ 18° F).

Ohmmeter should display approximately ∞ ohms for temperature > 4° C (39° F).



### 12 63 060 REMOVING AND INSTALLING 45° C (113° F) TEMPERATURE SWITCH

Pull off plug (1).

Remove temperature switch.


*Installation:*

Tightening torque: max. 30 Nm (22 ft. lbs.).


Fill and bleed cooling system (Group 17).

*Installation:*

Check code number (1)\* and switching point (2)\*.



2013613



*Checking:*

Connect ohmmeter (M 06) on temperature switch.


Ohmmeter should display approximately 0 ohm for temperature < 30° C (86° F).

Ohmmeter should display approximately ∞ ohms for temperature > 48° C (118° F).

2013634

\* See Specifications

\* See Specifications



## DESCRIPTION:

There will be vacuum in hose (4) from partial load on (not at idle speed).

A thermo valve switches the vacuum through to the flushing air control valve as from a coolant temperature of  $\geq 46^{\circ}\text{C}$  ( $115^{\circ}\text{F}$ ).

With vacuum supply the flushing air control valve switches and the active carbon filter is flushed with fresh air depending on speed and temperature.

## ACTIVE CARBON FILTER VENT – HOSE ROUTING AND COMPONENTS

1 = Thermo valve; tightening torque max. 15 Nm (11 ft. lbs.)  
 opens  $\geq 43 \pm 3^{\circ}\text{C}$  ( $109 \pm 5^{\circ}\text{F}$ ) – opens with rising temperature  
 switching temperature  
 closes  $\leq 33 \pm 3^{\circ}\text{C}$  ( $91 \pm 5^{\circ}\text{F}$ )

2 = Flushing air control valve

3 = Hose to active carbon filter

4 = Hose to throttle housing

5 = Check valve

Connections on thermo valve must not be mixed up  
 – center connection for throttle housing.

## TROUBLESHOOTING ELECTRONIC IDLE CONTROL (VDO)

Testing Requirements:

Battery charged — battery voltage at least 11.5 volts.

Components must have ambient temperature ( $23 \pm 5^{\circ}\text{C}$  /  $73 \pm 9^{\circ}\text{F}$ ).

Specified multimeter functions (for example, M 01) refer to the BMW SERVICE TEST.

Testing is performed on the disconnected control unit plug for electronic idle control.

The following test procedures do not consider outside effects on the electronic idle control system.

1.) Checking Power Supply and Ground of Idle Control Unit:

Connect voltmeter (M 01) between term. 2 and ——— no —→ Check green/yellow wire for breaks with ohmmeter (M 06) — see wiring diagram.  
car ground point.

Turn on ignition.

Eliminate breaks.

Voltmeter displaying at least 9 volts?

yes

Connect voltmeter (M 01) between term. 2 and ——— no —→ Check brown wire for breaks with ohmmeter  
term. 4. (M 06) — see wiring diagram.

Turn on ignition.

Eliminate breaks.

Voltmeter displaying at least 9 volts?

yes

Power supply and ground of idle control unit are  
okay!



## 2. Checking Speed Signal and Idle Speed Signal for Idle Speed Control Unit

### a) Speed Signal

Terminal 3 must have "terminal 1 signal" with the engine running.

### b) Idle Speed Signal

Connect ohmmeter (M 06) between \_\_\_\_\_ terminals 4 and 12. no → Adjust or replace throttle switch.  
Adjust cable.  
Is voltmeter displaying at least 9 volts?  
Nominal value: 0 ohm.


yes

Depress accelerator pedal several centimeters. no → Adjust or replace throttle switch.  
Adjust cable.  
Is voltmeter displaying approximately "0" volt?

yes

Idle speed signal for idle speed control unit is okay!

## 3.) Checking Idle Valve



\* See Specifications

\*\* Engine oil temperature at least  $60^{\circ}\text{C}$  ( $140^{\circ}\text{F}$ )

## 4.) Checking Periphery for Air Conditioner Speed


Connect voltmeter (M 01) between term. 4 and ——— no —→ Check blue/white wire for breaks with  
term. 9. ohmmeter (M 06).  
Turn on ignition. Eliminate breaks.  
Turn on air conditioner.  
Voltmeter displaying at least 9 volts?

### *Important!*


After selecting a driving range (cars with automatic transmission) there will always only be regulation of the nominal idle speed =  $700 \pm 50$  rpm (priority circuit).

## 5.) Checking Periphery for Warm-up Speed

## a) Coolant Temperature Switch



b) Air Temperature Switch



## 6.) Priority Circuit

(Car with automatic transmission)  
 Connect voltmeter (M 01) between term. 4 and  
 term. 8.  
 Turn on ignition.  
 Move selector lever on automatic transmission  
 to "P".  
 Voltmeter displaying at least 9 volts?

no

→ Check blue/brown wire for breaks with ohmmeter  
 (M 06) and eliminate breaks.  
 Check selector lever switch, replacing if necessary.

(Car with manual transmission)  
 Connect voltmeter (M 01) between term. 4 and  
 term. 7.  
 Turn on ignition.  
 Voltmeter displaying at least 9 volts?

no

→ Eliminate breaks in blue/yellow wires (from  
 terminal 7 to terminal 2).

### Important!

After selecting a driving range (cars with automatic transmission) there  
 will always only be regulation of the nominal idle speed = 700 ± 50 rpm.

1) Cold engine does not start (oil temp.  $\leq 20^{\circ}\text{C}$  /  $68^{\circ}\text{F}$ )

2) Engine starts, but stops again

3) Cold engine hard to start (oil temp.  $\leq 20^{\circ}\text{C}$  /  $68^{\circ}\text{F}$ )

4) Warm engine does not start (oil temp.  $\leq 60^{\circ}\text{C}$  /  $140^{\circ}\text{F}$ )

5) Warm engine hard to start (oil temp.  $\leq 60^{\circ}\text{C}$  /  $140^{\circ}\text{F}$ )

6) Erratic idling during warm-up phase

7) Idle speed not correct

8) Splashing in intake

9) Hesitation while accelerating

10) Knock while accelerating

11) Hesitation while coasting

12) Misfiring at constant engine speed

13) Poor acceleration/final power output

14) Fuel consumption too high

15) CO/HC values not correct

## 13 - 900

### TROUBLESHOOTING FUEL INJECTION

— See application information on next page.

#### Testing Requirements:

Engine in perfect running condition (timing, compression, oil carbon deposits, etc.).

Starting system in perfect condition (battery voltage, starter, ignition lock, etc.).

Correct fuel in tank (octane rating, leaded/unleaded, dirt, etc.).

Connections and plugs correct according to the wiring diagram.

See engine electronics troubleshooting in Group 12 for other test points.

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	Test Position	Job No.	Page	
X			X	X				X				X	X	X						1	Fuel pressure (injection pressure)	13 51 200	
		X		X				X				X								2	Fuel pressure (pump pressure)	13 31 029	
		X		X								X		X						3	Fuel pressure regulator	13 51 200	
																				4			
																				5			
X	X		X	X			X	X		X	X	X	X	X						6	Fuel injector	13 64 501	
X		X											X	X						7	Cold start valve	13 64 030	
																				8			
		X											X							9	Temperature time switch	13 62 050	
					X							X	X							10	Coolant temperature sensor	13 62 531	
														X						11			
																				12	Throttle switch	13 63 544	
																				13			
		X		X		X				X										14	Throttle housing	13 54 051	
																				15	Throttle positioner	13 54 130	
X	X		X						X	X		X	X							16	Control unit (DME or L-Jetronic)	13 61 000	
X			X									X	X							17	Air flow sensor	13 62 000	
																				18			
																				19			
						X														20	Temperature switch (idle control)		
							X													21			
						X														22	Electric idle control valve	13 41 000	
																				23	Control unit (idle control)	13 41 010	
																				24			
																				25			
																				26			
																				27			
X			X																	28	Fuel pump relay/master relay		
								X				X		X						29	Oxygen sensor	Group 11	
																				30			



## TEST POSITIONS FOR FUEL INJECTION TROUBLESHOOTING CHART

### Note:


These points have been compiled in view of the greatest probability, so that it is quite possible to have to perform additional tests depending on circumstances.

The testing instructions refer to the "BMW service tester", e.g. engine test, test step 05 (P 05) or multimeter functions (M).

See operating instructions of the BMW service tester for connections.

### Test Positions 1, 2 and 3 – FUEL PRESSURE

#### a) No Pressure



\* See Specifications  
\*\* See Wiring Diagram

## 13 – 902

### b) Fuel Pressure Too High

Vacuum hose to or on pressure regulator → Check fuel return line – routing, flow. → Pressure regulator defective – replace, see 13 51 200 in Group 13.

### c) Fuel Pressure Too Low

Check fuel feed line – routing and flow. → Check flow in fuel filter. → Check filter screen on fuel intake, cleaning if necessary – see 16 12 000 in Group 16.


↓

Check pressure regulator, replacing if necessary – see 13 51 200 in Group 13.

\* See Specifications

\*\* See Wiring Diagram

## Test Position 6 - FUEL INJECTORS



\* See Specifications

\*\* See Wiring Diagram

Test Position 7 - COLD START VALVE

Check code number\* → Replace cold start valve.  
 Check resistance\*.

↓  
 Power supply\*\* via term. 50 (greater than 9 volts while starting).  
 Ground supply\*\* via temperature time switch (and 0° C / 32° F temp. switch).

↓  
 Remove cold start valve (fuel line remains connected) → Replace cold start valve.  
 Plug Jetronic test lead 61 1 440 on cold start valve and connect with B + or B -  
 Hold cold start valve in measuring glass 13 3 020.  
 Operate electric fuel pump.  
 Cold start valve ejecting fuel?  
 Spray angle\* and flow rate\* okay?


↓  
 Pull off Jetronic test lead 61 1 440 on cold start valve while electric fuel pump is still running. → Replace cold start valve.  
 Cold start valve must stop fuel flow.  
 Does cold start valve stop fuel flow?

↓  
 Leak Test: → Replace cold start valve.  
 A leak rate\* of max. 0.3 cc per minute is permissible with electric fuel pump running and Jetronic test lead 61 1 440 disconnected.

\* See Specifications


\*\* See Wiring Diagram

## Test Position 9 - TEMPERATURE TIME SWITCH



NOMINAL VALUE TABLE				
Version	Temperature		Resistance Measured in Ohms Between	
	Below °C	Above °C	Term. G and Ground (Housing)	Term. W and Ground (Housing)
15° C 8 s	+ 10	+ 20	50 ... 70 50 ... 70	0 ∞
35° C 8 s	+ 30	+ 40	25 ... 40 50 ... 80	0 100 ... 200
35° C 12 s	+ 30	+ 40	25 ... 80 50 ... 100	0 200 ... 400

\* See Specifications.  
\*\* See Wiring Diagram

Test Position 10 - COOLANT TEMPERATURE SENSOR

\* See Specifications

\*\* See Wiring Diagram

## Test Position 12 – THROTTLE VALVE SWITCH

Check code number\*.  
 Check switching points – see 13 63 544.  
 Check connections and wires\*\*.

→ Replace throttle valve switch.  
 Adjust throttle valve switch.

## Test Position 13 – THROTTLE VALVE POTENTIOMETER

Check tightness of throttle valve potentiometer.  
 Check contacts of plug.  
 Check wires to wiring diagram.

↓

Check adjustment of throttle valve potentiometer -- see 13 63 544.

\* See Specifications

\*\* See Wiring Diagram



## Test Position 14 – THROTTLE HOUSING

Check throttle cable adjustment. —————▶ See Groups 24 / 35 / 65.

Check full load position.

Eliminate leaks if applicable.

Check movement of throttle.

Check basic setting of throttle. —————▶ See 13 54 051.

## Test Position 16 - CONTROL UNIT

Check code number\* and manufacturing date\* → Replace control unit, if necessary.

Check control unit plug for tight fit.  
Check contacts of plug pins.

↓  
Check tied back plug connections on wire harness close to the control unit plug to the wiring diagram.

↓  
Check power supply\*\* and ground\*\*  
(with L-Jetronic check control unit test program; not with DME)

\* See Specifications

\*\* See Wiring Diagram

## Test Step 17 – AIR FLOW SENSOR

Check code number\* and manufacturing date\* —→ Replace air flow sensor.  
 Check tightness of plug contacts.  
 Check movement and swinging range of sensor plate.



Electric Test:  
 Check air flow sensor with universal test adapter —→ Replace air flow sensor.  
 and wire harness connection (35 pins).  
 Test values\*.

\* See Specifications  
 \*\* See Wiring Diagram

## 16 Fuel tank and lines

16 11 030	Fuel tank – remove and install .....	16-	1
031	Fuel tank – replace .....	16-	2
120	Expansion tank – remove and install .....	16-	3
16 12 002	Fuel intake (level transmitter) – remove and install or replace .....	16-	4
010	Charcoal canister – replace .....	16-	5
16 12 . . .	Fuel intake / level transmitter – checking .....	16-	5

## 16-1

### 16 11 030 REMOVING AND INSTALLING FUEL TANK


Empty fuel tank with a scavenging pump\*\* or unscrew drain plug if necessary.

*Caution!*

Conform with safety regulations when draining and filling fuel tank.


*Installation:*

Tightening torque\*.




Pull off cover (1).

Loosen hose clamps and pull off vent lines.



28 16 115



Remove trunk mat.

Unscrew cover (1).


Pull off plugs (2 and 3).

Loosen hose clamps (4 and 5) and pull off fuel lines.

*Installation:*

Use new hose clamps.


28 16 116



Disconnect rubber suspension ring of muffler assembly.

\* See Specifications

\*\* Source: HWB



Prevent final muffler from falling down (wire).

Unscrew bolt (1).

Unscrew tank mounting bolt (2).

*Installation:*

Tightening torque\*.

Prevent fuel tank from falling down.

Cut straps (1).

Unscrew bolts (2 and 3).

Remove fuel tank.

*Installation:*

Tightening torque\*.

\* See Specifications


## 16-2

### 16 11 031 REPLACING FUEL TANK

Removing and installing fuel tank 16 11 030.  
Unscrew nuts and pull out fuel level transmitter.

*Installation:*

Replace gasket (1).




Unscrew bolts.

Pull out fuel intake.


*Installation:*

Replace gasket (2) if necessary.




Install liners (1).

Screw on guard (2).




Unscrew and transfer bolts (1) for heat shield (2).



## 16 11 120 REMOVING AND INSTALLING EXPANSION TANK

Remove trim panels in trunk.




28 16 126

Unscrew bolts (1) and pull off lines.

*Installation:*

Use new hose clamps.



28 16 122



## 16-4

### 16 12 002 REMOVING AND INSTALLING/ REPLACING FUEL INTAKE (LEVEL TRANSMITTER)

If fuel tank is full, drain some of gasoline with a scavenging pump\*\* or through drain plug opening, if necessary.

*Caution!*

Conform with safety regulations.

Remove trunk mat.

Unscrew cover (1).

Pull off plugs (2 and 3).

Loosen hose clamps (4 and 5) and pull off fuel lines.

*Installation:*

Use new hose clamps.

Unscrew nuts and pull out level transmitter.


*Installation:*

Replace gasket

If replacing fuel level transmitter, remove transportation guard (8).

\*\* Source: HWB

Unscrew screws.  
Pull out fuel intake.



733 16 008


*Installation:*

Clean filter screen if necessary.


Replace gasket (9).



28 16 110




78 16 114



28 16 116




21 16 002



28 16 108


## 16-5

### 16 12 010 REPLACING CHARCOAL CANISTER




Loosen hose clamp (1) and pull off lines.  
Unscrew bolt (2)  
Pull out canister.  
*Installation:*  
Use new hose clamp.

28 16 125




28 16 131

There must be connection between W and 31 in float position EMPTY.




733 16 00E

### 16 12 ... CHECKING FUEL LEVEL TRANSMITTER AND FUEL TRANSFER PUMP



28 16 131

Connect ohmmeter (M 06) of BMW service test unit on terminals G and 31.



Swing fuel level transmitter slowly.  
Measure resistance with float positioned at EMPTY and FULL.  
Resistance value must change continuously while moving the float.


733 16 010


\* See Specifications

\* See Specifications


# 17 Radiator

	Coolant circuit – 528 e .....	17-	1
	Coolant circuit – 533 i / 535 i .....	17-	2
	Coolant circuit – 524 td .....	17-	3
17 00 009	Cooling system – check for leaks (with tester) .....	17-	4
010	Leakage between cooling system and combustion chamber – check .....	17-	4
039	Cooling system – bleed .....	17-	4
17 11 000	Radiator – remove and install .....	17-	5
100	Coolant expansion tank – remove and install .....	17-	6
509	Radiator – flush .....	17-	6
17 40 000	Extra fan assembly – remove and install .....	17-	7
17 11 150	Oil cooler – remove and install .....	17-	8





730 17 031




→ Circuit with thermostat closed

→ Circuit with thermostat opened

- 1 Water pump
- 2 Crankcase
- 3 Cylinder head
- 4 Thermostat housing
- 5 Thermostat
- 6 To radiator — thermostat open

- 7 Radiator outlet
- 8 To water pump
- 9 To heat exchanger (car heating)
- 10 From heat exchanger
- 11 From expansion tank




21 17 004

Circuit with opened thermostat

Circuit with closed thermostat

- 1 Water pump
- 2 Cylinder head
- 3 Thermostat housing
- 4 Radiator inlet - with opened thermostat
- 5 Radiator outlet
- 6 Heater valve


- 7 To heater exchanger (car heater)
- 8 Heat exchanger return
- 9 Housing for TLA  
(temp. dependent idle boost)
- 10 To expansion tank
- 11 Connector




## 17 00 009 CHECKING COOLING SYSTEM FOR LEAKS

Apply Special Tool 17 0 002 (with adapter 17 0 003 for screw-on cap) and produce 1 bar (14 psi) pressure.  
Cooling system does not leak, if there is no considerable pressure drop (approx. 0.1 bar or 0.7 psi) after waiting about 2 minutes.

Checking Cooling System Bayonet Cap:  
Assemble adapter 17 0 001, cap and tester 17 0 002.  
Check opening pressure\* of safety valve.



Checking Cooling System Screw-On Cap:  
Assemble adapter 17 0 003, connector 17 0 004, cap (1) and tester 17 0 002.  
Check opening pressure\* of safety valve.




20 17 003

Lift vacuum valve slightly and check for correct fit.  
Check gasket, replacing if necessary.



30 17 032

See Specifications




## 17 00 010 CHECKING FOR LEAKS BETWEEN COOLING SYSTEM AND COMBUSTION CHAMBER

Run engine to operating temperature.  
Fill "tester for cylinder head gasket"\*\*\* and perform test (see instructions supplied with equipment).




## 17 00 039 BLEEDING COOLING SYSTEM

Requirements:  
Engine at operating temperature.  
Heater set to "WARM".  
Engine running at fast idle speed.



Loosen bleeder screw and tighten again when escaping coolant is without air bubbles.  
Keep expansion tank full while bleeding.  
See Service Information of Group 00 for coolant specifications.




Mark on expansion tank shows the full level for cold coolant (approx. 20° C / 68° F).

\*\* Source: HWB



## 17 11 000 REMOVING AND INSTALLING RADIATOR




28 17 113

Unscrew cap on expansion tank.  
Unscrew drain plug (1) and drain coolant.  
Loosen hose clamp and pull off hose.  
*Caution!*  
Danger of scalding when engine is hot.  
*Installation:*  
Drain plug tightening torque\*.  
Use new hose clamp.  
Fill cooling system with coolant\*\* and bleed 17 00 039.




633 17 009

Cars with Automatic Transmission:  
Unscrew oil lines on radiator.  
*Installation:*  
Tightening torque\*.  
Check ATF level, see 24 00 009.




633 17 007

Unscrew mounting bolts on right and left sides.  
Disconnect cable.  
Lift out radiator.  
*Installation:*  
Check rubber mounts for correct installation.



78 17 114

Pull off plugs on temperature switches.




633 17 005

Unscrew fan cowl mounting screws (1).  
Loosen hose clamps and pull off hoses.

\* See Specifications  
\*\* See Service Information of Gr. 00


\* See Specifications



# 17 11 100 REMOVING AND INSTALLING COOLANT EXPANSION TANK

Unscrew cap on expansion tank.  
Loosen hose clamp (1).  
Pull off hose (2) and drain coolant in tank.  
*Caution!*  
Danger of scalding when engine is hot.

*Installation:*  
Fill cooling system with coolant\* and bleed,  
see 17 00 039.



Loosen hose clamp (1).  
Pull off hoses (2 and 3).  
Unscrew and remove full level transmitter (4).



Unscrew bolts (1).  
Remove tank.

\* See Service Information of Gr. 00

# 17 11 509 FLUSHING RADIATOR

If oil has penetrated into the coolant circuit,  
flush the radiator and expansion tank with  
solvethane\*.

Cleaning and Flushing Procedures:

1. Remove radiator and expansion tank.
2. Pour in 2 to 3 liters (2 to 3 quarts) of
3. Shake radiator and tank thoroughly and drain  
when oil has been dissolved (after 2 to 3  
minutes).
4. Install cleaned radiator and expansion tank in  
car and connect on cooling circuit.
5. Fill entire cooling circuit with hot water and  
flush thoroughly by replacing hot water  
several times as necessary, to make sure that  
all solvethane is removed.
6. Check drained coolant for traces of oil and, if  
necessary, repeat step 5. Fill and bleed cooling  
system as normally the case after completion  
of cleaning and flushing procedures.

*Caution!*

Solvethane attacks rubber seals, hoses etc. and  
consequently must not be permitted to enter or  
remain in cooling system.

Always conform with safety measures for  
handling solvethane (printed on cans).

Also refer to Service Information 11 03 80 (660)

\* Source: HWB, No. 81 22 9 400 702